



SERVICE MANUAL

SP18A / ISP60
SP21A / ISP70
SP21AJ / ISP70J

For the machine with Isuzu 4LE2 engine
(Emission standard: EPA Interim Tier 4 / EU Stage 3-A)



/// NACHI
CORPORATION

1152, RYOKE, AGE0, SAITAMA, JAPAN.

Introduction

This manual describes correct adjustment and servicing procedures for Wheel type self- propelled Elevation work platforms: SP18A/ISP60, SP21A/ISP70 and SP21AJ/ISP70J in order to ensure the most effective use of superb performance and excellent features for your satisfaction.

Read this manual carefully and understand the descriptions correctly before making any repair or maintenance works.

Always be sure of the following items when conducting repair or maintenance works.

- **Use only the spare parts approved by the manufacturer, particularly for load- supporting and safety- related components.**
- **Do not make any modifications to the machine without obtaining the manufacturer's approval.**

The design check, the manufacturing check as well as the practical test should be conducted by the approved agent, if the modification which would affect the stability, strength or performance of the machine is made.

Please, note that the numerical values in this manual may be subject to change due to engineering improvement.

Index

1. General information

| | |
|--|-------|
| SP18A Specifications | 1- 2 |
| SP21A Specifications | 1- 3 |
| SP21AJ Specifications | 1- 4 |
| Overall dimensions (SP18A / ISP60) | 1- 5 |
| Overall dimensions (SP21A / ISP70) | 1- 6 |
| Overall dimensions (SP21AJ / ISP70J) | 1- 7 |
| Work range diagram (SP18A / ISP60) | 1- 8 |
| Work range diagram (SP21A / ISP70) | 1- 9 |
| Work range diagram (SP21AJ / ISP70J) | 1- 10 |
| Safety devices | 1- 11 |

2. Mechanical section

| | |
|---|-------|
| Diesel engine | 2- 2 |
| Hydraulic pump and Oil cooler installations | 2- 3 |
| Chassis | 2- 4 |
| Rotation bearing | 2- 5 |
| Boom rotation gearbox | 2- 7 |
| Boom | 2- 8 |
| 1. Structures | 2- 8 |
| 2. Hydraulic hoses and Electrical cables arrangements | 2- 8 |
| 3. Inspection procedures | 2- 9 |
| 4. Extension / Retraction wire ropes | 2- 10 |
| 5. Adjustment of Extension / Retraction wire ropes | 2- 11 |
| 6. Tension of Electric cables | 2- 13 |
| 7. Sectional drawings | 2- 14 |
| Fly- jib | 2- 16 |
| Platform (for SP18A / ISP60 and SP21A / ISP70) | 2- 17 |
| Platform (for SP21AJ / ISP70J) | 2- 18 |

3. Hydraulic section

| | |
|--|-------|
| Oil reservoir | 3- 2 |
| High- pressure line filter for Boom functions | 3- 3 |
| High- pressure line filter for Charge pump | 3- 4 |
| Adaptor filter | 3- 5 |
| Hydraulic pump | 3- 6 |
| Emergency pump | 3- 8 |
| Main control valve | 3- 9 |
| Platform rotation solenoid valve (302- 00153- 00D) | 3- 11 |
| Platform rotation / Fly jib solenoid valve (303- 00152- 00D) | 3- 12 |
| Travel speed select solenoid valve | 3- 13 |

| | |
|--|-------|
| Parking brake release solenoid valve ----- | 3- 14 |
| Oscillation axle release solenoid valve ----- | 3- 15 |
| Unit valve ----- | 3- 16 |
| Flow priority valve ----- | 3- 17 |
| Flow divider valve ----- | 3- 18 |
| Swivel joint ----- | 3- 19 |
| Boom elevation cylinder ----- | 3- 20 |
| Single holding valve (for Boom elevation cylinder) ----- | 3- 21 |
| 1. Inspection procedures ----- | 3- 22 |
| Boom telescope cylinder ----- | 3- 23 |
| Double holding valve (for Boom telescope cylinder) ----- | 3- 24 |
| 1. Inspection procedures ----- | 3- 25 |
| Single pilot check valve (for Boom telescope cylinder) ----- | 3- 26 |
| Fly- jib cylinder ----- | 3- 27 |
| Double holding valve (for Fly- jib cylinder) ----- | 3- 28 |
| Overload relief valve (for Fly- jib cylinder) ----- | 3- 29 |
| Oscillation axle lock cylinder ----- | 3- 30 |
| Lock valve (for Oscillation axle lock cylinder) ----- | 3- 31 |
| Steering cylinder ----- | 3- 32 |
| Double pilot check valve (for Steering cylinder) ----- | 3- 33 |
| Platform leveling system ----- | 3- 34 |
| 1. Note on function ----- | 3- 35 |
| 2. Inspection procedures ----- | 2- 35 |
| 3. Air bleeding procedures ----- | 3- 35 |
| Combination valve (for Platform leveling system) ----- | 3- 36 |
| Lower leveling cylinder (for the machines without Fly jib) ----- | 3- 37 |
| Lower leveling cylinder (for the machines with Fly jib) ----- | 3- 38 |
| Upper leveling cylinder (for the machines without Fly jib) ----- | 3- 39 |
| Double holding valve (for Upper leveling cylinder without Fly- jib) ----- | 3- 40 |
| Upper leveling cylinder (for the machines with Fly jib) ----- | 3- 41 |
| Double pilot check valve (for Upper leveling cylinder with Fly- jib) ----- | 3- 42 |
| Boom rotation motor ----- | 3- 43 |
| Platform rotary actuator ----- | 3- 44 |
| 1. Function of Rotary actuator ----- | 3- 45 |
| 2. Platform rotary actuator air bleeding procedures ----- | 3- 46 |
| Travel motor ----- | 3- 47 |
| Check valve block ----- | 3- 49 |

4. Electric section

| | |
|--|-------|
| Main CPU box (M2A) ----- | 4- 2 |
| 1. Input / Output characteristics (for the machine without Duplicated sensors) ----- | 4- 3 |
| 2. Input / Output characteristics (for the machine with Duplicated sensors) ----- | 4- 4 |
| 3. Error codes and their countermeasures ----- | 4- 5 |
| Upper control box ----- | 4- 7 |
| 1. Electrical schematic ----- | 4- 8 |
| Sub- CPU board (M4A) ----- | 4- 9 |
| 1. Input / Output characteristics ----- | 4- 10 |
| Joystick controller ----- | 4- 11 |
| Foot switch ----- | 4- 12 |
| Lower control box ----- | 4- 13 |
| 1. Electrical schematic ----- | 4- 14 |
| Main key switch ----- | 4- 15 |
| Relays in Lower control box ----- | 4- 16 |
| 1. Relay CR1 ----- | 4- 16 |
| 1. Relay CR3, 4, 5, 6, 7 and 10 ----- | 4- 16 |
| Engine control box ----- | 4- 17 |
| 1. EGR cut controller ----- | 4- 18 |
| 2. Timer relay ----- | 4- 18 |
| 3. EGR cut relay ----- | 4- 19 |
| 4. Safety relay ----- | 4- 20 |
| 5. Charge relay ----- | 4- 21 |
| 6. Relay CR-21 ----- | 4- 22 |
| 7. Contactor for Emergency pump ----- | 4- 22 |
| Boom length sensors ----- | 4- 23 |
| 1. Boom length sensor (R/H) ----- | 4- 24 |
| 2. Boom length sensor (L/H) ----- | 4- 25 |
| Boom angle sensor R/H ----- | 4- 26 |
| Boom angle sensor L/H ----- | 4- 27 |
| Boom length limit switches ----- | 4- 28 |
| Tilt sensor ----- | 4- 29 |
| Accelerator motor (for Diesel engine) ----- | 4- 30 |
| Fuel pump for Automatic air Bleeding system (for Diesel engine) ----- | 4- 31 |
| Air cleaner clog detect switch ----- | 4- 31 |
| Low fuel level detect switch ----- | 4- 32 |
| Starter motor ----- | 4- 32 |
| Alternator ----- | 4- 33 |

5. Electric circuit for individual system

| | |
|--|-------|
| Engine start and stop system (for Diesel engine)----- | 5- 2 |
| Boom elevation system ----- | 5- 3 |
| Boom telescope system ----- | 5- 4 |
| Boom rotation system ----- | 5- 5 |
| Traveling system ----- | 5- 6 |
| H / V control system ----- | 5- 7 |
| Steering and Platform level adjust systems ----- | 5- 8 |
| Platform rotation and Fly- jib articulation systems ----- | 5- 9 |
| Work range limit and Overload sensing systems (for the machine without Duplicated sensors) ----- | 5- 10 |
| Work range limit and Overload sensing systems (for the machine with Duplicated sensors) ----- | 5- 11 |
| Accelerator and Oscillation axle release systems ----- | 5- 12 |
| Emergency pump system ----- | 5- 13 |
| Horn, Work light and Hydraulic generator systems ----- | 5- 14 |

6. Inspection and Adjustment

| | |
|--|------|
| Inspection of Limited work radius and Limited boom angle ----- | 6- 2 |
| SP18A / ISP60 Inspection data sheet ----- | 6- 3 |
| SP21A / ISP70 Inspection data sheet ----- | 6- 4 |
| SP21AJ / ISP70J Inspection data sheet ----- | 6- 5 |
| Engine RPM measurement procedures ----- | 6- 6 |
| System pressure adjustment procedures ----- | 6- 7 |

7. Appendix

| | |
|--|-------|
| Hydraulic circuit diagram ----- | 7- 2 |
| Electrical circuit diagram, Platform ----- | 7- 4 |
| Electrical circuit diagram, Turntable ----- | 7- 5 |
| Electrical wiring chart, Platform ----- | 7- 7 |
| Electrical wiring chart, Turntable ----- | 7- 8 |
| Locations of Hydraulic and Electrical components ----- | 7- 10 |
| Water- proof connectors ----- | 7- 13 |
| Color code of wires ----- | 7- 15 |
| Tightening torque standard ----- | 7- 16 |

8. Inspection manual

| | |
|--|-------|
| Procedures of Daily inspections ----- | 8- 2 |
| Daily inspection check sheet ----- | 8- 4 |
| Procedures of Periodical inspections ----- | 8- 5 |
| Procedures of Function tests ----- | 8- 9 |
| Periodical inspection check sheet ----- | 8- 10 |
| Function tests check sheet ----- | 8- 12 |
| Major alterations and repairs ----- | 8- 12 |

1. General information

SP18A / ISP60 Specifications

| Model | | | | SP18A / ISP60 | | |
|------------------------------|---|--|---|---|-------------------------|-----------|
| Weight | Gross weight | | 12,300 kg | 27,120 LBS | | |
| | Maximum tire loading force | | 9,800 kg | 21,610 LBS | | |
| | Maximum tire ground contact pressure | | 7.0 kg/cm ² | 100 PSI | | |
| Gradeability | | | 45 % (24 degrees) | ← | | |
| Maximum allowable tilt angle | | | 5 degrees | ← | | |
| Maximum allowable wind speed | | | 12.5 meters / second | 28 MPH | | |
| Diesel engine | Model | | Isuzu AU-4LE2XYBB-01 | ← | | |
| | Total displacement | | 2,179 cc | 133.0 in ³ | | |
| | Maximum output power | | 41.1 kw / 2,200 rpm | 55.1 HP / 2,200 rpm | | |
| | Maximum output torque | | 207 N- m / 1,600 rpm (21 kg-m / 1,600 rpm) | 153 ft- lbs / 1,600 rpm | | |
| | Fuel tank capacity | | 150 liters | 39.6 gallons | | |
| | Engine oil capacity | | 7.6 ~ 10.3 liters | 2.00 ~ 2.72 gallons | | |
| | Coolant capacity | | 8.6 liters | 2.27 gallons | | |
| | Battery | | DC12V / 70Ah x 2 | ← | | |
| | Engine rpm | | Low (Idling) | 1,020 rpm | ← | |
| Mid | | | 1,300 rpm | ← | | |
| High | | | 2,200 rpm | ← | | |
| Platform | Specific working load | | 227 kg or 2 persons + Tools (67 kg) | 500 LBS or 2 persons + Tools (148 LBS) | | |
| | Maximum allowable side force | | 41 kg | 90 LBS | | |
| | Maximum floor height | | 18 meters | 59ft – 1in | | |
| | Maximum work radius | | 16.7 meters | 54ft – 9in | | |
| | Rotation angle | | 180 degrees | ← | | |
| Boom | Boom length | | 6.905 ~ 16.625 meters | 22ft- 8in ~ 54ft- 7in | | |
| | Boom angle | | - 12 ~ 70 degrees | ← | | |
| | Rotation angle | | 360 degrees (Continuous) | ← | | |
| Tires | Type | | Foam filled tire | ← | | |
| | Size | | 15 x 19.5 | ← | | |
| Actuating speed | Boom elevation (with the boom fully retracted) | | Up | 40 ± 6 seconds | ← | |
| | | | Down | 40 ± 6 seconds | ← | |
| | Boom telescope | | Out | 35 ± 5 seconds | ← | |
| | | | In | 30 ± 5 seconds | ← | |
| | Boom rotation (with the boom fully retracted) | | CW | 80 ± 12 seconds | ← | |
| | | | CCW | 80 ± 12 seconds | ← | |
| | Platform rotation | | CW | 15 ± 5 seconds | ← | |
| | | | CCW | 15 ± 5 seconds | ← | |
| | Horizontal movement | | Out | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | | | In | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | Vertical movement | | Up | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | | | Down | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | Traveling | High speed | Forward | 5.5 ± 0.8 km/hour | 3.42 ± 0.50 MPH | |
| | | | Reverse | 5.5 ± 0.8 km/hour | 3.42 ± 0.50 MPH | |
| | | | Forward | 2.8 ± 0.4 km/hour | 1.74 ± 0.25 MPH | |
| Reverse | | | 2.8 ± 0.4 km/hour | 1.74 ± 0.25 MPH | | |
| Low speed | | Forward | 1.3 ± 0.2 km/hour | 0.81 ± 0.12 MPH | | |
| | | Reverse | 1.3 ± 0.2 km/hour | 0.81 ± 0.12 MPH | | |
| Hydraulic system | Hydraulic oil | Tank capacity | | 150 liters | 39.6 gallons | |
| | | Recommended oil | | Shell Tellus oil T22 | ← | |
| | Specific pressure | Travelling system | | 340 kg/cm ² | 4,840 PSI | |
| | | Boom functions | | 210 kg/cm ² | 2,990 PSI | |
| | | Platform rotation, Steering functions | | 140 kg/cm ² | | 1,990 PSI |
| | | | | | | |

SP21A / ISP70 Specifications



| Model | | | | SP21A / ISP70 | | |
|------------------------------|---|-----------|---|---|-------------------------|-----------------|
| Weight | Gross weight | | 14,500 kg | 31,970 LBS | | |
| | Maximum tire loading force | | 11,400 kg | 25,130 LBS | | |
| | Maximum tire ground contact pressure | | 8.0 kg/cm ² | 114 PSI | | |
| Gradeability | | | 45 % (24 degrees) | ← | | |
| Maximum allowable tilt angle | | | 5 degrees | ← | | |
| Maximum allowable wind speed | | | 12.5 meters / second | 28 MPH | | |
| Diesel Engine | Model | | Isuzu AU-4LE2XYBB-01 | ← | | |
| | Total displacement | | 2,179 cc | 133.0 in ³ | | |
| | Maximum output power | | 41.1 kw / 2,200 rpm | 55.1 HP / 2,200 rpm | | |
| | Maximum output torque | | 207 N- m / 1,600 rpm (21 kg-m / 1,600 rpm) | 153 ft- lbs / 1,600 rpm | | |
| | Fuel tank capacity | | 150 liters | 39.6 gallons | | |
| | Engine oil capacity | | 7.6 ~ 10.3 liters | 2.00 ~ 2.72 gallons | | |
| | Coolant capacity | | 8.6 liters | 2.27 gallons | | |
| | Battery | | DC12V / 70Ah x 2 | ← | | |
| | Engine rpm | | Low (Idling) | 1,020 rpm | ← | |
| Mid | | | 1,300 rpm | ← | | |
| High | | | 2,200 rpm | ← | | |
| Platform | Specific working load | | 227 kg or 2 persons + Tools (67 kg) | 500 LBS or 2 persons + Tools (148 LBS) | | |
| | Maximum allowable side force | | 41 kg | 90 LBS | | |
| | Maximum floor height | | 21 meters | 68ft – 11in | | |
| | Maximum work radius | | 18.6 meters | 61ft – 0in | | |
| | Rotation angle | | 180 degrees | ← | | |
| Boom | Boom length | | 8.440 ~ 20.190 meters | 27ft- 8in ~ 66ft- 3in | | |
| | Boom angle | | - 12 ~ 70 degrees | ← | | |
| | Rotation angle | | 360 degrees (Continuous) | ← | | |
| Tires | Type | | Foam filled tire | ← | | |
| | Size | | 15 x 19.5 | ← | | |
| Actuating speed | Boom elevation (with the boom fully retracted) | | Up | 40 ± 6 seconds | ← | |
| | | | Down | 40 ± 6 seconds | ← | |
| | Boom telescope | | Out | 45 ± 7 seconds | ← | |
| | | | In | 35 ± 5 seconds | ← | |
| | Boom rotation (with the boom fully retracted) | | CW | 90 ± 12 seconds | ← | |
| | | | CCW | 90 ± 12 seconds | ← | |
| | Platform rotation | | CW | 15 ± 5 seconds | ← | |
| | | | CCW | 15 ± 5 seconds | ← | |
| | Horizontal movement | | Out | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | | | In | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | Vertical movement | | Up | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | | | Down | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | Traveling | | High speed | Forward | 5.5 ± 0.8 km/hour | 3.42 ± 0.50 MPH |
| | | | | Reverse | 5.5 ± 0.8 km/hour | 3.42 ± 0.50 MPH |
| | | | Mid speed | Forward | 2.8 ± 0.4 km/hour | 1.74 ± 0.25 MPH |
| | | | | Reverse | 2.8 ± 0.4 km/hour | 1.74 ± 0.25 MPH |
| | | Low speed | Forward | 1.3 ± 0.2 km/hour | 0.81 ± 0.12 MPH | |
| | | | Reverse | 1.3 ± 0.2 km/hour | 0.81 ± 0.12 MPH | |
| Hydraulic system | Hydraulic oil | | Tank capacity | 150 liters | 39.6 gallons | |
| | | | Recommended oil | Shell Tellus oil T22 | ← | |
| | Specific pressure | | Travelling system | 340 kg/cm ² | 4,840 PSI | |
| | | | Boom functions | 210 kg/cm ² | 2,990 PSI | |
| | | | Platform rotation, Steering functions | 140 kg/cm ² | 1,990 PSI | |

SP21AJ / ISP70J Specifications

| Model | | | | SP21AJ / ISP70J | | |
|------------------------------|---|--|---|---|-------------------------|-----------------|
| Weight | Gross weight | | 14,700 kg | 32,410 LBS | | |
| | Maximum tire loading force | | 11,300 kg | 24,910 LBS | | |
| | Maximum tire ground contact pressure | | 8.0 kg/cm ² | 114 PSI | | |
| Gradeability | | | 45 % (24 degrees) | ← | | |
| Maximum allowable tilt angle | | | 5 degrees | ← | | |
| Maximum allowable wind speed | | | 12.5 meters / second | 28 MPH | | |
| Diesel Engine | Model | | Isuzu AU-4LE2XYBB-01 | ← | | |
| | Total displacement | | 2,179 cc | 133.0 in ³ | | |
| | Maximum output power | | 41.1 kw / 2,200 rpm | 55.1 HP / 2,200 rpm | | |
| | Maximum output torque | | 207 N- m / 1,600 rpm (21 kg-m / 1,600 rpm) | 153 ft- lbs / 1,600 rpm | | |
| | Fuel tank capacity | | 150 liters | 39.6 gallons | | |
| | Engine oil capacity | | 7.6 ~ 10.3 liters | 2.00 ~ 2.72 gallons | | |
| | Coolant capacity | | 8.6 liters | 2.27 gallons | | |
| | Battery | | DC12V / 70Ah x 2 | ← | | |
| | Engine rpm | | Low (Idling) | 1,020 rpm | ← | |
| Mid | | | 1,300 rpm | ← | | |
| High | | | 2,200 rpm | ← | | |
| Platform | Specific working load | | 227 kg or 2 persons + Tools (67 kg) | 500 LBS or 2 persons + Tools (148 LBS) | | |
| | Maximum allowable side force | | 41 kg | 90 LBS | | |
| | Maximum floor height | | 21 meters | 68ft – 11in | | |
| | Maximum work radius | | 17.8 meters | 58ft – 5in | | |
| | Rotation angle | | 180 degrees | ← | | |
| Boom | Boom length | | 8.440 ~ 18.690 meters | 27ft- 8in ~ 61ft- 4in | | |
| | Boom angle | | - 12 ~ 70 degrees | ← | | |
| | Rotation angle | | 360 degrees (Continuous) | ← | | |
| Fly- jib | Jib length | | 1.65 meters | 5ft- 5in | | |
| | Jib articulating angle | | - 60 ~ 70 degrees | ← | | |
| Tires | Type | | Foam filled tire | ← | | |
| | Size | | 15 x 19.5 | ← | | |
| Actuating speed | Boom elevation (with the boom fully retracted) | | Up | 40 ± 6 seconds | ← | |
| | | | Down | 40 ± 6 seconds | ← | |
| | Fly- jib elevation | | Up | 30 ± 5 seconds | ← | |
| | | | Down | 25 ± 5 seconds | ← | |
| | Boom telescope | | Out | 40 ± 6 seconds | ← | |
| | | | In | 30 ± 5 seconds | ← | |
| | Boom rotation (with the boom fully retracted) | | CW | 110 ± 12 seconds | ← | |
| | | | CCW | 110 ± 12 seconds | ← | |
| | Platform rotation | | CW | 15 ± 5 seconds | ← | |
| | | | CCW | 15 ± 5 seconds | ← | |
| | Horizontal movement | | Out | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | | | In | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | Vertical movement | | Up | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | | | Down | 200 ± 30 mm/second | 7.9 ± 1.2 inches/second | |
| | Traveling | | High speed | Forward | 5.5 ± 0.8 km/hour | 3.42 ± 0.50 MPH |
| | | | | Reverse | 5.5 ± 0.8 km/hour | 3.42 ± 0.50 MPH |
| | Traveling | | Mid speed | Forward | 2.8 ± 0.4 km/hour | 1.74 ± 0.25 MPH |
| | | | | Reverse | 2.8 ± 0.4 km/hour | 1.74 ± 0.25 MPH |
| | | | Low speed | Forward | 1.3 ± 0.2 km/hour | 0.81 ± 0.12 MPH |
| Reverse | | | | 1.3 ± 0.2 km/hour | 0.81 ± 0.12 MPH | |
| Hydraulic system | Hydraulic oil | Tank capacity | 150 liters | 39.6 gallons | | |
| | | Recommended oil | Shell Tellus oil T22 | ← | | |
| | Specific pressure | Travelling system | 340 kg/cm ² | 4,840 PSI | | |
| | | Boom functions | 210 kg/cm ² | 2,990 PSI | | |
| | | Fly- jib, Platform rotation, Steering functions | 140 kg/cm ² | 1,990 PSI | | |




Overall dimensions (SP18A / ISP60)

600-00053-18



Overall dimensions (SP21A / ISP70)


600-00049-99



Overall dimensions (SP21AJ / ISP70J)


600-00056-19

This drawing shows the machine that is equipped with 8-foot platform



Working range diagram (SP18A / ISP60)


Specific working load: 227 kg (500 LBS)



The working range of the platform shown in the above diagram is obtained at any boom-rotated directions.

Working range diagram (SP21A / ISP70)


Specific working load: 227 kg (500 LBS)



The working range of the platform shown in the above diagram is obtained at any boom-rotated directions.

Working range diagram (SP21AJ / ISP70J)

Specific working load: 227 kg (500 LBS)



The working range of the platform shown in the above diagram is obtained at any boom-rotated directions.



Safety Devices

The safety devices ensure safety and prevent damage to the machine.



| Name | Main function |
|--|--|
| Relief valves | Protect the hydraulic components by relieving abnormally high pressure in the hydraulic system. |
| Single holding valve on Boom elevation cylinder | Prevents the boom from natural descent in the event of hydraulic hose breakage. |
| Double holding valve on Boom telescope cylinder | Prevents the boom from natural retraction and extension in the event of hydraulic hose breakage. |
| Double holding (or pilot check) valve on Upper leveling cylinder | Maintains the platform level in the event of hydraulic hose breakage. |
| Foot switch | The boom, traveling and platform rotating functions are disabled unless the foot switch is depressed. |
| Motion alarm buzzer | The motion alarm buzzer sounds when the machine is in motion to warn the people nearby. |
| Emergency stop switch | Stops all of the movements of the machine when this switch is pressed. |
| Tilt alarm buzzer | The tilt alarm buzzer sounds, if the machine tilts more than 5 degrees. |
| Travel speed limit system | The high and mid speed traveling is disabled, unless the boom is retracted and is lowered under the horizontal. |
| Rotation lock pin | Fixes the turntable to the chassis to prevent the turntable from being rotated when transporting the machine. |
| Emergency pump | Auxiliary hydraulic pump driven by the battery. And used to lower the platform in the event of engine or main pump failure. |
| Alarm horn | Before moving the machine, sound the alarm horn to warn the people around the machine. |
| Boom rotating speed limit system | This system automatically reduces the boom rotation speed to ensure the safe speed as the boom is extended. |
| Boom elevating speed limit system | This system automatically reduces the boom rising and lowering speed to ensure the safe speed as the boom is extended. |
| Traveling speed limit system | This system automatically reduces the traveling speed to ensure the safe speed as the boom extended. |
| Work range limit system | This system automatically limits the work radius (Outreach) of the platform within the specific range. (This system is not equipped on SP18A/ISP60.) |
| Boom wire rope failure detecting system | This system disables the boom extending functions in the event of the boom extension wire rope failure. |
| Overload sensing system (CE model) | This system disables all of the functions when the platform is overloaded. (This system is equipped only on CE specifications.) |
| Boom / Travel function interlock system (CE model) | This system stops all of the functions when the travel and boom operations are conducted simultaneously. (This system is equipped only on CE specifications.) |

2. Mechanical section


Diesel engine



Fuel system



A - detail



Accelerator motor - detail




Adjustment procedures of Engine rpm

See the section of 6. *Inspection and Adjustment* for detail.


| | |
|---|---|
| 1 | Warm up the engine. |
| 2 | Turn the <i>Idle adjust screw</i> to adjust the Low (Idling) speed to 1,020 rpm. |
| 3 | Turn the <i>Double nuts</i> to adjust the High speed to 2,200 rpm. |
| 4 | Turn the <i>Mid speed adjust trimmer</i> that is installed on the accelerator motor to adjust the Mid speed to 1,300 rpm. |

- Load the engine by imposing the relief pressure, when adjusting the High and Mid speeds.


Hydraulic pump and Oil cooler installations




Chassis




- Note:**
- Set the *Soft zones* of the inner and outer races at the positions shown in the figure, when installing the rotation bearing onto the chassis.
 - See the section of *Rotation bearing* for the detail of Rotation bearing.



A - view



C - view




B - view

Insert the *Thrust washers* to the front side

Front

Apply molybdenum grease to the pin, thrust washers and bushings before installing the pin


Pin



D - view

Rotation bearing

This rotation bearing is mounted between the chassis and the turntable, and enables the turntable to rotate freely over the chassis.



1. Inspection procedures

1. Check the anchor bolts and nuts for looseness, omission and any other damage.
 - a. Loose bolts should be removed and checked for damaged threads and deformation.
 - b. When re-installing anchor bolts or nuts, apply thread lock agent to the threads.
 - Recommended thread lock agent: Loctite 262.
 - c. Tighten anchor bolts by the specific tightening torque.
 - Specified tightening torque: 39 kg-m (282 ft-lbs)

NOTE:

In case it is hard to loosen anchor bolts due to lock agent, heat them up by using a gas burner to melt the agent.

The heated or removed bolts and nuts should be replaced with new ones.

2. Check the ring gear for cracks and any other damage.


To make the cracks obvious, use a liquid penetrant test such as a color check.
3. Check the backlash between the ring gear of the rotation bearing and the pinion gear of the rotation gearbox.
 - Standard backlash: 0.6 mm (0.024 in) or less.

NOTE:

To check the backlash, rotate the turntable and insert a lead wire between the ring gear and the pinion gear of the rotation gearbox to crush the wire, and then measure the thickness of the crushed lead wire.

If the backlash is inadequate, adjust it by moving the rotation gearbox.

4. Check the free-play between inner and outer races of the rotation bearing as follows.



- Set a dial gauge between the turntable and the chassis as shown in the figure above.
- Retract and raise the boom fully, and set the pointer of the dial gauge at ZERO.
- Lower the boom, set it horizontally, extend it fully to its maximum outreach and then read the dial gauge again.

The reading of the gauge is the numerical value of free-play.

- Standard free-play: 0.9 mm (0.035 in).
- Serviceable limit: 3.0 mm (0.118 in).


NOTE:

The rotation bearing should be replaced, if the free-play exceeds the serviceable limit.

Boom rotation gearbox

The boom rotation gearbox reduces the rotation speed of the hydraulic motor and increases the torque to rotate the turntable through the boom rotation bearing.

- Type ----- Worm gear
- Reduction ratio ----- 1/50
- Gear oil ----- Shell Spirax EP- 90 (1.7 liters, 0.45 gallons)
- Oil change interval ----- 1,200 hours or annually




| | | | | | |
|----|-----------------|----|-----------------------|----|---------------|
| 01 | Case | 11 | Needle roller bearing | 21 | Bolt |
| 02 | Cover | 12 | Ball bearing | 22 | Spring washer |
| 03 | Worm shaft | 13 | Taper roller bearing | 23 | ----- |
| 04 | Worm wheel | 14 | Oil seal | 24 | Shim |
| 05 | Pinion shaft | 15 | Oil seal | 25 | Eye bolt |
| 06 | Motor flange | 16 | O- ring | 26 | ----- |
| 07 | Cover | 17 | O- ring | 27 | Bearing nut |
| 08 | Oil drain plug | 18 | O- ring | 28 | Lock washer |
| 09 | Plug | 19 | O- ring | 29 | Bolt |
| 10 | Oil level gauge | 20 | ----- | 30 | Spring washer |

1. Inspection

1. Check the gear oil level and replenish or change the oil, if necessary.

Recommended gear oil ----- Shell Spirax EP- 90 (1.7 liters, 0.45 gallons)

To check the oil level, screw in the oil level gauge (Dipstick) fully into the gearbox first, then remove the dipstick. The proper oil level is between the two lines on the dipstick as shown in the figure below.



2. Check the backlash between the pinion of the rotation gearbox and the ring gear of the rotation bearing.

Standard backlash ----- 0.6 mm (0.024 in) or less.

Follow the next procedures to check the backlash.

- 1) Place a lead wire between the pinion and the ring gear of the Rotation bearing.
- 2) Rotate the turntable slowly and crush the lead wire.
- 3) Measure the thickness of the crushed lead wire to determine the backlash.
- 4) If the backlash is inadequate, loosen the fixing bolts and nuts of the Boom rotation gearbox, and then adjust the backlash by shifting the position of the rotation gearbox.

2. Disassembly and Re- assembly

1. Remove both of the **Oil level gauge** (10) and the **Oil drain plug** (08) to drain the gear oil thoroughly.
2. Remove the **Boom rotation motor** from the rotation gearbox.
3. Remove the **Cover** (02), the **Cover** (07) and the **Motor flange** (06) from the **Case** (01).
4. Pull out the **Worm shaft** (03) from the **Case** (01) by rotating the **Pinion shaft** (05).
5. Unlock the **Lock washer** (28), remove the **Bearing nut** (27), and then pull out the **Pinion shaft** (05) from the **Case** (01).
6. Remove the **Worm wheel** (04) from the **Case** (01).
7. Remove all of the bearings and the oil seals, if necessary.
8. Check each part and replace the part, if necessary.
9. Reverse the above procedures to re- assemble the rotation gearbox.
10. Re- install the **Boom rotation motor** onto the rotation gearbox, and then refill the gear oil.

Boom

1. Structures

The boom consists of the 1st, 2nd, and 3rd boom sections, Boom telescope cylinder, the Extension/ Retraction wire ropes, Hydraulic hoses, Electric cables and Sheaves.

The 2nd boom section is extended or retracted directly by the Boom telescope cylinder.

However, the 3rd boom section is telescoped by the movement of the 2nd boom section through the extension and retraction wire ropes.

The 1st and 2nd boom sections are connected by the Boom telescope cylinder, which directly extends and retracts the 2nd boom section.


While, the 3rd boom section is connected to the 2nd boom section by the extension and retraction wire ropes as shown in the figure below.

The retraction wire ropes are connected to the tail of the 3rd boom section through the tail sheave installed on the tail of the 2nd boom section.


The extension wire ropes are also connected to the tail of the 3rd boom section through the head sheave that is installed on the head of the 2nd boom section.

The 2nd boom section is extended by the Boom telescope cylinder together with the head sheave coming along. As a result, the 3rd boom section is pulled by the extension wire rope and accordingly goes out of the 2nd boom section.

When retracting the boom, the 2nd boom section is retracted by the Boom telescope cylinder together with the tail sheave coming along. As a result, the 3rd boom section is pulled by the retraction wire rope and accordingly goes into the 2nd boom section.



2. Hydraulic hoses and Electrical cables arrangements




3. Inspection procedures

The boom is to be disassembled for a detailed inspection every 4 years.

1. Clearance between each boom section.

1) Check the clearance between each wear pad and boom section.

- Specific clearance:



| | | Vertical direction | Lateral direction, Upper Sum of Right and Left | Lateral direction, Lower Sum of Right and Left |
|---|-----------|----------------------------------|---|---|
| Clearance between 1 st and 2 nd boom sections | boom head | 0.5 ~ 0.9 mm (0.020 ~ 0.035") | 1.0 ~ 2.0 mm (0.039 ~ 0.079") | 6.0 ~ 7.0 mm (0.236 ~ 0.276") |
| | boom tail | 0.5 ~ 0.9 mm (0.020 ~ 0.035") | 1.0 ~ 2.0 mm (0.039 ~ 0.079") | 1.0 ~ 2.0 mm (0.039 ~ 0.079") |
| Clearance between 2 nd and 3 rd boom sections | boom head | 0.5 ~ 1.0 mm (0.020 ~ 0.039") | 1.0 ~ 2.0 mm (0.039 ~ 0.079") | 6.0 ~ 7.0 mm (0.236 ~ 0.276") |
| | boom tail | 2.0 ~ 3.0 mm (0.079 ~ 0.118") | 1.0 ~ 2.0 mm (0.039 ~ 0.079") | 1.0 ~ 2.0 mm (0.039 ~ 0.079") |

- 2) If the clearance is not adequate, adjust the clearance by adding or reducing the spacers installed under each wear pad.

NOTE :

- Check each wear pad for wear, and replace it if necessary.
- Apply a thread lock agent to the thread of each setscrew for wear pad before setting.

Recommended thread lock agent: Loctite 262.


2. Bend of boom section.

- 1) Set the boom horizontally and extend it fully.

- 2) Visually check the bend of each boom section and disassemble the boom to measure the bend, if the excessive bend is observed.

- Serviceable limit:

| | SP18A | SP18AJ | SP21A | SP21AJ |
|--------------------|------------------|-----------------|------------------|------------------|
| Vertical direction | 10.6 mm (0.417") | 9.8 mm (0.386") | 12.1 mm (0.476") | 12.1 mm (0.476") |
| Lateral direction | 7.1 mm (0.280") | 6.5 mm (0.256") | 8.1 mm (0.319") | 8.1 mm (0.319") |



3. Dents, scratches.

Check the each boom section for both dents and scratches thoroughly. If any dent or scratch that exceeds the serviceable limit is observed, replace the boom section.

- Serviceable limit:

“Length = 50 mm (1.97 in) or more” and “Depth = 2 mm (0.08 in) or more”

4. Cracks.

Check each boom section thoroughly for cracks. For fine cracks, use **COLOR CHECK** or penetrant check.

- Pay special attention, when checking each pin boss and welded section.


5. Lubrications

Check the grease on the wear pad- sliding surface of each boom section and apply multipurpose grease, if necessary.

4. Extension / Retraction wire ropes


After disassembling the boom, inspect the extension and retraction wire ropes as follows.

1. Measure the diameter of both the extension and retraction wire ropes, using a slide calipers.
Replace the wire rope, if the decrease of the diameter is more than 3 % of the nominal diameter.




| | Nominal diameter | Serviceable limit |
|----------------------|--------------------------|----------------------------------|
| Retraction wire rope | ϕ 8.0 mm (0.32 in) | ϕ 7.8 mm (0.31 in) or less |
| Extension wire rope | ϕ 12.0 mm (0.47 in) | ϕ 11.7 mm (0.46 in) or less |


2. Check for broken wires.
If you find 3 or more single wires cut in one twist stroke, replace the wire rope.




3. Check wire ropes for rust formation.
If the rust is penetrated into the rope, replace the wire rope.



4. If any kinks are observed, replace the wire rope.
Also, a deformed wire rope requires replacement.




5. Check carefully the end sections of the wire rope, especially sections A and B.
Replace the wire rope, if any defects are found.




5. Adjustment of Extension/Retraction wire ropes


Adjust the tension of the Extension/Retraction wire ropes as follows.




1. Set the boom horizontally and retract it fully.
2. Unlock the **Lock nuts B**, turn the **Adjust nuts B** and adjust the “**Dimension L2**” to 78 mm (3.1 inches).
 - **Caution:** Do not twist the wire ropes when turning the adjust and lock nuts.
3. Loosen the **Lock nuts A** and the **Adjust nuts A** at the terminal end of the extension wire ropes, and then make sure that the 8 plate springs, 2 washers and 1 collar are assemble at the end of the extension wire rope as shown in the figure below.



4. Tighten the **Adjust nut A** until the washers touch the collar as shown in the figure below.




5. Measure the “**Dimension L1**” and make sure that it is 460 ~ 480 mm (18.1 ~ 18.9 inches).
6. Adjust the “**Dimension L1**” as follows, if the “**Dimension L1**” is not 460 ~ 480 mm (18.1 ~ 18.9 inches).
- In case the “**Dimension L1**” is shorter than 460 mm (18.1 inches).
Screw out the **Adjust nuts B** and screw in the **Adjust nuts A** to adjust the “**Dimension L1**” to 460 ~ 480 mm (18.1 ~ 18.9 inches).
 - In case the “**Dimension L1**” is longer than 480 mm (18.1 inches).
Screw out the **Adjust nuts A** and screw in the **Adjust nuts B** to adjust the “**Dimension L1**” to 460 ~ 480 mm (18.1 ~ 18.9 inches).
7. Repeat the steps 3 and 4, and then tighten the **Lock nuts A and B**.
8. Telescope the boom several times, retract the boom fully, and then make sure that “**Dimension L1**” is 460 ~ 480 mm (18.1 ~ 18.9 inches).
- When replacing the **Plate springs** with the new ones, make sure to use the suitable collar by following the next instructions.
- 1) Stack the new 8 **Plate springs** on level surface, and then measure the **Overall height (H1)** of the plate springs.



- 2) See the table below to select the suitable collar corresponding to the Overall height (H1) of the plate springs.

| | | | | | | | |
|---------------------------------------|------|-------------|-------------|-------------|-------------|-------------|-------------|
| Height (H1) of 8 plate springs | mm | 22.0 ~ 22.6 | 22.6 ~ 23.2 | 23.2 ~ 23.8 | 23.8 ~ 24.4 | 24.4 ~ 25.0 | 25.0 ~ 25.6 |
| | inch | 0.86 ~ 0.89 | 0.89 ~ 0.91 | 0.91 ~ 0.94 | 0.94 ~ 0.96 | 0.96 ~ 0.98 | 0.98 ~ 1.01 |
| Height (H2) of suitable collar | mm | 16.1 | 17.0 | 17.7 | 18.3 | 19.1 | 19.8 |
| | inch | 0.63 | 0.67 | 0.70 | 0.72 | 0.75 | 0.78 |
| Part number of the suitable collar | | S44340- 07 | S44340- 08 | S44340- 09 | S44340- 10 | S44340- 11 | S44340- 12 |




6. Tension on Electrical cables


Impose the proper tension onto the electrical cables as follows every 6 months or 600 hours.

It is necessary to impose the tension after adjusting the boom extension/retraction wire ropes.


1. Telescope the boom several times, set the boom horizontally, and then retract it fully.
2. Loosen the cable clamps at the top end of the 3rd boom section.
3. Pull the electrical cables by the force of 20 ~ 25 kg (44 ~ 55 lbs), and then tighten the cable clamps.






7. Sectional drawing (1/2)




Sectional drawing (2/2)




Fly- jib



A - view






B - view



C - view

| | |
|---|--|
| 1 | Electric cable - 1 |
| 2 | Hydraulic hose (P) |
| 3 | Hydraulic hose (T) |
| 4 | Electric cable - 2 |
| 5 | Hydraulic hose - 1 for Fly- jib cylinder |
| 6 | Hydraulic hose - 2 for Fly- jib cylinder |
| 7 | Hydraulic hose - 3 for Fly- jib cylinder |

Platform for SP18A/ISP60 and SP21A/ISP70





Adjustment procedures of Overload sensing limit switch




1. Adjust the dimension between the 2 Spring retainers to 76 mm (3.0 in) by tightening the Nut A, and then lock the lock nut.
2. Load the platform with the weight of 240 kg (530 lbs) at the Test weight position A, and then shake the platform several times.
3. Move the weight to the Test weight position B, and then shake the platform several times.
4. Perform the above steps 2 ~ 3 several times to settle the spring and the linkages.
5. Load the platform with the weight of 240 kg (530 lbs) at the Test weight position A, and then turn the Adjust bolt so that the limit switch is switched on.
6. Move the weight to the Test weight position B, and then make sure that the limit switch switches on.

If the limit switch does not switch on, perform the followings.

- 1) Turn the Adjust bolt again until the limit switch switches on.
- 2) Move the test weight to the Test weight position A again, and then make sure that the limit switch switches on.
- 3) If the limit switch does not switch on, repeat the steps 2 to 6.
7. Measure the clearance "X" between the Roller of the overload sensing limit switch and the Adjust bolt.
8. Adjust the clearance between the limit switch bracket and the stopper bolts to $X + 3 \text{ mm}$ ($X + 0.12 \text{ in}$) to prevent the limit switch from breakage that is caused by overloading.




Platform for SP21AJ/ISP70J



A - detail

Adjustment procedures of Overload sensing limit switch

1. Adjust the dimension between the 2 Spring retainers to 76 mm (3.0 in) by tightening the Nut A, and then lock the lock nut.
2. Load the platform with the weight of 240 kg (530 lbs) at the Test weight position A, and then shake the platform several times.
3. Move the weight to the Test weight position B, and then shake the platform several times.
4. Perform the above steps 2 ~ 3 several times to settle the spring and the linkages.
5. Load the platform with the weight of 240 kg (530 lbs) at the Test weight position A, and then turn the Adjust bolt so that the limit switch is switched on.
6. Move the weight to the Test weight position B, and then make sure that the limit switch switches on.
If the limit switch does not switch on, perform the followings.
 - 1) Turn the Adjust bolt again until the limit switch switches on.
 - 2) Move the test weight to the Test weight position A again, and then make sure that the limit switch switches on.
 - 3) If the limit switch does not switch on, repeat the steps 2 to 6.
7. Measure the clearance "X" between the Roller of the overload sensing limit switch and the Adjust bolt.
8. Adjust the clearance between the limit switch bracket and the stopper bolts to $X + 3 \text{ mm}$ ($X + 0.12 \text{ in}$) to prevent the limit switch from breakage that is caused by overloading.




B - detail

3. Hydraulic section

Oil reservoir

| | |
|---------------------------|--------------------------------------|
| Oil capacity | 150 liters (39.6 gallons) |
| Recommended hydraulic oil | Shell Tellus T22 |
| Oil change interval | Every 1200 working hours or annually |



| No. | Description | No. | Description |
|-----|----------------|-------|--------------------------|
| 1 | Filler cap | 7 | Tube band |
| 2 | Body | 8 | Stay |
| 3 | Suction filter | 9 | Drain plug (with O-ring) |
| 4 | Baffle plate | 10 | Suction pipe |
| 5 | Vinyl tube | 11 | Return pipe |
| 6 | Level float | ----- | ----- |

NOTE:

1. For new machines, the first oil change should be carried out after 300 working hours or 3 months of use.
2. Clean the Suction filter, and replace the In-line filter at the same time when changing the hydraulic oil.
3. When changing or checking the oil level, be sure to retract and lower the boom fully.

High- pressure line filter for Boom functions


This high- pressure line filter is installed in the output line of the main hydraulic pump for boom functions to eliminate contaminations contained in the oil.

It is advisable to replace the filter element every 1200 working hours or annually.

NOTE:

- For a new machine, the first replacement of the element should be carried out in 300 working hours or 3 months of use.
- Do not reuse the O-ring and the back- up ring when once removed.

| | |
|---------------------|------------------------------------|
| Rated pressure | 175 kg/cm ² (2,500 PSI) |
| Proof pressure | 315 kg/cm ² (4,480 PSI) |
| Rated flow | 100 liters/min (26.4 GPM) |
| Filtration accuracy | 10 micron |



| | |
|---|----------------|
| 1 | Filter element |
| 2 | Filter head |
| 3 | Case |
| 4 | O- ring |
| 5 | Back -up ring |
| 6 | By-pass valve |

High- pressure line filter for Charge pump


This high- pressure line filter is installed in the output line of the Charge pump to eliminate contaminations contained in the oil.

It is advisable to replace the filter element every 1200 working hours or annually.

NOTE:

- For a new machine, the first replacement of the element should be carried out in 300 working hours or 3 months of use.
- Do not reuse the O-ring and the back- up ring when once removed.

| | |
|----------------------------------|------------------------------------|
| Rated pressure | 140 kg/cm ² (1,990 PSI) |
| Rated flow | 30 liters/min (7.9 GPM) |
| Filtration accuracy | 30 micron |
| By- pass valve cracking pressure | 5 kg/cm ² (71 PSI) |




305- 00000- 04
 305- 00000- 51
 305- 00000- 64
 305- 00000- 69


Adaptor filter

This Adaptor filters are installed at the A1, B1, A2, B2, A3, B3 and P port of the main control valve to eliminate contaminations contained in the oil.


| | | | |
|-------------|--------------|----------------|--|
| Part number | 305-00000-04 | | |
| Port | P | Rated pressure | 17.2 MPa (175 kg/cm ²) [2,500 PSI] |
| Mesh size | 100 mesh | Rated flow | 100 liters/min. (26.4 GPM) |




| | | | |
|-------------|-------------------|----------------|--|
| Part number | 305-00000-51 | | |
| Port | A1, B1, A2 and B2 | Rated pressure | 20.6 MPa (210 kg/cm ²) [3,000 PSI] |
| Mesh size | 100 mesh | Rated flow | 60 liters/min. (15.9 GPM) |



| | | | |
|-------------|--------------|----------------|--|
| Part number | 305-00000-64 | | |
| Port | A3 | Rated pressure | 20.6 MPa (210 kg/cm ²) [3,000 PSI] |
| Mesh size | 100 mesh | Rated flow | 40 liters/min. (10.6 GPM) |




| | | | |
|-------------|--------------|----------------|--|
| Part number | 305-00000-69 | | |
| Port | B3 | Rated pressure | 20.6 MPa (210 kg/cm ²) [3,000 PSI] |
| Mesh size | 100 mesh | Rated flow | 40 liters/min. (10.6 GPM) |






Hydraulic pump

| | Displacement | Rated pressure |
|--------------------------------|--|--------------------------------------|
| Plunger pump (for Travel | 0 ~ 56 cc / rev (0 ~ 3.42 in ³ / rev) | 405 kg / cm ² (5,760 PSI) |
| Gear pump (for Boom functions) | 40.0 cc / rev (2.44 in ³ / rev) | 210 kg / cm ² (2,990 PSI) |
| Charge pump | 12.1 cc / rev (0.74 in ³ / rev) | 250 kg / cm ² (3,560 PSI) |



Relief valve reset pressure


| | |
|----|--------------------------------------|
| P1 | 340 kg / cm ² (4,840 PSI) |
| P2 | 340 kg / cm ² (4,840 PSI) |
| P3 | 20 kg / cm ² (290 PSI) |



DA valve

Do not touch



(The screw is adjusted by manufacturer precisely.)



1. Replacement procedures

Perform the following items when replacing the hydraulic pump.

1. Fill the new hydraulic pump with hydraulic oil from the T1- port before installing it.
2. If hydraulic oil spilled while installing the pump, add the hydraulic oil again from the R- port after being installed.
3. Start the engine, then keep it running at idling speed with no load for 2 ~ 3 minutes until the charge pump pressure reading on the pressure gauge 3 becomes stable and any noise can not be heard.




Pressure gauge-3

Emergency pump

This emergency pump consists of a DC motor and a gear pump, and is driven by the chassis batteries to supply hydraulic pressure in the event of failure on the main pump or the engine.

| | |
|----------------|---|
| DC motor | 1.0 kw / 24 v DC |
| Displacement | 1.7 cc / rev. (0.10 in ³ / rev.) |
| Rated pressure | 175 kgf / cm ² (2,490 PSI) |




NOTE:

- Do not operate the emergency pump for more than 30 seconds continuously.
- Allow the interval of 30 seconds or more to resume operating the pump.
- The continuous operation of the pump will cause the DC motor to burn out.

Main control valve

The main control valve proportionally controls the Boom elevation, telescope and rotation functions



| | | | | |
|------------------------------|--|----------|-----------------|---------------------|
| Rated pressure | 210 kg/cm ² (2,990 PSI) | Solenoid | Rated voltage | DC24 volts |
| Rated flow | 100 liters/min (26.4 GPM) | | Rated current | 800 mA |
| Relief valve preset pressure | P4 210 kg/cm ² (2,990 PSI) P6 90 kg/cm ² (1,280 PSI) P7 150 kg/cm ² (2,130 PSI) | | Coil resistance | 15.6 ohms (at 20°C) |




Manual over-ride screw

Operate the boom function manually as follows in case of emergency.


1. Loosen the lock nut.
2. Screw in the manual over-ride screw until the boom begins to move slowly.
3. Screw out the manual over-ride screw to stop the movement of the boom.
4. Set the screw length to 18 mm (0.71 in) after using the manual over-ride screw.
5. Tighten the lock nut.




1. Sectional drawings




A- A section




X- X section




B- B section




Y- Y section




C- C section



Z- Z section



Main relief valve Detail







Port relief valve Detail

Platform rotation solenoid valve (302- 00153- 00D)

For the machine without Fly- jib

This valve is mounted on the Rotary actuator for Platform rotation to control the platform rotation functions.




Solenoid valve

4.2 ~ 4.4 kg- m (30 ~ 32 ft- lbs)

0.5 ~ 0.6 kg- m (3.6 ~ 4.4 ft- lbs)

0.41 ~ 0.51 kg- m (3.0 ~ 3.7 ft- lbs)



Solenoid coil

Solenoid valve installation procedures


Follow the instructions below to install the Solenoid valve onto the manifold.

1. Insert the "Solenoid valve cartridge" (7) into the manifold, and then tighten the cartridge by the tightening torque of 4.2 ~ 4.4 kg- m (30 ~ 32 ft- lbs).
2. Install the 2 pieces of the "Solenoids coils" (1) onto the valve cartridge, and then tighten the "Nut" (17) by the tightening torque of 0.41 ~ 0.51 kg-m (3.0 ~ 3.7 ft- lbs).
3. Turn the "Adjust screw" (31) counter-clockwise to screw it out fully.
4. Install the "Cap nut" (32), and tighten it by the tightening torque of 0.5 ~ 0.6 kg- m (3.6 ~ 4.4 ft- lbs).

Caution: Do not allow the "Adjust screw" (31) to be turned when tightening the "Cap nut" (32).

Platform rotation / Fly jib solenoid valve (302- 00152- 00D) For the machine with Fly- jib



This valve is mounted on the Rotary actuator for Platform rotation to control the Platform rotation and Fly- jib articulation functions.



Travel speed select solenoid valve

This solenoid valve is installed in the hydraulic circuit between the Charge pump and the four Travel motors. When this solenoid valve is switched on, the valve supplies the pilot pressure to the Speed select valves incorporated in the travel motors to turn the motors into the “High- speed modes”.



| | |
|----------------|------------------------------------|
| Rated voltage | DC24V (DC18 ~ 30V) Less than 13W |
| Rated pressure | 210 kg/cm ² (2,990 PSI) |
| Rated flow | 3 liters/min. (0.79 GPM) |



Parking brake release solenoid valve

This solenoid valve is installed in the hydraulic circuit between the Charge pump and the four Travel motors. When this solenoid valve is switched on, the valve supplies the hydraulic pressure to the parking brakes incorporated in the travel motors to release the parking brake.



| | |
|----------------|------------------------------------|
| Rated voltage | DC24V (DC18 ~ 30V) Less than 13W |
| Rated pressure | 210 kg/cm ² (2,990 PSI) |
| Rated flow | 3 liters/min. (0.79 GPM) |



Oscillation axle release solenoid valve

This solenoid valve is installed in the hydraulic circuit between the Charge pump and the two oscillation axle lock cylinders. When this solenoid valve is switched on, the valve supplies the hydraulic pressure to release both of the oscillation axle lock cylinders.


| | |
|----------------|------------------------------------|
| Rated voltage | DC24V (DC18 ~ 30V) Less than 13W |
| Rated pressure | 210 kg/cm ² (2,990 PSI) |
| Rated flow | 3 liters/min. (0.79 GPM) |



Unit valve

302- 00149- 00

This unit valve is installed on the turntable to control the Platform rotation and Platform level adjustment functions.






| | | | |
|---|--------------------------------------|----|---------------------|
| 1 | Unloading solenoid valve | 10 | Plug (3/8) |
| 2 | Bolt | 11 | Plug (M8) |
| 3 | Platform level adjust solenoid valve | 12 | Manifold |
| 4 | Double pilot check valve | 13 | O- ring |
| 5 | Bolt | 14 | Plug (3/8) |
| 6 | Steering solenoid valve | 15 | Serial number plate |
| 7 | Bolt | 16 | Rivet |
| 8 | Relief valve (P10) | 17 | Plug (3/8) |
| 9 | O- ring | | |

Flow priority valve

This valve maintains the flow that comes of the PF port at the constant level regardless of the flow fluctuation that is supplied to the IN port. The rest of the flow comes out of the EF port.

| | |
|--------------------------|------------------------------------|
| Rated pressure | 260 kg/cm ² (3,700 PSI) |
| Rated flow | 100 liters/min (26.4 GPM) |
| Constant flow of PF port | 17 ± 2 liters/min (4.5 ± 0.5 GPM) |




Flow divider valve

1 piece of Flow divider valve #302- 00104- 00 and 2 pieces of Flow divider valves #302- 00105- 00 are installed in the hydraulic circuit of the Traveling system to supply equal flow to the 4 pieces of Travel motors.

1. Flow divider valve #302- 00104- 00


| | |
|--------------------------------------|------------------------------------|
| Rated pressure | 340 kg/cm ² (4,980 PSI) |
| Rated flow | 130 liters/min (34.3 GPM) |
| Flow dividing ratio to A and B ports | 1 : 1 |



| | | | |
|---|---------------|----|--------------------------------|
| 1 | Body | 9 | Plug (PT 1/8) |
| 2 | Main spool | 10 | Cap screw (M12 x 40) |
| 3 | Sub spool | 11 | Throttle adjust screw |
| 4 | Spool plug | 12 | Bushing |
| 5 | Cover | 13 | O- ring (P7) |
| 6 | Spring | 14 | Back- up ring (for O- ring P7) |
| 7 | O- ring (P29) | 15 | O- ring (P16) |
| 8 | O- ring (G45) | 16 | Lock nut (M8) |

2. Flow divider valve #302- 00105- 00

| | |
|--------------------------------------|------------------------------------|
| Rated pressure | 340 kg/cm ² (4,980 PSI) |
| Rated flow | 65 liters/min (17.2 GPM) |
| Flow dividing ratio to A and B ports | 1 : 1 |









| | | | |
|---|---------------|----|--------------------------------|
| 1 | Body | 9 | Plug (PT 1/8) |
| 2 | Main spool | 10 | Throttle adjust screw |
| 3 | Sub spool | 11 | Bushing |
| 4 | Spool plug | 12 | O- ring (P7) |
| 5 | Cover | 13 | Back- up ring (for O- ring P7) |
| 6 | Spring | 14 | O- ring (P16) |
| 7 | O- ring (P21) | 15 | Lock nut (M8) |
| 8 | O- ring (P36) | | |



Swivel joint

The swivel joint is installed at the rotation center of the turntable to provide the hydraulic oil passages between the turntable and chassis.


| | | |
|----------------|---------------------------|------------------------------------|
| Rated pressure | A, B, C, D, F and G ports | 350 kg/cm ² (4,980 PSI) |
| | E port | 210 kg/cm ² (2,990 PSI) |
| | Dr port | 2 kg/cm ² (28 PSI) |
| Rated flow | A, B, C, D, F and G ports | 150 liters/min (39.6 GPM) |
| | E port | 15 liters/min (3.96 GPM) |
| | Dr port | 18 liters/min (4.76 GPM) |



Boom elevation cylinder



| No. | Description | No. | Description |
|-----|---------------|-----|----------------------|
| 1 | Cylinder tube | 13 | Spacer |
| 2 | Piston rod | 14 | Piston |
| 3 | Cylinder head | 15 | U- ring |
| 4 | Bushing | 16 | Backup ring |
| 5 | Snap ring | 17 | Wear ring |
| 6 | U- ring | 18 | Nut |
| 7 | Backup ring | 19 | Set screw |
| 8 | Dust seal | 20 | Steel ball |
| 9 | O- ring | 21 | O- ring |
| 10 | Backup ring | 22 | Spherical bearing |
| 11 | O- ring | 23 | Bushing |
| 12 | Lock washer | 24 | Single holding valve |





Hydraulic circuit diagram

Single holding valve (for Boom elevation cylinder)


The Single holding valve is mounted on the Boom elevation cylinder to prevent the cylinder from natural retraction.

- Rated pressure ----- 210 kg/cm² (2,990 PSI)
- Rated flow ----- 50 liters/min. (13.2 GPM)



E – E section

| | | | | | |
|---|-----------------------------|----|---------------|----|----------|
| 1 | Valve housing | 6 | Cap | 11 | Spring |
| 2 | Pilot check valve cartridge | 7 | O- ring | 12 | Spring |
| 3 | Holding valve cartridge | 8 | Pilot piston | 13 | Guide |
| 4 | Plug | 9 | O- ring | 14 | Push rod |
| 5 | Plug | 10 | Back- up ring | | |




1. Inspections

Measure the natural retraction of the boom elevation cylinder as follows to check the internal oil leakage of the single holding valve.

1. Set up the machine on firm and level surface.
2. Raise the boom and set the boom at the boom angle of 45 degrees, and then shut down the engine.
3. Apply the mark on the piston rod of the boom elevation cylinder, and then measure the **Dimension A** as shown in the figure below.

Caution: Do not damage the piston rod when marking.



4. Leave the machine for 10 minutes, then measure the **Dimension A'**.

$$A - A' = \text{Natural retraction}$$

Serviceable limit of natural retraction ----- 2 mm (0.08 in)/10 minutes.

5. If the natural retraction exceeds the serviceable limit, check the single holding valve and the boom elevation cylinder for internal oil leakage.

Follow the next procedures to specify which has internal oil leakage (the single holding valve or the boom elevation cylinder).



- 1) Support the boom using a crane to prevent the boom from unexpected descent.
- 2) Disconnect the hydraulic hose that is connected to the "A port" of the single holding valve.

Caution: Loosen the hydraulic hose fitting slowly when disconnecting the hydraulic hose.

- 3) Lower the hoisting hook of the crane to load the boom elevation cylinder with the gravity of the boom, and then check if hydraulic oil leaks from the single holding valve.

If the hydraulic oil leaks from the single holding valve, it indicates that the internal oil leakage is in the single holding valve. No oil leakage indicates that the internal oil leakage is in the boom elevation cylinder.



Boom telescope cylinder




| | | | |
|----|---------------|----|-------------------------|
| 1 | Cylinder tube | 12 | Piston |
| 2 | Piston rod | 13 | U- ring |
| 3 | Cylinder head | 14 | Back- up ring |
| 4 | Bushing | 15 | Wear ring |
| 5 | U- ring | 16 | O- ring |
| 6 | Back- up ring | 17 | Back- up ring |
| 7 | Dust seal | 18 | Set screw |
| 8 | O- ring | 19 | Holding valve cartridge |
| 9 | O- ring | 20 | Plug |
| 10 | Lock washer | 21 | O- ring |
| 11 | Spacer | 22 | Serial number plate |

Double holding valve (for Boom telescope cylinder)

The Double holding valve is equipped on the Boom telescope cylinder to prevent the cylinder from natural retraction and extension.




Valve cartridge detail



1. Inspections

Measure the natural retraction and extension of the boom telescope cylinder to check the internal oil leakage of the Double holding valve.

1. Set up the machine on firm and level surface.
2. Raise the boom fully and extend the boom about 1 meter (3 feet), and then shut down the engine.
3. Apply the mark on the 2nd boom section, and then measure the **Dimension A** as shown in the figure below.




4. Leave the machine for 10 minutes, and then measure the **Dimension A'**.

$$A - A' = \text{Natural retraction}$$

Serviceable limit of natural retraction ----- 2 mm (0.08 in)/10 minutes.

5. Lower the boom fully, extend it about 0.5 meter (1.5 feet), shut down the engine, and then measure the **Dimension B** as shown in the figure below.



6. Leave the machine for 10 minutes, and then measure the **Dimension B'**.

$$B' - B = \text{Natural extension}$$

Serviceable limit of natural extension ----- 2 mm (0.08 in)/10 minutes.

7. If the natural retraction and/or extension exceed the serviceable limit, check the Double holding valve and the boom telescope cylinder for internal oil leakage.

Follow the next procedures to specify which has internal oil leakage (the Double holding valve or the Boom telescope cylinder).

- 1) Set the boom as follows.

* When natural retraction exceeds the serviceable limit:

Boom angle --- Max. (Fully raised) Boom extended length --- About 1 meter (3 feet)

* When natural extension exceeds the serviceable limit:

Boom angle --- Min. (Fully lowered) Boom extended length --- About 0.5 meter (1.5 feet)

- 2) Disconnect both of the hydraulic hoses that are connected to the boom telescope cylinder, and then check if the hydraulic oil leaks from the boom telescope cylinder.


Caution: Loosen the hydraulic hose fittings slowly when disconnecting the hydraulic hoses.

If the hydraulic oil leaks from the boom telescope cylinder, it indicates that the internal oil leakage is in the double holding valve. No oil leakage indicates that the internal oil leakage is in the boom telescope cylinder.

Single pilot check vale (for Boom telescope cylinder)


This valve, together with the double holding valve, is to prevent a “Natural retraction” of the Boom telescope cylinder caused by the gravity of the boom and the platform.

| | |
|-------------------------------|---------------------------------------|
| Rated pressure | 175 kg / cm ² (2500 PSI) |
| Rated flow | 60 liters / min. (15.9 gallons / min) |
| Check valve cracking pressure | 0.1 kg / cm ² (1.42 PSI) |



| No. | Description | No. | Description |
|-----|-------------|-----|-------------|
| 1 | Snap ring | 6 | Name plate |
| 2 | Spring seat | 7 | Body |
| 3 | Spring | 8 | Pilot valve |
| 4 | Check valve | 9 | O-ring |
| 5 | Valve seat | 10 | Cap |



Fly- jib cylinder



| | | | | | |
|---|---------------|----|-------------------|----|-----------------------|
| 1 | Cylinder tube | 10 | Lock washer | 19 | Bushing |
| 2 | Piston rod | 11 | Piston | 20 | Double holding valve |
| 3 | Cylinder head | 12 | Wear ring | 21 | Bolt |
| 4 | Bushing | 13 | U- ring | 22 | Overload relief valve |
| 5 | U- ring | 14 | Back- up ring | 23 | Filter |
| 6 | Dust seal | 15 | Set screw | 24 | O- ring |
| 7 | O- ring | 16 | Steel ball | 25 | Bolt |
| 8 | Back- up ring | 17 | O- ring | 26 | Spring washer |
| 9 | O- ring | 18 | Spherical bearing | 27 | Grease fitting |

Double holding valve (for Fly- jib cylinder)

This Double holding valve is equipped on the Fly- jib cylinder to prevent the cylinder from natural retraction and extension.





| | | | | | |
|---|---------------|----|-------------|----|---------|
| 1 | Body | 6 | Cap | 11 | O- ring |
| 2 | Valve seat | 7 | Orifice | 12 | O- ring |
| 3 | Valve spool | 8 | Check valve | 13 | O- ring |
| 4 | Valve housing | 9 | O- ring | 14 | Plug |
| 5 | Spring | 10 | O- ring | | |


Overload relief valve (for Fly- jib cylinder)

Two Overload relief valves (P11 and P12) are equipped on the Fly- jib cylinder to release abnormally high pressure produced in the Fly- jib cylinder.


Pre- set pressure: 150 kg/cm² (2,130 PSI)



A – A section



Oscillation axle lock cylinder



| No. | Description | No. | Description |
|-----|-----------------------|-----|---------------|
| 1 | Cylinder tube | 14 | Bushing |
| 2 | Piston rod | 15 | Cap bolt |
| 3 | Cylinder head | 16 | Bolt |
| 4 | Piston | 17 | Spring washer |
| 5 | Dust seal | 18 | Lock valve |
| 6 | Packing | 19 | O-ring |
| 7 | Bushing | 20 | O-ring |
| 8 | O-ring | 21 | Grease nipple |
| 9 | Packing | 22 | Grease nipple |
| 10 | Wear ring Lock washer | 23 | Set screw |
| 11 | O-ring Spacer | 24 | Steel ball |
| 12 | Backup ring | 25 | Backup ring |
| 13 | Bushing | 26 | Set screw |

Air bleeding procedures

Bleed air from the “*Oscillation axle lock cylinders*” as follows when the air is suspected in the “*Oscillation axle lock system*”.

- (1) Set up the machine on firm and level surface, and then unload the platform.
- (2) Set the boom under the horizontal and retract it fully.
- (3) Loosen the “*Air bleed plugs A*” shown in the figure left on the “*Oscillation lock cylinder (L/H)*”.
- (4) Drive the machine, have the “*Left / Front wheel*” on a curb as shown in Fig. 1 to retract the “*Oscillation lock cylinder (L/H)*” fully and to bleed air from the *bottom room* of the cylinder.
- (5) Tighten the “*Air bleed plugs A*” loosened in step (3).
- (6) Loosen the “*Air bleed plug B*” shown in the figure left on the “*Oscillation lock cylinder (L/H)*”.
- (7) Drive the machine, have the “*Right / Front wheel*” on a curb as shown in Fig. 2 to extend the “*Oscillation lock cylinder (L/H)*” fully and to bleed air from the *rod room* of the cylinder.
- (8) Tighten the “*Air bleed plug B*” loosened in step (6).
- (9) Loosen the “*Air bleed plug B*” shown in the figure left on the “*Oscillation lock cylinder (R/H)*”.
- (10) Drive the machine, have the “*Left / Front wheel*” on a curb as shown in Fig. 1 to extend the “*Oscillation lock cylinder (R/H)*” fully and to bleed air from the *rod room* of the cylinder.
- (11) Tighten the “*Air bleed plug B*” loosened in step (9).
- (12) Loosen the “*Air bleed plugs A*” shown in the figure left on the “*Oscillation lock cylinder (R/H)*”.
- (13) Drive the machine, have the “*Right / Front wheel*” on a curb as shown in Fig. 2 to retract the “*Oscillation lock cylinder (R/H)*” fully and to bleed air from the *bottom room* of the cylinder.
- (14) Tighten the “*Air bleed plugs A*” loosened in step (12).
- (15) Repeat the above steps until no air comes out from all of the air bleed plugs.

Fig. 1






Fig. 2




Lock valve (for Oscillation axle lock cylinder)

This Lock valve is equipped on the Oscillation axle lock cylinder to lock the cylinder. This valve also releases abnormally high pressure produced in the Oscillation axle lock cylinder to protect the cylinder.



Steering cylinder





| | | | | | |
|---|---------------|----|---------------|----|----------------|
| 1 | Cylinder tube | 6 | Bushing | 11 | Dust seal |
| 2 | Piston rod | 7 | O- ring | 12 | O- ring |
| 3 | Cylinder head | 8 | U- ring | 13 | O- ring |
| 4 | Piston | 9 | U- ring | 14 | Wear ring |
| 5 | Bushing | 10 | Back- up ring | 15 | Self- lock nut |


Double pilot check valve (for Steering cylinder)

This double pilot check valve is installed in the Steering hydraulic circuit to prevent the steering cylinders from being extended or retracted naturally, while the steering function is not operated.

- Rated pressure ----- 210 kg/cm² (2,990 PSI)
- Rated flow ----- 30 liters/min (7.9 gallons/min)



This system automatically maintains the platform at its level position regardless of the boom UP/Down movements, and consist of the Upper and Lower leveling cylinders, Double holding or pilot check valve mounted on Upper leveling cylinder and the combination valve for adjusting platform level as shown in the figures.



1. Note on function

When the boom is lowered, the Lower leveling cylinder retracts and the hydraulic oil in the bottom room of the cylinder flows into the bottom room of the Upper leveling cylinder.

Since the sizes of both leveling cylinders are exactly the same, the Upper leveling cylinder extends simultaneously in according with the retraction of the Lower leveling cylinder.

Thus, the platform is balanced by the two leveling cylinders to maintain its level, as the boom is lowered.

When the boom is raised, the leveling cylinders work vice versa.

2. Inspection procedures

(1) Tilt of platform

Perform Boom elevation and telescope operations several times, and check that the platform always stays level.

If the platform does not stay level, check the leveling system as follows.

- 1) Thoroughly check the system for external oil leakage.
- 2) Follow the instructions described in the **3. Air bleeding procedures** to bleed air from the Platform leveling system.
- 3) Check the internal oil leakage of the Combination valve.
- 4) Check the internal oil leakage of the Double holding valve or Double pilot check valve mounted on the Upper leveling cylinder.
- 5) Check the internal oil leakage of the Upper and Lower leveling cylinders.

(2) Natural descent

Load the platform with its maximum specified load (250 kg, 550 lbs), and then visually check for any sign of the platform tilting downward.

If the platform tilts naturally, thoroughly check the leveling system for external oil leakage, and then check the components listed below for internal oil leakage.


- Double holding valve or Double pilot check valve mounted on Upper leveling cylinder
- Combination valve
- Upper and lower leveling cylinders

3. Air bleeding procedures

CAUTION

- When bleeding air, always operate the machine from the lower control.
- Do not allow any load on the platform when carrying out these procedures.





- 1) Pull the platform level adjust lever equipped on the Combination valve while pressing the lock lever.
- 2) Operate the Boom telescope switch to its **IN** position to tilt the platform fully upward.
- 3) Operate the Boom telescope switch to its **OUT** position to tilt the platform fully downward.
- 4) Perform the above steps 2 and 3 several times.
- 5) Adjust the platform to its level position, and then set the platform level adjust lever to its original position.




Combination valve (for Platform leveling system)

The Combination valve is used in the Platform leveling system and incorporates the Directional control valve, the Double pilot check valve and two Overload relief valves.

| | | |
|--|------------------------|----------------|
| Rated pressure | 300 kg/cm ² | 4,270 PSI |
| Rated flow | 50 liters/min | 13 gallons/min |
| Preset pressure for Overload relief valves (P8 and P9) | 230 kg/cm ² | 3,272 PSI |
| Rated flow | 50 liters/min | 13.2 GPM |




A-A Section



B-B Section


| No. | Description | No. | Description | No. | Description |
|-----|-------------|-----|------------------|-----|-----------------------|
| 1 | Body | 11 | Plate | 21 | O-ring |
| 2 | Spool | 12 | Bolt | 22 | Plug |
| 3 | Oil seal | 13 | Bolt | 23 | Piston |
| 4 | Bracket | 14 | Spool lock lever | 24 | O- ring |
| 5 | Washer | 15 | Bolt | 25 | Gasket |
| 6 | Bolt | 16 | Spring | 26 | Expand plug |
| 7 | Bushing | 17 | Plug | 27 | Overload relief valve |
| 8 | Steel ball | 18 | Valve seat | 28 | |
| 9 | Spring | 19 | Valve | 29 | |
| 10 | Cap | 20 | Spring | 30 | |

Lower leveling cylinder (for the machine without Fly- jib)




| No. | Description | No. | Description |
|-----|---------------|-------|----------------|
| 1 | Cylinder tube | 12 | U- ring |
| 2 | Piston rod | 13 | Wear ring |
| 3 | Cylinder head | 14 | Set screw |
| 4 | Bushing | 15 | Steel ball |
| 5 | U-ring | 16 | O- ring |
| 6 | Dust seal | 17 | Bushing |
| 7 | O- ring | 18 | Collar |
| 8 | Backup ring | 19 | Bushing |
| 9 | O- ring | 20 | Grease fitting |
| 10 | Lock washer | 21 | Name plate |
| 11 | Piston | ----- | ----- |

Lower leveling cylinder (for the machine with Fly- jib)



| No. | Description | No. | Description |
|-----|---------------|-----|----------------|
| 1 | Cylinder tube | 12 | Back- up ring |
| 2 | Piston rod | 14 | Wear ring |
| 3 | Cylinder head | 15 | Set screw |
| 4 | Bushing | 16 | Steel ball |
| 5 | U-ring | 17 | O- ring |
| 6 | Dust seal | 18 | Bushing |
| 7 | O- ring | 19 | Collar |
| 8 | Back- up ring | 20 | Bushing |
| 9 | O- ring | 21 | Grease fitting |
| 10 | Lock washer | 22 | Name plate |
| 11 | Piston | 23 | Grease fitting |
| 12 | U- ring | -- | ----- |

Upper leveling cylinder (for the machine without Fly- jib)





| No. | Description | No. | Description |
|-----|---------------|-----|----------------------|
| 1 | Cylinder tube | 14 | Set screw |
| 2 | Piston rod | 15 | Steel ball |
| 3 | Cylinder head | 16 | O- ring |
| 4 | Bushing | 17 | Bushing |
| 5 | U- ring | 18 | Collar |
| 6 | Dust seal | 19 | Bushing |
| 7 | O- ring | 20 | Grease fitting |
| 8 | Back- up ring | 21 | Double holding valve |
| 9 | O- ring | 22 | Bolt |
| 10 | Lock washer | 23 | Bolt |
| 11 | Piston | 24 | Spring washer |
| 12 | U- ring | 25 | O- ring |
| 13 | Wear ring | 26 | Name plate |

Double holding valve (for Upper leveling cylinder without Fly- jib)


This Double holding valve is mounted on the Upper leveling cylinder to maintain the platform level in the event of hydraulic hose breakage.

- Rated pressure ----- 230 kg/cm² (3,270 PSI)
- Rated flow ----- 10 liters/min (2.64 gallons/min)




| | | | |
|---|-------------|----|-------------|
| 1 | Body | 8 | Check valve |
| 2 | Valve seat | 9 | O- ring |
| 3 | Valve spool | 10 | O- ring |
| 4 | Cap | 11 | O- ring |
| 5 | Spring | 12 | O- ring |
| 6 | Cap | 13 | O- ring |
| 7 | Orifice | 14 | Plug |

Upper leveling cylinder (for the machine with Fly- jib)




| No. | Description | No. | Description |
|-----|---------------|-----|--------------------------|
| 1 | Cylinder tube | 14 | Wear ring |
| 2 | Piston rod | 15 | Set screw |
| 3 | Cylinder head | 16 | Steel ball |
| 4 | Bushing | 17 | O- ring |
| 5 | U- ring | 18 | Bushing |
| 6 | Dust seal | 19 | Collar |
| 7 | O- ring | 20 | Bushing |
| 8 | Back- up ring | 21 | Grease fitting |
| 9 | O- ring | 22 | Double pilot check valve |
| 10 | Lock washer | 23 | Bolt |
| 11 | Piston | 24 | Spring washer |
| 12 | U- ring | 25 | O- ring |
| 13 | Back- up ring | 27 | Name plate |



Double pilot check valve (for Upper leveling cylinder with Fly- jib)

This double pilot check valve is mounted on the Upper leveling cylinder to maintain the platform level in the event of hydraulic hose breakage.



Boom rotation motor


The boom rotation motor is installed on the rotation gearbox to rotate the turntable.

Type ----- Plunger type

Rated pressure ----- 210 kg/cm^2 (3,000 PSI)


Drain pressure ----- 1.5 kg/cm^2 (21 PSI)

Displacement ----- 39.3 cc/rev ($2.4 \text{ in}^3/\text{rev}$)



Platform rotary actuator

The Platform rotary actuator is installed between the platform and the top of 3rd boom or Fly- jib to rotate the platform.




| | |
|----|----------------|
| 1 | Body |
| 2 | Shaft |
| 3 | Ball bearing |
| 4 | O- ring |
| 5 | Back- up ring |
| 6 | O- ring |
| 7 | Air bleed plug |
| 8 | Steel ball |
| 9 | Piston |
| 10 | Packing |
| 11 | Back- up ring |
| 12 | Packing |
| 13 | Back- up ring |
| 14 | Wear ring |
| 15 | Head |
| 16 | O- ring |
| 17 | O- ring |
| 18 | Set screw |

Tightening torque : 5.1 kg-m (37 ft-lbs)


1. Function of Rotary actuator

1 Clockwise



1. Pressurized oil comes in to the lower room of the rotary actuator and push up the piston as shown in the figure left.
2. The piston and the shaft are threaded and mesh each other.
3. The piston rotates the shaft clockwise while it goes up.

2. Counter clockwise



1. Pressurized oil comes in to the upper room of the rotary actuator and push down the piston as shown in the figure left.
2. The piston rotates the shaft counter-clockwise while it goes down.

2. Platform rotary actuator air bleeding procedures



Bleed air from the platform rotary actuator as follows when the air is suspected in the rotary actuator and causes excessive free play.

1. For the machine with Fly- jib.

- 1) Start the engine, raise and lower the fly- jib to its full stroke more than 5 times to bleed air from the hydraulic hoses installed in the boom, and then lower the platform close to the ground.
Caution: Do not operate the platform rotating functions while raising and lowering the fly- jib.
- 2) Rotate the platform fully CW and CCW more than 10 times.
- 3) Rotate the platform CCW fully, loosen the “Air bleed plug” shown in the Fig - 1 to bleed air from the rotary actuator, then tighten the air bleed plug.
- 4) Rotate the platform CW and CCW fully 2 ~ 3 times, repeat the above step 3) until no air comes out of the rotary actuator, and then tighten the air bleed plug securely.
- 5) Move the platform by hands, and make sure that the rotary actuator does not have excessive free play.




1) For the machine without Fly- jib

- 1) Shut down the engine, disconnect both of the hydraulic hose connected to the P and T port of the platform rotation solenoid valve shown in Fig - 2, and then connect the hoses each other using the hose adapters.
- 2) Start the engine, depress the foot switch and hold the platform rotation switch either in CW or CCW position for about 2 minutes to bleed air from the hydraulic hoses installed in the boom.
- 3) Shut down the engine, disconnect the hydraulic hoses, and then re- connect them to their original positions.
- 4) Re- start the engine, rotate the platform CW and CCW fully more than 10 times.
- 5) Rotate the platform CCW fully, loosen the “Air bleed plug” shown in Fig - 1 to bleed air from the rotary actuator, and then tighten the air bleed plug.
- 6) Rotate the platform CW and CCW fully 5 times, repeat the above step 5) until no air comes out from the rotary actuator, and then tighten the air bleed plug securely.
- 7) Move the platform by hands, and make sure that the rotary actuator does not have excessive free play.



Travel motor

| | | |
|-----------------|----------------------|--|
| Hydraulic motor | Motor type | Plunger motor |
| | Rated pressure | 350 kg /m ² (4,980 PSI) |
| | Displacement | 26.8 or 52.7 cc / rev. (1.64 or 3.22 in ³ / rev.) |
| Gearbox | Gear type | Planetary gear |
| | Reduction ratio | 1 / 37.7 |
| | Recommended gear oil | Shell Spirax EP90 |
| | Gear oil capacity | 1.7 liters (0.45 gallons) |




A - view

This technical drawing shows a top-down view of a circular mechanical assembly. The assembly features a central vertical shaft with various components mounted on it. The outermost ring has 16 circular features, likely bolt holes or ports, spaced evenly around the circumference. Numerous callout lines point from numbered circles to specific parts of the assembly. The callout numbers are arranged as follows:

- Top row (left to right): 324, 336, 328, 326, 337, 330, 327, 323, 338, 386, 321, 325, 343, 42.
- Bottom row (left to right): 204, 208, 205, 203, 209, 206, 218, 217, 209, 202, 222, 201, 211, 208, 370, 212, 216, 215, 221.

This diagram is a detailed exploded view of a mechanical assembly, likely a pump or engine component. It features numerous numbered callouts (1 through 56) pointing to specific parts. The assembly is shown in a disassembled state to illustrate the relationship between components. Section lines A-A and B-B are indicated, suggesting cross-sectional views are provided elsewhere in the document. The parts are arranged in a symmetrical, radial pattern around a central axis.




3- 48


Check valve block

This check valve block is installed at the outlet lines of the main and emergency pumps to prevent the counter- flow.

| | | |
|----------------|---------|--------------------------------------|
| Rated pressure | | 210 kg / cm ² (2,990 PSI) |
| Rated flow | P1 → T1 | 100 liters /min (26.4 gallons / min) |
| | P2 → T2 | 5 liters /min (1.3 gallons / min) |



X – X section




4. Electrical section

Main CPU box (M2A)


This main CPU box is installed on the turntable to control the machine together with the *Sub- CPU board (M4A)* in the upper control box.

7- segment diodes


These 7- segment diodes show error codes in the event of system failures. See the pages 4- 5 and 4- 6 for the details of Error codes and their countermeasures.



1. Input/Output characteristics (for the machine without Duplicated sensors)



2. Input/Output characteristics (for the machine with Duplicated sensors)



3. Error codes and their countermeasures

Machines applied: Manufactured in April 2003 and after

In the event that any error was found, the 7 segment diodes on the Main CPU board (M2A) indicate the error code as listed below.

NOTE: If several errors were found at the same time, only one error code that has the highest priority will be indicated on the 7 segment diodes.


| Priority | Error code | Upper control box | | Lower control box | | Error descriptions | Cause | Countermeasures |
|----------|------------|--------------------|--------------------|--------------------|--------------------|---|--|--|
| | | System failure LED | Outreach limit LED | System failure LED | Outreach limit LED | | | |
| 1 | 30 | Blinks | Off | Blinks | Off | 1. M2A. Divided by Zero 2. M2A. ROM error 3. M2A. RAM error 4. Exceptional error | 1. Incorrect parameters are memorized in the Main CPU box (M2A). 2. Faulty ROM in the Main CPU box (M2A) 3. Faulty Main CPU box (M2A) | 1. Write the correct parameters into the Main CPU box (M2A), using the Laptop computer. 2. Replace the Main CPU box (M2A). |
| 2 | 32 | Blinks | Off | Blinks | Off | 1. M4A. Divided by Zero 2. Exceptional error | Faulty Sub-CPU board (M4A) | Replace the Sub-CPU board (M4A). |
| 3 | 23 | Blinks | Off | Blinks | Off | M2A. E2PROM error | 1. Incorrect or damaged parameters are memorized in the Main CPU box (M2A). 2. Faulty Main CPU box (M2A) | 1. Write the correct parameters into the Main CPU box (M2A), using the Laptop computer. 2. Replace the Main CPU box (M2A). |
| 4 | 24 | Blinks | Off | Blinks | Off | M2A. E2P Bios error | 1. Incorrect or damaged parameters are memorized in the Main CPU box (M2A). 2. Faulty Main CPU box (M2A) | 1. Write the correct parameters into the Main CPU box (M2A), using the Laptop computer. 2. Replace the Main CPU box (M2A). |
| 5 | 64 | Off | Off | Off | Off | M2A. Power source voltage (24 volts) error | 1. The main power voltage for the Main CPU box (M2A) is lower than 18 volts or higher than 30 volts. 2. Faulty Main CPU box (M2A) | 1. Check the main power voltage and rectify. 2. Replace the Main CPU box (M2A). |
| 6 | 66 | Off | Off | Off | Off | M4A. Power source voltage (24 volts) error | 1. The main power voltage for the Sub-CPU board (M4A) is lower than 18 volts or higher than 30 volts. 2. Faulty Sub-CPU board (M4A) | 1. Check the main power voltage and rectify. 2. Replace the Sub-CPU board (M4A). |
| 7 | 71 | Blinks | Off | Blinks | Off | 1. M2A 12 bit AD timeout error 2. M2A 12 bit AD converter error 3. M2A 10 bit AD timeout error 4. M2A 10 bit AD converter error | Faulty Main CPU box (M2A) | Replace the Main CPU box (M2A). |
| 8 | 74 | Blinks | Off | Blinks | Off | M2A. AD power source voltage (5 volts) error | Faulty Main CPU box (M2A) | Replace the Main CPU box (M2A). |
| 9 | 73 | Blinks | Off | Blinks | Off | 1. M4A. 12 bit AD converter error 2. M4A. 10 bit AD converter error | Faulty Sub-CPU board (M4A) | Replace the Sub-CPU board (M4A). |
| 10 | 90 | Blinks | Off | Blinks | Off | 1. M2A. PWM 1 error: Elevation UP 2. M2A. PWM 2 error: Elevation DOWN | The Main CPU box (M2A) has output to the Elevation UP or DOWN solenoid in spite of no command. 1. Short circuit in the output lines to the Elevation UP or DOWN solenoid(s). 2. Faulty Elevation UP or DOWN solenoid 3. Faulty Main CPU box (M2A) | 1. Rectify the output lines to the Elevation UP and DOWN solenoids. 2. Replace the Elevation UP or/ and DOWN solenoid(s). 3. Replace the Main CPU box (M2A). |
| 11 | 92 | Blinks | Off | Blinks | Off | 1. M2A. PWM 3 error: Telescope OUT 2. M2A. PWM 4 error: Telescope IN | The Main CPU box (M2A) has output to the Telescope OUT or IN solenoid in spite of no command. 1. Short circuit in the output lines to the Telescope OUT or IN solenoid 2. Faulty Telescope OUT or IN solenoid 3. Faulty Main CPU box (M2A) | 1. Rectify the output lines to the Telescope OUT and IN solenoids. 2. Replace the Telescope OUT or/ and IN solenoid(s). 3. Replace the Main CPU box (M2A). |
| 12 | 94 | Blinks | Off | Blinks | Off | 1. M2A. PWM 5 error: Boom rotation CW 2. M2A. PWM 6 error: Boom rotation CCW | The Main CPU box (M2A) has output to the Rotation CW or CCW solenoid in spite of no command. 1. Short circuit in the output lines to the Rotation CW or CCW solenoid 2. Faulty Rotation CW or CCW solenoid 3. Faulty Main CPU box (M2A) | 1. Rectify the output lines to the Rotation CW and CCW solenoids. 2. Replace the Rotation CW or/ and CCW solenoid(s). 3. Replace the Main CPU box (M2A). |
| 13 | 96 | Blinks | Off | Blinks | Off | 1. M2A. PWM 7 error: Travel FWD 2. MA. PWM 8 error: Travel REV | The Main CPU box (M2A) has output to the Travel FWD or REV solenoid in spite of no command. 1. Short circuit in the output lines to the Travel FWD or REV solenoid 2. Faulty Travel FWD or REV solenoid 3. Faulty Main CPU box (M2A) | 1. Rectify the output lines to the Travel FWD or REV solenoid. 2. Replace the Travel FWD or/ and REV solenoid(s). 3. Replace the Main CPU box (M2A). |
| 14 | 77 | Blinks | Off | Blinks | Off | 1. M2A: ET1 error: Unload sol. A 2. M2A: ET2 error: Unload sol. B 3. M2A: ET3 error: Platform level UP sol. 4. M2A: ET4 error: Platform level DWN sol. | The Main CPU box (M2A) has output to the ET1, ET2, ET3, or ET4 in spite of no command. 1. Short circuit in the output lines to the solenoid(s) 2. Faulty solenoid(s) 3. Faulty Main CPU box (M2A) | 1. Rectify the output lines to the solenoid(s). 2. Replace the solenoid(s). 3. Replace the Main CPU box (M2A). |
| 15 | 79 | Blinks | Off | Blinks | Off | 1. M4A. ET1 error: Platform rotation CW sol. 2. M4A. ET2 error: Platform rotation CCW sol. | The Sub-CPU board (M4A) has output to the Platform rotation solenoid CW or CCW in spite of no command. 1. Short circuit in the output lines to the Platform rotation solenoid CW or CCW 2. Faulty Platform rotation solenoid CW or CCW 3. Faulty Sub-CPU board (M4A) | 1. Rectify the output lines to the Platform rotation CW and CCW solenoids. 2. Replace the Platform rotation CW or/ and CCW solenoid(s). 3. Replace the Sub-CPU board (M4A). |
| 16 | 81 | Blinks | Off | Blinks | Off | M2A. RS485 Reception error (M4A → M2A) | The Main CPU box (M2A) has failed to receive the data from the Sub-CPU board (M4A). 1. Faulty communication lines between the Main CPU box (M2A) and the Sub-CPU board (M4A) 2. Faulty Main CPU box (M2A) 3. Faulty Sub-CPU board (M4A) | 1. Rectify the communication lines. 2. Replace the Main CPU box (M2A). 3. Replace the Sub-CPU board (M4A). |
| 17 | 82 | Blinks | Off | Blinks | Off | M4A. RS485 Reception error (M2A → M4A) | The sub CPU board (M4A) has failed to receive the data from the Main CPU box (M2A). 1. Faulty communication lines between the Main CPU box (M2A) and the Sub-CPU board (M4A) 2. Faulty Main CPU box (M2A) 3. Faulty Sub-CPU board (M4A) | 1. Rectify the communication lines. 2. Replace the Main CPU box (M2A). 3. Replace the Sub-CPU board (M4A). |
| 18 | 06 | Blinks | Off | Blinks | Off | AD Lower limit: Boom angle | Abnormally low AD value has been input from the Boom angle sensor. 1. Faulty electrical lines between the Boom angle sensor and the Main CPU box (M2A) 2. Incorrect Boom angle sensor calibrations 3. Faulty Boom angle sensor 4. Faulty Main CPU box (M2A) 5. [For the machine with Duplicated sensor] The difference of AD value between the main and sub sensors exceeds the specified value. | 1. Rectify the electrical lines to the Boom angle sensor. 2. Perform the Boom angle sensor calibrations, using the Laptop computer. 3. Replace the Boom angle sensor. 4. Replace the Main CPU box (M2A). |
| 19 | 07 | Blinks | Off | Blinks | Off | AD Upper limit: Boom angle | Abnormally high AD value has been input from the Boom angle sensor. 1. Faulty electrical lines between the Boom angle sensor and the Main CPU box (M2A) 2. Incorrect Boom angle sensor calibrations 3. Faulty Boom angle sensor 4. Faulty Main CPU box (M2A) | 1. Rectify the electrical lines to the Boom angle sensor. 2. Perform the Boom angle sensor calibrations, using the Laptop computer. 3. Replace the Boom angle sensor. 4. Replace the Main CPU box (M2A). |
| 20 | 08 | Blinks | Off | Blinks | Off | AD Lower limit: Boom length | Abnormally low AD value has been input from the Boom length sensor. 1. Faulty electrical lines between the Boom length sensor and the Main CPU box (M2A) 2. Incorrect Boom length sensor calibrations 3. Faulty Boom length sensor 4. Faulty Main CPU box (M2A) 5. [For the machine with Duplicated sensor] The difference of AD value between the main and sub sensors exceeds the specified value. | 1. Rectify the electrical lines to the Boom length sensor. 2. Perform the Boom length sensor calibrations, using the Laptop computer. 3. Replace the Boom length sensor. 4. Replace the Main CPU box (M2A). |

| Priority | Error code | Upper control box | | Lower control box | | Error descriptions | Cause | Countermeasures |
|----------|------------|--------------------|--------------------|--------------------|--------------------|-----------------------------|--|--|
| | | System failure LED | Outreach limit LED | System failure LED | Outreach limit LED | | | |
| 21 | 09 | Blinks | Off | Blinks | Off | AD Upper limit: Boom length | <p>Abnormally high AD value has been input from the Boom length sensor..</p> <ol style="list-style-type: none"> Faulty electrical lines between the Boom length sensor and the Main CPU box (M2A). Incorrect Boom length sensor calibrations. Faulty Boom length sensor. Faulty Main CPU box (M2A) [For the machine with Boom wire rope failure L/S] No input from the Boom wire rope failure L/S. | <ol style="list-style-type: none"> Rectify the electrical lines to the Boom length sensor.. Perform the Boom length sensor calibrations, using the Laptop computer.. Replace the Boom length sensor.. Replace the Main CPU box (M2A). Rectify the electrical lines to the Boom wire rope failure L/S, Replace the Boom wire rope failure L/S. |
| 22 | 53 | Blinks | Off | Blinks | Off | AD Lower limit: Tilt (X) | <p>Abnormally low AD value has been input from the Tilt (X), Longitudinal sensor.</p> <ol style="list-style-type: none"> Faulty electrical lines between the Tilt sensor (X) and the Main CPU (M2A). Incorrect Tilt sensor (X) calibrations Faulty Tilt sensor (X) Faulty Main CPU box (M2A) | <ol style="list-style-type: none"> Rectify the electrical lines to the Tilt sensor (X). Perform the Tilt sensor (X), Longitudinal calibrations, using the Laptop computer. Replace the Tilt sensor (X), Longitudinal. Replace the Main CPU box (M2A). |
| 23 | 54 | Blinks | Off | Blinks | Off | AD Upper limit: Tilt (X) | <p>Abnormally high AD value has been input from the Tilt (X), Longitudinal sensor.</p> <ol style="list-style-type: none"> Faulty electrical lines between the Tilt sensor (X) and the Main CPU box (M2A) Incorrect Tilt sensor (X) calibrations Faulty Tilt sensor (X) Faulty Main CPU box (M2A) | <ol style="list-style-type: none"> Rectify the electrical lines to the Tilt sensor (X). Perform the Tilt sensor (X), Longitudinal calibrations, using the Laptop computer. Replace the Tilt sensor (X), Longitudinal. Replace the Main CPU box (M2A). |
| 24 | 55 | Blinks | Off | Blinks | Off | AD Lower limit: Tilt (Y) | <p>Abnormally high AD value has been input from the Tilt (Y), Longitudinal sensor.</p> <ol style="list-style-type: none"> Faulty electrical lines between the Tilt sensor (Y) and the Main CPU box (M2A) Incorrect Tilt sensor (Y) calibrations Faulty Tilt sensor (Y) Faulty Main CPU box (M2A) | <ol style="list-style-type: none"> Rectify the electrical lines to the Tilt sensor (Y). Perform the Tilt sensor (Y), Lateral calibrations, using the Laptop computer. Replace the Tilt sensor (Y), Lateral. Replace the Main CPU box (M2A). |
| 25 | 56 | Blinks | Off | Blinks | Off | AD Upper limit: Tilt (Y) | <p>Abnormally high AD value has been input from the Tilt (Y), Lateral sensor.</p> <ol style="list-style-type: none"> Faulty electrical lines between the Tilt sensor (Y) and the Main CPU box (M2A) Incorrect Tilt sensor (Y) calibrations Faulty Tilt sensor (Y) Faulty Main CPU box (M2A) | <ol style="list-style-type: none"> Rectify the electrical lines to the Tilt sensor (Y). Perform the Tilt sensor (Y), Lateral calibrations, using the Laptop computer. Replace the Tilt sensor (Y), Lateral. Replace the Main CPU box (M2A). |
| 26 | 60 | Blinks | Off | Blinks | Off | Limit cancel switch error | <ol style="list-style-type: none"> Open or short circuit in the lines between the “<i>Limit cancel switch</i>” and the Main CPU box (M2A) Faulty Limit cancel switch Faulty Main CPU box (M2A) | <ol style="list-style-type: none"> Rectify the lines between the Limit cancel switch and the Main CPU box (M2A). Replace the Limit cancel switch. Replace the Main CPU box (M2A). |
| 27 | 61 | Blinks | Off | Blinks | Off | Pre- start check error | Pre-start check switch was operated while the platform is positioned out of the specified range for Pre-start check. | See the operation manual |
| 28 | 69 | Blinks | Off | Blinks | Off | Runaway movements | <p>AD values for sensors have been changed in spite of no outputs.</p> <ol style="list-style-type: none"> Faulty Hydraulic system Short circuit in the output lines to solenoid(s) Faulty solenoid(s) Faulty Main CPU box (M2A) | <ol style="list-style-type: none"> Rectify the Hydraulic system. Rectify the output lines to solenoid(s). Replace solenoid(s). Replace the Main CPU box (M2A). |


Upper control box

329- 00134- 02L
329- 00134- 04D
329- 00134- 05E

| No. | Descriptions | Remarks |
|-----|-------------------------------------|---|
| 1 | Sub-CPU board | |
| 2 | Connector No. 204 | |
| 3 | Connector No. 205 | |
| 4 | Connector No. 206 | |
| 5 | Connector No. 201 | |
| 6 | Connector No. 202 | |
| 7 | Connector No. 203 | |
| 8 | Fly jib switch | For the machine with Fly jib only. |
| 9 | Platform rotation switch | |
| 10 | Travel speed select switch | |
| 11 | Blind cap for optional switch | |
| 12 | Emergency pump switch | |
| 13 | Work light switch | Option |
| 14 | Head light switch | Option |
| 15 | Fuel select switch | For the machine with Dual fuel engine only. |
| 16 | Hydraulic generator LED | Option for USA only. |
| 17 | Hydraulic generator switch | Option for USA only. |
| 18 | Horizontal/Vertical LED | |
| 19 | Horizontal/Vertical select switch | |
| 20 | Platform level adjust switch | |
| 21 | Overload LED | |
| 22 | System failure LED | |
| 23 | Fuel level LED | |
| 24 | Outreach limit LED | SP18A/ISP60 is not equipped with this LED.. |
| 25 | Engine failure LED | |
| 26 | Tilt LED | |
| 27 | Emergency stop switch | |
| 28 | Horn switch | |
| 29 | Engine start switch | |
| 30 | Steering switch | |
| 31 | Tilt/Overload alarm buzzer | |
| 32 | Joy stick controller for Rotation | |
| 33 | Joy stick controller for Telescope | |
| 34 | Joy stick controller for Elevation | |
| 35 | Horizontal/Vertical buzzer | |
| 36 | Joy stick controller for Travelling | |




1 Electrical schematic



Sub- CPU board (M4A)


329- 00223- 00

This board is installed in the Upper control box to control the machine together with the *Main CPU box (M2A)* located at the turntable.




1. Input / output characteristics

329- 00223- 00





Joystick controller

Four joystick controllers are installed on the upper control box to control the Boom elevation, Boom telescope, Boom rotation and Traveling functions.



Foot switch

This foot switch is installed on the platform floor to disable the functions unless the foot switch is depressed.




| No. | Description | No. | Description |
|-----|---------------|------|--------------------------|
| 1 | Pedal | 7 | Micro switch (MZ20-7117) |
| 2 | Spring | 8 | Insulator |
| 3 | Body | 9 | Electric cable |
| 4 | Pedal shaft | 10 | Cable gland |
| 4a | O-ring | 11 | Rubber packing |
| 5 | Lever | 12 | Cover |
| 6 | Switch holder | ---- | ----- |

Lower control box


329- 00052- 00C
329- 00053- 00B
329- 00055- 00C

| No. | Capacity | Descriptions |
|-----|----------|------------------|
| F1 | 20 A | CPU, Upper |
| F2 | 20 A | Engine |
| F3 | 10 A | CPU, Lower |
| F4 | 10 A | Work light |
| F5 | 10 A | Glow (Fuel pump) |
| F6 | 10 A | Engine start |
| F7 | 5 A | Emergency pump |
| F8 | 5 A | Lower control |
| F9 | 5 A | Upper control |
| F10 | 10 A | Horn |
| F11 | 5 A | Hour meter |





Fuse holder detail

| No | Descriptions | Remarks |
|----|-------------------------|---|
| 1 | Main key switch | |
| 2 | Limit cancel switch | |
| 3 | Fuse holder | |
| 4 | Glow LED | |
| 5 | Fuel level LED | |
| 6 | Engine oil pressure LED | |
| 7 | Water temperature LED | |
| 8 | Charge LED | |
| 9 | Air cleaner LED | |
| 10 | System failure LED | |
| 11 | Outreach limit LED | SR18A/ISR60 is not equipped with this LED. |
| 12 | Overload LED | |
| 13 | Hour meter | |
| 14 | Emergency stop switch | |
| 15 | Dead-man switch | |
| 16 | Fly jib switch | |
| 17 | Boom rotation switch | For the machine with Fly jib only. |
| 18 | Emergency pump switch | |
| 19 | Boom telescope switch | |
| 20 | Pre-start check switch | |
| 21 | Boom elevation switch | SR18A/ISR60 is not equipped with this switch. |
| 22 | Relay CR3 | |
| 23 | Relay CR4 | 320-05792 |
| 24 | Relay CR5 | 320-05792 |
| 25 | Relay CR6 | 320-05792 |
| 26 | Relay CR7 | 320-05792 |
| 27 | Relay CR1 | 320-05778 |
| 28 | Relay CR10 | 329-05792 |
| 29 | Fuel select switch | For the machine with Duel fuel engine only. |




A – A section




Connector detail

1. Electrical schematic



Main key switch

The Main key switch is installed on the lower control box to start or shut down the engine as well as to select the upper or lower control.



| | | Terminals | | | | | |
|---------------|---------------|-----------|-------|----|----|----|-----|
| | | 30 | 15/54 | 58 | 19 | 17 | 50a |
| Key positions | OFF | ○ | | | | | |
| | Upper control | ○ | — | ○ | | | |
| | Lower control | ○ | ○ | | | | |
| | Pre-heat | ○ | — | — | ○ | | |
| | Start | ○ | — | — | — | ○ | ○ |


Relays in Lower control box

1. Relay CR1 (320- 05778)

This relay is installed in the lower control box to supply the main power to the machine.

Rated voltage ----- DC 24 v


Coil resistance ----- 130




CAUTION

Connect the wires to the contacts of the relay as follows.

*When using “*Normally closed*” contact.



*When using “*Normally open*” contact.




2. Relays CR3, 4, 5, 6, 7 and 10 (320- 05792)

These relays are installed in the lower control box to supply the power to the various electrical components.


Rated voltage ----- DC 24 v

Coil resistance ----- 290




Engine control box


This Engine control box is installed at the right/front side of the turntable to control the engine, and to supplies the power (DC24 V) to the emergency pump.



Connector




Electric circuit



1. EGR cut controller (5C0-01328-00)

The EGR cut controller is installed in the engine control box to control the EGR cut solenoid.

Connector




| | | | | | | |
|---|---|---|----|----|----|----|
| 7 | 8 | 9 | 10 | 11 | 12 | 13 |
| 1 | 2 | 3 | X | 4 | 5 | 6 |


| | |
|----|---------------------|
| 1 | Starter s/w |
| 2 | Battery (-) C/U/GND |
| 3 | Thermo sensor |
| 4 | IGkey (+) |
| 5 | (TXD) |
| 6 | Stop R/L |
| 7 | Tacho (+) |
| 8 | Tacho (-) |
| 9 | Boost VCC |
| 10 | Boost SIG |
| 11 | Boost GND |
| 12 | (RXD) |
| 13 | EGR R/L |

2. Timer relay (5C0-01329-00)

The timer relay is installed in the engine control box to supply power to the glow plugs on the diesel engine.




Key s/w



3. EGR cut relay (CR-22) (320- 05792)



This EGR cut relay is installed in the engine control box to supply power to the EGR cut solenoid.



4. Safety relay (320- 05779A)

This safety relay is installed in the engine control box to prevent the starter motor from being driven while the engine is in motion.

| | |
|---------------|---------|
| Rated voltage | DC 24 v |
| Rated current | 50 A |




ON/OFF conditions of the key switch

| Key positions | Terminals | B | ACC | C |
|---------------|-----------|---|-----|---|
| OFF | | ○ | | |
| ON | | ○ | ○ | |
| Engine start | | ○ | ○ | ○ |




5. Charge relay (320- 00000- 03C)

This charge relay is installed in the engine control box and switches on when the alternator charges the batteries.

| | |
|-----------------------|-------------------|
| Rated voltage | DC 24 v |
| Switching on voltage | DC 18 v or higher |
| Switching off voltage | DC 10v or lower |



This LED goes on when the relay is switched on.




6. Relay CR21 (320- 05778)

These relays are installed in the engine control box.

The relay CR20 actuates the engine stop motor, and the relay CR21 supplies power to such components as the accelerator motor, the alternator, the charge relay and the safety relay.

Rated voltage ----- DC 24 v


Coil resistance ----- 130




CAUTION

Connect the wires to the contacts of the relay as follows.

*When using “*Normally closed*” contact.




*When using “*Normally open*” contact.



7. Contactor for Emergency pump (320- 05313)

This contactor is installed in the engine control box to supply power to the emergency pump.

| | |
|---------------|---|
| Rated voltage | DC 24 v |
| Rated current | 200 A (Continuously), 700 A (for two minutes) |




Boom length sensor

For the machine with duplicated sensors:



The boom length sensors (R/H) and (L/H) are installed on the both sides of the 1st boom section to sense the boom length.

For the machine without duplicated sensors:

The boom length sensor (R/H) is installed on the right side of the 1st boom section to sense the boom length.





1. Boom length sensor (R/H)



Resistance characteristics


2. Boom length sensor (L/H)



Resistance characteristics

Boom angle sensor (R/H)

The boom angle sensor (R/H) is located on the right side of the turntable to sense the boom angle.




Sensor installation procedures

1. Lower the boom fully and make sure the boom angle is -12.5 degrees.
2. Adjust the length of the connecting rod to $277 \pm 0.5 \text{ mm}$ ($10.9 \pm 0.02 \text{ in.}$).
3. Loosen the fixing bolts of the boom angle sensor, and then connect an "Ohm meter" between the LR and LY wires of the boom angle sensor.
4. Shift the position of the sensor to adjust the resistance to $1.0 \pm 0.1 \text{ K}$, and then tighten the fixing bolts.

Boom angle sensor (L/H) for the machine with Duplicated sensors.

The boom angle sensor (L/H) is located on the left side of the turntable to sense the boom angle.




Sensor installation procedures

1. Lower the boom fully and make sure the boom angle is -12.5 degrees.
2. Adjust the length of the connecting rod to $277 \pm 0.5 \text{ mm}$ ($10.9 \pm 0.02 \text{ in.}$).
3. Loosen the fixing bolts of the boom angle sensor, and then connect an "Ohm meter" between the LY and B wires of the boom angle sensor.
4. Shift the position of the sensor to adjust the resistance to $1.0 \pm 0.1 \text{ K}$, and then tighten the fixing bolts.

Boom length limit switches

The boom length limit switch detect the 2nd boom extended length shown in the table below to disable the Boom telescope Out and Boom elevation Down function to prevent the platform exceed the working range limit while the functions is operated with using Limit cancel switch due to the system error occurs.

| Model | 2 nd boom extended length |
|--------|--------------------------------------|
| SP21AJ | 3,592 mm (141.4 inches) |
| SP21A | 5,080 mm (200.0 inches) |
| SP18AJ | 3,400 mm (133.9 inches) |





Tilt sensor

Two tilt sensors; one is for longitudinal direction and the other for lateral direction are installed on the turntable to sense the tilt angle of the machine.

Power voltage: $DC5 \pm 0.5 \text{ V}$

Output voltage: $100 \text{ mV} / 1 \text{ degree}$ ($2.5 \pm 0.05 \text{ volts}$ when horizontal)




Output characteristics

Accelerator motor For Diesel engine

This accelerator motor controls the engine rpm into three speeds: **Low**, **Mid** and **High**.

| | |
|---------------|------------------------|
| Rated voltage | DC 24 V (DC 20 ~ 30 V) |
|---------------|------------------------|



To check the functions of the accelerator motor, follow the instructions outlined below.

1. Connect the battery (DC24V) between the **Red** (+) and the **Black** (-) wires.
2. Supply +24V to the **Green** wire, and make sure that the control cable is pulled in to the **Mid rpm** position.
3. Supply +24V to both the **Green** and the **White** wires at the same time, and make sure that the control cable is pulled in to the **High rpm** position


Specific engine rpm

| | |
|------|---------------------------|
| Low | 1,020 rpm (Engine Idling) |
| Mid | 1,300 rpm |
| High | 2,200 rpm |

Fuel pump for automatic air bleeding system

For diesel engine


This fuel pump is actuated when the Main key switch is turned to the **ON**, the **START**, or the **GLOW** position to feed fuel to the injection pump on the diesel engine.



Air cleaner clog detect switch

897166- 4100


This switch is installed at the air cleaner inlet to sense the air cleaner clogging. The contact of this switch closes when the vacuum of the intake air reaches 6.23 kPa (635 mmAq).



Low fuel level detect switch


382- 00000- 26A

This switch is installed at the fuel tank to sense the fuel level.



Starter motor



For diesel engine (898072- 3151)



Alternator


Rated voltage: DC24V

Rated current: 15A




5. Electrical circuit for individual system


Engine start and stop system (Isuzu 4LE2)




Boom elevation system




Boom telescope system




Boom rotation system



Traveling system




H / V control system



Turntable



Platform rotation and Fly-jib articulation systems



For the machine without Duplicated sensors



For the machine with Duplicated sensors




For the machine without Oscillation axle release limit switch


For the machine without Oscillation axle release limit switch



Emergency pump system



Horn, Work light and Hydraulic generator systems



6. Inspections and Adjustments

Inspection of Limited work radius and Limited boom angle

Caution:

The items listed below should be strictly obeyed when checking the limited work radius and the limited boom angle.

- Set up the machine on firm and level surface.
- Do not allow either any personnel or load on the platform.
- Do not operate the machine from the platform. The machine should be operated only from the lower control.
- Stop the inspection immediately and conduct adequate adjustments or repairs, if any failure is observed during the inspections.
- Rotate the platform and set up the platform at the central position.

1. Check the limited work radius as follows. (See Fig-1)

| No | Inspection procedures | | |
|----|---|-------------------------------|--------------------------|
| 1 | Check the Maximum allowable work radius of the platform and mark this work radius on the ground. | | |
| | Model | Maximum allowable work radius | |
| | SP18AJ / ISP60J | 15.8 meters | 51ft - 10in |
| | SP21A / ISP70 | 18.6 meters | 61ft - 0 in |
| | SP21AJ / ISP70J | 17.8 meters. | 58ft - 5 in |
| 2 | Retract the boom fully, set it horizontally, and then extend the boom until the boom extending movements automatically stops. (For the machine equipped with the fly- jib, adjust the fly- jib so that the jib becomes horizontal.) Caution: Do not extend the boom further, if the work radius reaches the maximum allowable limit. If so, stop the inspection and conduct adequate adjustments or repairs. | | |
| 3 | Make sure that the boom lowering function is disabled. | | |
| 4 | Measure the work radius of the platform and make sure that the work radius is within the specific value. | | |
| | Model | Specific work radius | |
| | SP18AJ / ISP60J | 15.4 ~ 15.8 meters | 50ft - 6in ~ 51ft - 10in |
| | SP21A / ISP70 | 18.2 ~ 18.6 meters | 59ft - 8in ~ 61ft - 0in |
| | SP21AJ / ISP70J | 17.4 ~ 17.8 meters | 57ft - 1in ~ 58ft - 5in |

2. Check the limited boom angle as follows by using a goniometer. (See Fig-2)

| No | Inspection procedures | |
|----|---|--------------------------------------|
| 1 | Check the minimum allowable limited boom angle and mark it on a goniometer. | |
| | Model | Minimum allowable limited boom angle |
| | SP18AJ / ISP60J | 35 degrees |
| | SP21A / ISP70 | 31 degrees |
| | SP21AJ / ISP70J | 46 degrees |
| 2 | Raise the boom fully and extend it fully, set the goniometer on the upper surface of the 1 st boom section, and then lower the boom until the boom lowering movement automatically stops. Caution: Do not lower the boom further, if the boom angle reaches the minimum allowable limit. If so, stop the inspection and conduct adequate adjustments or repairs. | |
| 4 | Measure the boom angle and make sure that the boom angle is within the specific value. | |
| | Model | Specific limited boom angle |
| | SP18AJ / ISP60J | 35 ~ 38 degrees |
| | SP21A / ISP70 | 31 ~ 34 degrees |
| | SP21AJ / ISP70J | 46 ~ 49 degrees |

Fig- 1





Fig- 2




SP18A / ISP60 Inspection data sheet

| Model | Serial No. | Specification No. | Date of Inspection | Inspector |
|-------|------------|-------------------|--------------------|-----------|
| | | | | |

| Item | | | | Specific rpm | Inspected rpm | Remarks | |
|------------------------------|---------------------|---------------|------------------------------------|-----------------------------|--------------------|---|---------|
| Engine rpm | Diesel engine | Low (Idling) | | 1,020 rpm | | Check the Mid and High rpm with the relief valves being actuated. | |
| | | Mid | | 1,300 rpm | | | |
| | | High | | 2,200 rpm | | | |
| Item | | | Specific pressure | | Inspected pressure | Remarks | |
| Relief valve preset pressure | Relief valve (P1) | | 340 kg/cm ² (4,840 PSI) | | | | |
| | Relief valve (P2) | | 340 kg/cm ² (4,840 PSI) | | | | |
| | Relief valve (P3) | | 25 kg/cm ² (360 PSI) | | | | |
| | Relief valve (P4) | | 210 kg/cm ² (2,990 PSI) | | | | |
| | Relief valve (P10) | | 140 kg/cm ² (1,990 PSI) | | | | |
| Item | | | | Specific speed | | Inspected speed | Remarks |
| Actuating speed | Boom elevation | Maximum speed | UP | 40 ± 6 seconds | | | Fig-1 |
| | | | DOWN | 40 ± 6 seconds | | | |
| | | Limited speed | UP | 100 ± 15 seconds | | | Fig-2 |
| | | | DOWN | 100 ± 15 seconds | | | |
| | Boom telescope | OUT | | 35 ± 5 seconds | | | Fig-3 |
| | | IN | | 30 ± 5 seconds | | | |
| | Boom rotation | Maximum speed | CW | 80 ± 12 seconds | | | Fig-4 |
| | | | CCW | 80 ± 12 seconds | | | |
| | | Limited speed | CW | 240 ± 36 seconds | | | Fig-5 |
| | | | CCW | 240 ± 36 seconds | | | |
| | Traveling | High speed | FWD | 6.6 ± 1.0 sec/10 m (33 ft) | | | Fig-6 |
| | | | REV | 6.6 ± 1.0 sec/10 m (33 ft) | | | |
| | | Mid speed | FWD | 13 ± 2 sec/10m (33 ft) | | | |
| | | | REV | 13 ± 2 sec/10m (33 ft) | | | |
| | | Low speed | FWD | 28 ± 5 sec/10m (33ft) | | | |
| | | | REV | 28 ± 5 sec/10m (33ft) | | | |
| | Platform rotation | CW | | 15 ± 5 seconds | | | |
| | | CCW | | 15 ± 5 seconds | | | |
| | Horizontal movement | OUT | | 15 ± 2 sec/3 m (9ft – 10in) | | | |
| | | IN | | 15 ± 2 sec/3 m (9ft – 10in) | | | |
| | Vertical movement | UP | | 15 ± 2 sec/3 m (9ft – 10in) | | | |
| | | DOWN | | 15 ± 2 sec/3 m (9ft – 10in) | | | |


Fig- 1



Boom elevation Maximum speed


Fig- 2

Boom fully extended




Boom elevation Limited speed

Fig- 3




Boom telescope speed

Fig- 4



Boom rotation Maximum speed


Fig- 5



Boom rotation Limited speed

Fig- 6

FWD ← → REV




Traveling Low, Mid and High speed

SP21A / ISP70 Inspection data sheet

| Model | Serial No. | Specification No. | Date of Inspection | Inspector |
|-------|------------|-------------------|--------------------|-----------|
| | | | | |


| Item | | | | Specific rpm | Inspected rpm | Remarks | | | |
|------------------------------|---------------------|-------------------------------------|------------------------------------|-----------------------------|----------------------------|---|---------|---------|-------|
| Engine rpm | Diesel engine | Low (Idling) | | 1,020 rpm | | Check the Mid and High rpm with the relief valves being actuated. | | | |
| | | Mid | | 1,300 rpm | | | | | |
| | | High | | 2,200 rpm | | | | | |
| Item | | | Specific pressure | | Inspected pressure | Remarks | | | |
| Relief valve preset pressure | Relief valve (P1) | | 340 kg/cm ² (4,840 PSI) | | | | | | |
| | Relief valve (P2) | | 340 kg/cm ² (4,840 PSI) | | | | | | |
| | Relief valve (P3) | | 25 kg/cm ² (360 PSI) | | | | | | |
| | Relief valve (P4) | | 210 kg/cm ² (2,990 PSI) | | | | | | |
| | Relief valve (P10) | | 140 kg/cm ² (1,990 PSI) | | | | | | |
| Item | | | | Specific speed | | Inspected speed | Remarks | | |
| Actuating speed | Boom elevation | Maximum speed | UP | | 40 ± 6 seconds | | | Fig-1 | |
| | | | DOWN | | 40 ± 6 seconds | | | | |
| | | Limited speed | UP | | 50 ± 7 seconds | | | Fig-2 | |
| | | | DOWN | | 50 ± 7 seconds | | | | |
| | Telescope | OUT | | 45 ± 7 seconds | | | Fig-3 | | |
| | | IN | | 35 ± 5 seconds | | | | | |
| | Boom rotation | Max. speed | CE spec. | CW | | 90 ± 13 seconds | | | Fig-4 |
| | | | | CCW | | 90 ± 13 seconds | | | |
| | | | USA spec. | CW | | 80 ± 12 seconds | | | |
| | | | | CCW | | 80 ± 12 seconds | | | |
| | | Limited speed | CW | | 240 ± 36 seconds | | | Fig-5 | |
| | | | CCW | | 240 ± 36 seconds | | | | |
| | Traveling | High speed | FWD | | 6.6 ± 1.0 sec/10 m (33 ft) | | | Fig-6 | |
| | | | REV | | 6.6 ± 1.0 sec/10 m (33 ft) | | | | |
| | | Mid speed | FWD | | 13 ± 2 sec/10m (33 ft) | | | | |
| | | | REV | | 13 ± 2 sec/10m (33 ft) | | | | |
| | | Low speed | FWD | | 28 ± 5 sec/10m (33ft) | | | | |
| | | | REV | | 28 ± 5 sec/10m (33ft) | | | | |
| | Platform rotation | CW | | 15 ± 5 seconds | | | | | |
| | | CCW | | 15 ± 5 seconds | | | | | |
| | Horizontal movement | OUT | | 15 ± 2 sec/3 m (9ft – 10in) | | | | | |
| | | IN | | 15 ± 2 sec/3 m (9ft – 10in) | | | | | |
| | Vertical movement | UP | | 15 ± 2 sec/3 m (9ft – 10in) | | | | | |
| | | DOWN | | 15 ± 2 sec/3 m (9ft – 10in) | | | | | |
| Item | | Specific limited work radius | | | | Inspected work radius | | Remarks | |
| Limited work radius | | 18.2 ~ 18.6 m (59ft-8in ~ 61ft-0in) | | | | | | | |
| Item | | Specific limited boom angle | | | | Inspected boom angle | | Remarks | |
| Limited boom angle | | 31 ~ 34 degrees | | | | | | | |

Fig- 1




Boom elevation Maximum speed

Fig- 2




Boom elevation Limited speed

Fig- 3




Boom telescope speed

Fig- 4




Boom rotation Maximum speed

Fig- 5



Boom rotation Limited speed

Fig- 6



Traveling Low, Mid and High speed


SP21AJ / ISP70J Inspection data sheet

| Model | Serial No. | Specification No. | Date of Inspection | Inspector |
|-------|------------|-------------------|--------------------|-----------|
| | | | | |

| Item | | | | Specific rpm | | Inspected rpm | | Remarks | | | | | |
|------------------------------|---------------------|-------------------------------------|------------------------------------|----------------|-----------------------------|-----------------------|------------------|---------|---|-------|-------|-------|--|
| Engine rpm | Diesel engine | | Low (Idling) | | 1,020 rpm | | | | Check the Mid and High rpm with the relief valves being actuated. | | | | |
| | | | Mid | | 1,300 rpm | | | | | | | | |
| | | | High | | 2,200 rpm | | | | | | | | |
| Item | | | Specific pressure | | | Inspected pressure | | Remarks | | | | | |
| Relief valve preset pressure | Relief valve (P1) | | 340 kg/cm ² (4,840 PSI) | | | | | | | | | | |
| | Relief valve (P2) | | 340 kg/cm ² (4,840 PSI) | | | | | | | | | | |
| | Relief valve (P3) | | 25 kg/cm ² (360 PSI) | | | | | | | | | | |
| | Relief valve (P4) | | 210 kg/cm ² (2,990 PSI) | | | | | | | | | | |
| | Relief valve (P10) | | 140 kg/cm ² (1,990 PSI) | | | | | | | | | | |
| Item | | | | Specific speed | | | Inspected speed | | Remarks | | | | |
| Actuating speed | Boom elevation | Maximum speed | UP | | 40 ± 6 seconds | | | | | Fig-1 | | | |
| | | | DOWN | | 40 ± 6 seconds | | | | | | | | |
| | | Limited speed | UP | | 50 ± 7 seconds | | | | | Fig-2 | | | |
| | | | DOWN | | 50 ± 7 seconds | | | | | | | | |
| | Telescope | OUT | | | 40 ± 6 seconds | | | | | Fig-3 | | | |
| | | IN | | | 30 ± 5 seconds | | | | | | | | |
| | Boom rotation | Max. speed | CE spec. | CW | | 110 ± 15 seconds | | | | | Fig-4 | | |
| | | | | CCW | | 110 ± 15 seconds | | | | | | | |
| | | | USA spec. | CW | | 80 ± 12 seconds | | | | | | | |
| | | | | CCW | | 80 ± 12 seconds | | | | | | | |
| | | Limited speed | | | CW | | 240 ± 36 seconds | | | | | Fig-5 | |
| | | | | | CCW | | 240 ± 36 seconds | | | | | | |
| | Traveling | High speed | FWD | | 6.6 ± 1.0 sec/10 m (33 ft) | | | | | Fig-6 | | | |
| | | | REV | | 6.6 ± 1.0 sec/10 m (33 ft) | | | | | | | | |
| | | Mid speed | FWD | | 13 ± 2 sec/10m (33 ft) | | | | | | | | |
| | | | REV | | 13 ± 2 sec/10m (33 ft) | | | | | | | | |
| | | Low speed | FWD | | 28 ± 5 sec/10m (33ft) | | | | | | | | |
| | | | REV | | 28 ± 5 sec/10m (33ft) | | | | | | | | |
| | Platform rotation | CW | | | 15 ± 5 seconds | | | | | | | | |
| | | CCW | | | 15 ± 5 seconds | | | | | | | | |
| | Fly jib elevation | UP | | | 30 ± 5 seconds | | | | | | | | |
| | | DOWN | | | 25 ± 5 seconds | | | | | | | | |
| | Horizontal movement | OUT | | | 15 ± 2 sec/3 m (9ft – 10in) | | | | | | | | |
| | | IN | | | 15 ± 2 sec/3 m (9ft – 10in) | | | | | | | | |
| | Vertical movement | UP | | | 15 ± 2 sec/3 m (9ft – 10in) | | | | | | | | |
| | | DOWN | | | 15 ± 2 sec/3 m (9ft – 10in) | | | | | | | | |
| Item | | Specific limited work radius | | | | Inspected work radius | | Remarks | | | | | |
| Limited work radius | | 17.4 ~ 17.8 m (57ft-1in ~ 58ft-5in) | | | | | | | | | | | |
| Item | | Specific limited boom angle | | | | Inspected boom angle | | Remarks | | | | | |
| Limited boom angle | | 46 ~ 49 degrees | | | | | | | | | | | |


See the figures right to check each actuating speed.

Fig- 1




Boom elevation Maximum speed

Fig- 2




Boom elevation Limited speed

Fig- 3




Boom telescope speed

Fig- 4




Boom rotation Maximum speed

Fig- 5



Boom rotation Limited speed

Fig- 6



Traveling Low, Mid and High speed

Engine RPM measurement procedures

1. Specific engine

| | |
|--------------|---------------|
| | Diesel engine |
| Low (Idling) | 1.020 rpm |
| Mid | 1.300 rpm |
| High | 2,200 rpm |


2. Measurements

1. Set up the machine on firm and level surface, warm up the engine without load, and then operate the machine to warm up the hydraulic system.
2. Measure the engine **Low (Idling) rpm** without loading the engine.
3. Measure the engine **Mid rpm** as follows.
 - (1) Retract the boom fully and set it under the horizontal, and then shut down the engine.
 - (2) Disconnect the connector CM2 from the Main CPU box (M2A).
See the page 4- 2 for the location of connector CM2.
 - (3) Turn the engine key switch to its Lower control position, and make sure that the “System failure LED” blinks on the Lower control panel.
See the page 4- 13 for the location of System failure LED.
 - (4) Re- start the engine with the engine key switch.
 - (5) Hold the Limit cancel switch in its ON position, and operate the Telescope switch to its IN position to load the engine.
See the page 4- 13 for the location of Limit cancel switch.
 - (6) Under the above conditions, measure the engine **Mid rpm**.

Caution:

Do not extend the outreach of the platform when operating the machine using the Limit cancel switch. Because, the safety system does not work and it may cause the machine to tip over.

4. Measure the engine **High rpm** as follows.
 - (1) Set up the wheel chocks in front and rear of all tires as shown in the figure below.




- (2) Retract the boom fully and set it under the horizontal.
 - (3) Set the travel speed select switch to its High- speed position.
 - (4) Operate the travel joystick controller to Forward or Reverse direction to load the engine.
 - (5) Under the above conditions, measure the engine **High rpm**.
- See the page 2- 2 for adjusting the Diesel engine rpm.

System pressure adjustment procedures


Specific pre- set pressure

| Relief valve | Pre-set pressure | Relief valve locations | Pump RPM (Engine RPM) | Functions | Pressure gauge |
|--------------|---|------------------------|--------------------------|---|-------------------|
| P1 | 340 ~ 350 kg / cm ² (4,840 ~ 4,980 PSI) | Hydraulic pump | 2,200 rpm | Travel (Forward) | Gauge 1 |
| P2 | 340 ~ 350 kg / cm ² (4,840 ~ 4,980 PSI) | Hydraulic pump | 2,200 rpm | Travel (Reverse) | Gauge 2 |
| P4 | 210 ~ 215 kg / cm ² (2,990 ~ 3,060 PSI) | Main control valve | 1,300 rpm | Elevation (Up) Telescope (In) Boom rotation | Gauge 4 |
| P6 | 90 ~ 95 kg / cm ² (1,280 ~ 1,350 PSI) | Main control valve | 1,300 rpm | Telescope (Out) | Gauge 4 |
| P7 | 150 ~ 155 kg / cm ² (2,130 ~ 2,200 PSI) | Main control valve | 1,300 rpm | Elevation (Down) | Gauge 4 |
| P10 | 140 ~ 145 kg / cm ² (1,990 ~ 2,060 PSI) | Unit valve | 1,300 rpm | Platform rotation Platform level adjust Fly jib, Steering | Gauge 4 |



Pressure measurement procedures

- (1) Set the machine on firm and level surface.
- (2) Warm up the engine.
- (3) Operate the machine to warm up the hydraulic system.
- (4) Measure the pre- set pressure of the relief valves P1 and P2 as follows.
 1. Set up the wheel chocks in front and rear of all tires.



2. Retract the boom fully and lower it under the horizontal.
3. Set the travel speed select switch to its High speed position.
4. Operate the Travel joystick controller to Forward direction to activate the relief valve P1.
5. Read the pressure gauge (Gauge 1) and make sure that the pre- set pressure of the relief valve (P1) is within the specific value.
Specific pre-set pressure ---- 340 ~ 350 kg/cm² (4,840 ~ 4,980 PSI)
6. Operate the Travel joystick controller to Reverse direction to activate the relief valve P2.
7. Read the pressure gauge (Gauge 2) and make sure that the pre- set pressure of the relief valve (P2) is within the specific value.
Specific pre-set pressure ---- 340 ~ 350 kg/cm² (4,840 ~ 4,980 PSI)

(5) Measure the pre-set pressure of the relief valve P4 as follows.

1. Retract the boom fully.
2. Disconnect the connector CM2 from the Main CPU box (M2-A).
See the page 4- 2 for the location of the connector CM2.
3. Turn the engine key switch to its "Lower control" position and make sure that the system failure LED blinks.
See the page 4- 13 for the location of the system failure LED.
4. Start the engine with the engine key switch.
5. Hold the limit cancel switch in its ON position, and operate the boom telescope switch to IN position to activate the relief valve (P4).
See the page 4- 13 for the location of the limit cancel switch.
6. Read the pressure gauge (Gauge 4) and make sure that the pre- set pressure of the relief valve (P4) is within the specific value.

Specific pre- set pressure ---- $210 \sim 215 \text{ kg / cm}^2$ (2,990 ~ 3,060 PSI)

CAUTION : Do not extend the outreach of the platform when operating the machine using the limit cancel switch.

Because, the safety system does not work and the machine may tip over.

(6) Measure the pre- set pressure of the relief valve P6 as follows.

1. Raise the boom fully and extend it fully.
2. Disconnect the connector CM2 from the Main CPU box (M2-A).
See the page 4- 2 for the location of the connector CM2.
3. Turn the engine key switch to its "Lower control" position and make sure that the system failure LED blinks.
See the page 4- 13 for the location of the system failure LED.
4. Start the engine with the engine key switch.
5. Hold the limit cancel switch in its ON position, and operate the boom telescope switch to OUT position to activate the relief valve (P6).
See the page 4- 13 for the location of the limit cancel switch.
6. Read the pressure gauge (Gauge 4) and make sure that the pre- set pressure of the relief valve (P6) is within the specific value.

Specific pre- set pressure ---- $90 \sim 95 \text{ kg / cm}^2$ (1,280 ~ 1,350 PSI)

CAUTION : Do not extend the outreach of the platform when operating the machine using the limit cancel switch.

Because, the safety system does not work and the machine may tip over.

(7) Measure the pre- set pressure of the P7 as follows.

1. Retract and lower the boom fully.
2. Disconnect the connector CM2 from the Main CPU box (M2-A).
See the page 4- 2 for the location of the connector CM2.
3. Turn the engine key switch to its "Lower control" position and make sure that the system failure LED blinks.
See the page 4- 13 for the location of the system failure LED.
4. Start the engine with the engine key switch.
5. Hold the limit cancel switch in its ON position, and operate the boom elevation switch to DOWN position to activate the relief valve (P7).
See the page 4- 13 for the location of the limit cancel switch.
6. Read the pressure gauge (Gauge 4) and make sure that the pre- set pressure of the relief valve (P7) is within the specific value.

Specific pre- set pressure ---- $150 \sim 155 \text{ kg / cm}^2$ (2,130 ~ 2,200 PSI)

CAUTION : Do not extend the outreach of the platform when operating the machine using the limit cancel switch.






Because, the safety system does not work and the machine may tip over.

- (8) Measure the pre- set pressure of the relief valve P10 as follows.
1. Rotate the platform fully to C.W or C.C.W, then hold the platform rotation switch either in C.W or C.C.W position.
 2. Read the pressure gauge (Gauge 4) and make sure that the pre- set pressure of the relief valve (P10) is within the specific value.
- Specific pre- set pressure ---- 140 ~ 145 kg / cm² (1,990 ~ 2,060 PSI)

Pressure adjustment procedures

Adjust the relief valve as follows, if the pre- set pressure is not within the specific value.

- (1) Loosen the lock nut.
- (2) Adjust the pre- set pressure by turning the adjusting screw.
To increase the pressure, turn the adjusting screw clockwise.
To decrease the pressure, turn the adjusting screw counter- clockwise.
- (3) Lock the adjusting screw by the lock nut, and then check the pre- set pressure again and make sure that the pressure is within the specific value.




* See the pages 7- 13 to 7- 15 for the location of these hydraulic components.


7. Appendix

Hydraulic circuit diagram 1/2

601-00052-00



Hydraulic circuit diagram 2/2



Hydraulic oil temperature: 40 +/- 10 deg C.


Relief valve pre-set pressure












| Relief valve | Pre-set pressure | | | Pump speed (rpm) |
|--------------|------------------------------------|---------------------------------|------------------------------------|------------------|
| | MPa | Kg/cm ² | PSI | |
| P1 | 33.3 ^{+0.98} ₀ | 340 ⁺¹⁰ ₀ | 4,830 ⁺¹⁴⁰ ₀ | 2,200 |
| P2 | 33.3 ^{+0.98} ₀ | 340 ⁺¹⁰ ₀ | 4,830 ⁺¹⁴⁰ ₀ | 2,200 |
| P3 | 2.0 ^{+0.49} ₀ | 20 ⁺⁵ ₀ | 290 ⁺⁷⁰ ₀ | 1,300 |
| P4 | 20.6 ^{+0.49} ₀ | 210 ⁺⁵ ₀ | 3,000 ⁺⁷⁰ ₀ | 2,200 |
| P6 | 8.8 ^{+0.49} ₀ | 90 ⁺⁵ ₀ | 1,280 ⁺⁷⁰ ₀ | 2,200 |
| P7 | 14.7 ^{+0.49} ₀ | 150 ⁺⁵ ₀ | 2,130 ⁺⁷⁰ ₀ | Do not adjust |
| P8 | 22.5 ^{+0.88} ₀ | 230 ⁺⁹ ₀ | 3,260 ⁺¹³⁰ ₀ | Do not adjust |
| P9 | 22.5 ^{+0.88} ₀ | 230 ⁺⁹ ₀ | 3,260 ⁺¹³⁰ ₀ | Do not adjust |
| P10 | 13.7 ^{+0.49} ₀ | 140 ⁺⁵ ₀ | 2,000 ⁺⁷⁰ ₀ | 1,300 |
| P11 | 14.7 ^{+0.88} ₀ | 150 ⁺⁹ ₀ | 2,130 ⁺¹³⁰ ₀ | Do not adjust |
| P12 | 14.7 ^{+0.88} ₀ | 150 ⁺⁹ ₀ | 2,130 ⁺¹³⁰ ₀ | Do not adjust |
| P14 | 13.7 ^{+0.49} ₀ | 140 ⁺⁵ ₀ | 2,000 ⁺⁷⁰ ₀ | Do not adjust |
| P15 | 20.6 ^{+2.0} ₀ | 210 ⁺²⁰ ₀ | 3,000 ⁺²⁹⁰ ₀ | Do not adjust |
| P16 | 20.6 ^{+2.0} ₀ | 210 ⁺²⁰ ₀ | 3,000 ⁺²⁹⁰ ₀ | Do not adjust |




Electric circuit diagram, Turntable 1/2

602-00718-00






Electrical wiring chart, Platform




Electrical wiring chart, Turntable 1/2


7C1-00729-00



Electrical wiring chart, Turntable 2/2




7C1-00729-00






| No. | Descriptions | Qty | Part number | No | Descriptions | Qty | Part number |
|-----|--------------------------------|-----|----------------|----|--------------------------|-----|----------------|
| 1 | Oscillation axle lock cylinder | 2 | 303- 00086- 00 | 6 | Inline check valve | 1 | 302- 02839 |
| 2 | Lock valve | 2 | 302- 00101- 00 | 7 | Double pilot check valve | 1 | 302- 02898 |
| 3 | Travel motor | 4 | 301- 00000- 35 | 8 | Flow divider valve | 2 | 302- 00105- 00 |
| 4 | Steering cylinder | 2 | 303- 00085- 00 | 9 | Flow divider valve | 1 | 302- 00104- 00 |
| 5 | Swivel joint | 1 | 307- 00000- 38 | 10 | Shuttle valve | 1 | 302-00169- 00 |

Locations of Hydraulic and Electrical components (2/3)



| No. | Descriptions | Part number | Qty | Remarks |
|-----|---|----------------|-----|---|
| 1 | Oil reservoir | 378- 00001- 63 | 1 | Suction strainer (305- 06597) is incorporated in the oil reservoir. |
| 2 | Hydraulic pump | 300- 00000- 43 | 1 | |
| 3 | Emergency pump | 300- 01808 | 1 | |
| 4 | High- pressure line filter | 305- 00000- 18 | 1 | |
| 5 | High- pressure line filter | 305- 00000- 09 | 1 | |
| 6 | Check valve block | 302- 00041- 00 | 1 | |
| 7 | Main control valve | 302- 00103- 00 | 1 | Last chance filter (305- 00000- 04) is installed at the P port of the Main control valve. |
| 8 | Flow priority valve | 302- 00071- 00 | 1 | |
| 9 | Unit valve | 302- 00149- 00 | 1 | |
| 10 | Boom rotation motor | 301- 00000- 22 | 1 | |
| 11 | Combination valve | 302- 00000- 09 | 1 | |
| 12 | Oscillation axle release solenoid valve | 302- 00090- 00 | 1 | |
| 13 | Parking brake release solenoid valve | 302- 00090- 00 | 1 | |
| 14 | Travel speed select solenoid valve | 302- 00090- 00 | 1 | |
| 15 | Single pilot check valve | 302- 00000- 67 | 1 | |
| 16 | Lower control box | 329- 00135- 00 | 1 | |
| 17 | Main CPU box (M2A) | 329- 00001- 51 | 1 | |
| 18 | Engine control box | 329- 00925- 00 | 1 | |
| 19 | Horn | 5C1- 01668- 00 | 1 | |
| 20 | Motion alarm buzzer | 324- 00023- 00 | 1 | |
| 21 | Tilt sensor | 382- 00016- 00 | 2 | |
| 22 | Oscillation axle release limit switch | 320- 00025- 00 | 1 | |
| 23 | Battery | 378- 00443 | 2 | |

Locations of Hydraulic and Electrical components



| No. | Descriptions | Part number | Qty | Remarks |
|-----|--|----------------|-----|---------------------------------------|
| 1 | Boom telescope cylinder | 303- 00114- 00 | 1 | For SP18A / ISP60 |
| | | 303- 00108- 00 | 1 | For SP21A / ISP70 and SP21AJ / ISP70J |
| 2 | Boom elevation cylinder | 303- 00058- 00 | 1 | |
| 3 | Single holding valve | 302- 00109- 00 | 1 | |
| 4 | Lower leveling cylinder | 303- 00053- 00 | 1 | For SP18A / ISP60 and SP21A / ISP70 |
| | | 303- 00062- 00 | 1 | For SP21AJ / ISP70J |
| 5 | Upper leveling cylinder | 303- 00052- 00 | 1 | For SP18A / ISP60 and SP21A / ISP70 |
| | | 303- 00023-00 | 1 | For SP21AJ / ISP70J |
| 6 | Rotary actuator | 407- 00002- 84 | 1 | |
| 7 | Platform rotation solenoid valve | 302- 00153- 00 | 1 | For SP18A / ISP60 and SP21A / ISP70 |
| | Platform rotation / Fly-jib solenoid valve | 302- 00152- 00 | 1 | For SP21AJ / ISP70J |
| 8 | Boom length sensor (R/H) | 382- 00033- 00 | 1 | |
| 9 | Boom length sensor (L/H) | 382- 00033- 01 | 1 | For CE model |
| 10 | Boom angle sensor (R/H) | 382- 00017- 00 | 1 | |
| 11 | Boom angle sensor (L/H) | 382- 00017- 00 | 1 | For CE model |
| 12 | Boom wire rope failure limit switch | 320- 00025- 00 | 2 | |
| 13 | Overload sensing limit switch | 320- 00025- 01 | 1 | For CE model |
| 14 | Upper control box | ----- | 1 | |
| 15 | Foot switch | 320- 04017 | 1 | |
| 16 | Boom length limit switch | 320- 00058- 00 | 1 | |
| 17 | Fly-jib cylinder | 303- 00016- 00 | 1 | For SP21AJ / ISP70J |
| 18 | Double holding valve | 302- 00020- 00 | 1 | For SP21AJ / ISP70J |
| | | 302- 00021- 00 | 2 | For SP21AJ / ISP70J |

Water- proof connectors

1. Water- proof connectors

Female housing

| Number of pole | Color | Part number |
|----------------|--------|-------------|
| 2 poles | White | 192-21102 |
| | Gray | 192-21202 |
| | Green | 192-21302 |
| | Blue | 192-21402 |
| | Brown | 192-21502 |
| | Yellow | 192-21602 |
| 4 poles | White | 192-21104 |
| | Gray | 192-21204 |
| | Green | 192-21304 |
| | Blue | 192-21404 |
| | Brown | 192-21504 |
| | Yellow | 192-21604 |
| 6 poles | White | 192-21106 |
| | Gray | 192-21206 |
| | Green | 192-21306 |
| | Blue | 192-21406 |
| | Brown | 192-21506 |
| | Yellow | 192-21606 |
| 8 poles | White | 192-21108 |
| | Gray | 192-21208 |
| | Green | 192-21308 |
| | Blue | 192-21408 |
| | Brown | 192-21508 |
| | Yellow | 192-21608 |
| 12 poles | White | 192-21112 |
| | Gray | 192-21212 |
| | Green | 192-21312 |

Male housing


| Number of pole | Color | Part number |
|----------------|--------|-------------|
| 2 poles | White | 192-22102 |
| | Gray | 192-22202 |
| | Green | 192-22302 |
| | Blue | 192-22402 |
| | Brown | 192-22502 |
| | Yellow | 192-22602 |
| 4 poles | White | 192-22104 |
| | Gray | 192-22204 |
| | Green | 192-22304 |
| | Blue | 192-22404 |
| | Brown | 192-22504 |
| | Yellow | 192-22604 |
| 6 poles | White | 192-22106 |
| | Gray | 192-22206 |
| | Green | 192-22306 |
| | Blue | 192-22406 |
| | Brown | 192-22506 |
| | Yellow | 192-22606 |
| 8 poles | White | 192-22108 |
| | Gray | 192-22208 |
| | Green | 192-22308 |
| | Blue | 192-22408 |
| | Brown | 192-22508 |
| | Yellow | 192-22608 |
| 12 poles | White | 192-22112 |
| | Gray | 192-22212 |
| | Green | 192-22312 |

Male housing (with Flange)

| Number of pole | Color | Part number |
|----------------|--------|-------------|
| 4 poles | White | 192-24104 |
| | Gray | 192-24204 |
| | Green | 192-24304 |
| | Blue | 192-24404 |
| | Brown | 192-24504 |
| | Yellow | 192-24604 |
| 6 poles | White | 192-24106 |
| | Gray | 192-24206 |
| | Green | 192-24306 |
| | Blue | 192-24406 |
| | Brown | 192-24506 |
| | Yellow | 192-24606 |
| 8 poles | White | 192-24108 |
| | Gray | 192-24208 |
| | Green | 192-24308 |
| | Blue | 192-24408 |
| | Brown | 192-24508 |
| | Yellow | 192-24608 |
| 12 poles | White | 192-24112 |
| | Gray | 192-24212 |
| | Green | 192-24312 |


Others

| Description | Part number | Remarks |
|-------------------|-------------|---------------------------------|
| Terminal (Female) | 327-03607 | |
| Terminal (Male) | 327-03608 | |
| Grommet S (Blue) | 327-03660 | for wire diameter: 1.5 ~ 2.0 mm |
| Grommet M (Brown) | 327-03609 | for wire diameter: 2.0 ~ 2.9 mm |
| Dummy plug | 327-03663 | |



Terminal crimping tool

Part #: MZ99- 9259



2. Pin arrangements of Water- proof connectors

See the table below to specify the pin arrangements of water- proof connectors when reading “Electrical wiring diagrams”.

| | A view (Male connector) | Symbol | B view (Female connector) |
|----------|----------------------------|--------|------------------------------|
| 2 poles | | | |
| 3 poles | | | |
| 4 poles | | | |
| 6 poles | | | |
| 8 poles | | | |
| 12 poles | | | |

Color code of wires

See the table below to specify the colors of wires from the “Color codes”.

| No. | Color code | Color | No. | Color codes | Color |
|-----|------------|---------------|-----|-------------|--------------------|
| 1 | R | Red | 31 | GY | Green/ Yellow |
| 2 | Y | Yellow | 32 | GW | Green/ White |
| 3 | W | White | 33 | GB | Green/ Black |
| 4 | G | Green | 34 | GO | Green/ Orange |
| 5 | L | Blue | 35 | LR | Blue/ Red |
| 6 | B | Black | 36 | LY | Blue/ Yellow |
| 7 | V | Violet | 37 | LW | Blue/ White |
| 8 | P | Pink | 38 | LG | Blue/ Green |
| 9 | O | Orange | 39 | LB | Blue/ Black |
| 10 | Br | Brown | 40 | LO | Blue/ Orange |
| 11 | Lg | Light green | 41 | BR | Black/ Red |
| 12 | Lb | Light blue | 42 | BY | Black/ Yellow |
| 13 | Gy | Gray | 43 | BW | Black/ White |
| 14 | RY | Red/ Yellow | 44 | BG | Black/ Green |
| 15 | RW | Red/ White | 45 | BL | Black/ Blue |
| 16 | RG | Red/ Green | 46 | PY | Pink/ Yellow |
| 17 | RL | Red/ Blue | 47 | PL | Pink/ Blue |
| 18 | RB | Red/ Black | 48 | PB | Pink/ Black |
| 19 | YR | Yellow/ Red | 49 | OW | Orange/ White |
| 20 | YW | Yellow/ White | 50 | OB | Orange/ Black |
| 21 | YG | Yellow/ Green | 51 | BrR | Brown/ Red |
| 22 | YL | Yellow/ Blue | 52 | BrY | Brown/ Yellow |
| 23 | YB | Yellow/ Black | 53 | BrW | Brown/ White |
| 24 | WR | White/ Red | 54 | BrB | Brown/ Black |
| 25 | WY | White/ Yellow | 55 | LgR | Light green/ Red |
| 26 | WG | White/ Green | 56 | LgW | Light green/ White |
| 27 | WL | White/ Blue | 57 | LgB | Light green/ Black |
| 28 | WB | White/ Black | 58 | GyR | Gray/ Red |
| 29 | WBr | White/ Brown | 59 | GyB | Gray/ Black |
| 30 | GR | Green/ Red | | | |

Tightening torque standard

1. Hexagon headed bolts (8T or 8.8T) and nuts (6T)

| | | |
|------------------|-----------------------|-----------------------|
| | Bolt | Nut |
| Strength grade | 8T or 8.8T | 6T |
| Material | S45C | S45C |
| Tensile strength | 80 kg/cm ² | 80 kg/cm ² |

| Size (mm) | Pitch (mm) | Tightening torque | | |
|--------------|---------------|-------------------|--------------|-------------|
| | | N-m | kg-m | ft-lbs |
| 5 | 0.8 | 3.71 ~ 5.87 | 0.32 ~ 0.60 | 2.31 ~ 4.34 |
| 6 | 1.0 | 5.42 ~ 10.0 | 0.56 ~ 1.04 | 4.05 ~ 7.52 |
| 8 | 1.25 | 13.0 ~ 24.2 | 1.33 ~ 2.47 | 9.62 ~ 17.9 |
| 10 | 1.5 | 25.7 ~ 47.6 | 2.59 ~ 4.81 | 18.7 ~ 34.8 |
| 12 | 1.75 | 44.6 ~ 82.7 | 4.55 ~ 8.45 | 32.9 ~ 61.1 |
| 14 | 2.0 | 71.2 ~ 132 | 7.00 ~ 13.00 | 50.6 ~ 94.0 |
| 16 | 2.0 | 109 ~ 201 | 11.2 ~ 20.8 | 81.0 ~ 150 |
| 18 | 2.5 | 157 ~ 291 | 16.1 ~ 29.9 | 116 ~ 216 |
| 20 | 2.5 | 220 ~ 407 | 22.4 ~ 41.6 | 162 ~ 301 |
| 22 | 2.5 | 296 ~ 549 | 30.1 ~ 55.9 | 218 ~ 404 |
| 24 | 3.0 | 379 ~ 703 | 38.5 ~ 71.5 | 278 ~ 517 |

2. Hexagon headed bolts (10.9T) and nuts (8T)

| | | |
|------------------|------------------------|------------------------|
| | Bolt | Nut |
| Strength grade | 10.9T | 8T |
| Material | SCM435 | SCM435 |
| Tensile strength | 100 kg/cm ² | 100 kg/cm ² |

| Size (mm) | Pitch (mm) | Tightening torque | | |
|--------------|---------------|-------------------|--------------|-------------|
| | | N-m | kg-m | ft-lbs |
| 5 | 0.8 | 7.21 ~ 8.79 | 0.73 ~ 0.90 | 5.28 ~ 6.51 |
| 6 | 1.0 | 12.3 ~ 15.1 | 1.26 ~ 1.54 | 9.11 ~ 11.1 |
| 8 | 1.25 | 29.7 ~ 36.2 | 3.06 ~ 3.74 | 22.1 ~ 27.1 |
| 10 | 1.5 | 58.5 ~ 71.3 | 5.94 ~ 7.26 | 43.0 ~ 52.5 |
| 12 | 1.75 | 102 ~ 124 | 9.90 ~ 12.10 | 71.6 ~ 87.5 |
| 14 | 2.0 | 162 ~ 197 | 16.2 ~ 19.8 | 117 ~ 143 |
| 16 | 2.0 | 247 ~ 302 | 25.2 ~ 30.8 | 182 ~ 223 |
| 18 | 2.5 | 364 ~ 422 | 35.1 ~ 42.9 | 254 ~ 310 |
| 20 | 2.5 | 483 ~ 589 | 49.5 ~ 60.5 | 358 ~ 438 |
| 22 | 2.5 | 652 ~ 795 | 66.6 ~ 81.4 | 482 ~ 589 |
| 24 | 3.0 | 835 ~ 1018 | 84.6 ~ 103 | 612 ~ 745 |

3. Hexagon socket headed cap screws (10.9T)

| | |
|------------------|------------------------|
| | Bolt |
| Strength grade | 10.9T |
| Material | SCM435 |
| Tensile strength | 100 kg/cm ² |

| Size (mm) | Pitch (mm) | Tightening torque | | |
|--------------|---------------|-------------------|-------------|-------------|
| | | N-m | kg-m | ft-lbs |
| 5 | 0.8 | 4.81 ~ 5.87 | 0.49 ~ 0.60 | 3.54 ~ 4.34 |
| 6 | 1.0 | 8.24 ~ 10.0 | 0.81 ~ 0.99 | 5.86 ~ 7.16 |
| 8 | 1.25 | 19.8 ~ 24.2 | 2.07 ~ 2.53 | 15.0 ~ 18.3 |
| 10 | 1.5 | 39.0 ~ 47.6 | 3.96 ~ 4.84 | 28.6 ~ 35.0 |
| 12 | 1.75 | 67.8 ~ 82.7 | 6.93 ~ 8.47 | 50.1 ~ 61.3 |
| 14 | 2.0 | 108 ~ 132 | 10.8 ~ 13.2 | 78.1 ~ 95.5 |
| 16 | 2.0 | 165 ~ 201 | 17.1 ~ 20.9 | 124 ~ 151 |
| 18 | 2.5 | 239 ~ 291 | 24.3 ~ 29.7 | 176 ~ 215 |
| 20 | 2.5 | 333 ~ 407 | 34.2 ~ 41.8 | 247 ~ 302 |
| 22 | 2.5 | 450 ~ 549 | 45.9 ~ 56.1 | 332 ~ 406 |
| 24 | 3.0 | 576 ~ 703 | 58.5 ~ 71.5 | 423 ~ 517 |

8. *Inspection manual*

All of the inspection and test results should be recorded in the inspection check sheets and should be kept for three years.

The qualified personnel should perform the inspections and the tests.

Procedures of Daily inspections

The daily inspections should be conducted with the machine being set on firm and level ground.

| <i>Unit</i> | <i>Item</i> | <i>Descriptions</i> |
|-------------------------|---|---|
| Engine | Cooling system | Check the coolant level and replenish the coolant, if necessary. |
| | | Check the cooling system for water leakage. |
| | | Check the fan belt for wear and tension. |
| | Lubrication system | Check the engine oil level and replenish the oil, if necessary. |
| | | Check the engine for oil leakage. |
| | Fuel system | Check the fuel level and replenish the fuel, if necessary. |
| | | Check the fuel system for fuel leakage. |
| Battery | Electrolyte | Check the electrolyte level and replenish the distilled water, if necessary. |
| | Terminals | Check the battery terminals for looseness |
| Hydraulic oil reservoir | Oil level | Stow the boom and axles, then check for hydraulic oil level and replenish the oil, if necessary. |
| | Oil leakage | Check the oil reservoir for oil leakage. |
| Chassis | Chassis frame | Check the chassis frame for deformations and cracks. |
| | Tires | Check the tires for wear, cuts and air pressure. |
| | Wheel bolts and nuts. | Check the bolts and nuts for looseness. |
| | Travel motor and gearbox | Check the travel motor and gearbox for oil leakage. |
| | Axle | Check the axle for deformations and cracks. |
| | Oscillation axle lock cylinder | Check the cylinder for oil leakage. |
| | Steering linkages | Check the steering linkages for deformations, cracks and excessive free play. |
| | Steering cylinder | Check the cylinder for oil leakage. |
| | Track links, shoes | Check the track links and shoes for wear and tension. |
| Turntable | Crack, deformation | Check the turntable for cracks and deformations. |
| | Abnormal noise, movements | Rotate the turntable, and check for any abnormal noise and movements. |
| Boom, Fly jib | Crack, deformation | Extend the boom fully and check each boom section and the fly jib for cracks and deformations. |
| | Boom and Fly jib pivot pins | Check the pivot pins for any damage. |
| | Abnormal noise, movements | Raise, lower, telescope the boom and the fly jib and check for any abnormal noise and movements. |
| | Oil leakage | Check the hydraulic cylinders for oil leakage. |
| | Natural descent | Elevate the platform and check if the elevation, telescope and fly jib cylinders retract or extend naturally. |
| Platform | Crack, deformation | Check the platform and the platform rotation device for cracks and deformations. |
| | Abnormal noise, movements | Rotate the platform and check for any abnormal noise and movements. |
| | Oil leakage | Check the platform levelling cylinders and the platform rotation motor for oil leakage. |
| | Platform levelling system | Raise and lower the boom several times and check if the platform stays level. |
| Safety devices. | Emergency stop system | Start the engine, then, operate the emergency stop switch and make sure that the engine stops and all of the functions are disabled. |
| | Emergency pump | Shut down the engine, then operate the machine using the emergency pump and make sure that the machine moves properly. |
| | Work range limit system, Moment limiter | For the machine equipped with the pre-start check switch, conduct the pre-start check and make sure that no failure is in the system. |
| | Foot switch | Operate the machine from the platform and make sure that the functions are disabled unless the foot switch is pressed down. |

| <i>Unit</i> | <i>Item</i> | <i>Descriptions</i> |
|--------------------|----------------------|--|
| Safety devices | Tilt alarm buzzer | Turn on the main key switch and make sure that the tilt alarm buzzer sounds just after turning on the main key switch. |
| | Motion alarm buzzer | Operate the machine and make sure that the motion alarm buzzer sounds while the machine is in motion. |
| | Alarm horn | Press the horn switch on the platform and make sure that the alarm horn sounds. |
| | Other safety devices | Check the functions of other safety devices, if any. |
| Decals | Readability | Check the decals for readability and replace the decals, if necessary. |

Daily inspection check sheet

| <i>Unit</i> | <i>Item</i> | | <i>Results</i> | | | | | | | | | | | | | | | |
|---|---|--------------------------------|----------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Date → | | | | | | | | | | | | | | | | | | |
| Engine | Cooling system | Coolant level | | | | | | | | | | | | | | | | |
| | | Water leakage | | | | | | | | | | | | | | | | |
| | | Fan belt | | | | | | | | | | | | | | | | |
| | Lubrication system | Oil level | | | | | | | | | | | | | | | | |
| | | Oil leakage | | | | | | | | | | | | | | | | |
| | Fuel system | Fuel level | | | | | | | | | | | | | | | | |
| Fuel leakage | | | | | | | | | | | | | | | | | | |
| Battery | Electrolyte level | | | | | | | | | | | | | | | | | |
| | Battery terminals | | | | | | | | | | | | | | | | | |
| Hydraulic oil reservoir | Oil level | | | | | | | | | | | | | | | | | |
| | Oil leakage | | | | | | | | | | | | | | | | | |
| Chassis | Chassis frame | Cracks, deformations | | | | | | | | | | | | | | | | |
| | Tires | Wear, cuts, Air pressure | | | | | | | | | | | | | | | | |
| | Wheel bolts, nuts | Looseness | | | | | | | | | | | | | | | | |
| | Travel motor, gearbox | Oil leakage | | | | | | | | | | | | | | | | |
| | Axle | Cracks, deformations | | | | | | | | | | | | | | | | |
| | Oscillation axle lock cylinder | Oil leakage | | | | | | | | | | | | | | | | |
| | Steering linkages | Cracks, deformations free play | | | | | | | | | | | | | | | | |
| | Steering cylinder | Oil leakage | | | | | | | | | | | | | | | | |
| | Track links, shoes | Wear, tension | | | | | | | | | | | | | | | | |
| | Turntable | Crack, deformation | | | | | | | | | | | | | | | | |
| Abnormal noise, movements | | | | | | | | | | | | | | | | | | |
| Boom, Fly jib | Cracks, deformations | | | | | | | | | | | | | | | | | |
| | Pivot pins | Damage | | | | | | | | | | | | | | | | |
| | Abnormal noise, movements | | | | | | | | | | | | | | | | | |
| | Oil leakage | | | | | | | | | | | | | | | | | |
| | Elevation cylinder | Natural descent | | | | | | | | | | | | | | | | |
| | Telescope cylinder | Natural descent | | | | | | | | | | | | | | | | |
| | Fly jib cylinder | Natural descent | | | | | | | | | | | | | | | | |
| Platform | Crack, deformation | | | | | | | | | | | | | | | | | |
| | Abnormal noise, movements | | | | | | | | | | | | | | | | | |
| | Oil leakage | | | | | | | | | | | | | | | | | |
| | Platform levelling system | Functions | | | | | | | | | | | | | | | | |
| Safety devices | Emergency stop system | | Functions | | | | | | | | | | | | | | | |
| | Emergency pump | | Functions | | | | | | | | | | | | | | | |
| | Work range limit system, Moment limiter | | Functions | | | | | | | | | | | | | | | |
| | Foot switch | | Functions | | | | | | | | | | | | | | | |
| | Tilt alarm buzzer | | Functions | | | | | | | | | | | | | | | |
| | Motion alarm buzzer | | Functions | | | | | | | | | | | | | | | |
| | Alarm horn | | Functions | | | | | | | | | | | | | | | |
| | Other safety devices | | Functions | | | | | | | | | | | | | | | |
| Decals | Readability | | | | | | | | | | | | | | | | | |
| Remarks | | | | | | | | | | | | | | | | | | |

Procedures of Periodical inspections

Conduct the periodical inspection with the machine being set on firm and level surface.

Carry out the both descriptions of the monthly and annual inspections when conducting the annual inspections.

| <i>Unit</i> | <i>Item</i> | <i>Monthly inspections</i> | <i>Annual inspections</i> |
|-------------------------|------------------------------|---|--|
| Engine | Engine oil | Check the engine oil and replenish or change the oil, if necessary. | Change the engine oil. Oil change interval: 200 hours. |
| | Oil filter | Check the oil filter and replace the filter element, if necessary. | Replace the oil filter element. Replacement interval: 400 hours. |
| | Oil leakage | Check the engine for oil leakage. | |
| | Coolant | Check the coolant and replenish or change the coolant, if necessary. | |
| | Water leakage | Check the engine for water leakage | |
| | Fan belt | Check the fan belt for wear and tension. | |
| | Radiator hose | Check the radiator hose for any damage. | |
| | Air filter | Check the air filter and clean or replace the filter element, if necessary. | |
| | Fuel filter | Check the fuel filter and replace the filter element, if necessary. | Replace the fuel filter element. Replacement interval: 600 hours. |
| | Bolts and nuts | Check each bolt and nut for looseness | |
| | Fuel leakage | Check the fuel system for fuel leakage. | |
| | Abnormal noise, performances | Operate the machine and check for abnormal noise and performances. | |
| Battery | Electrolyte | Check the electrolyte level and replenish with distilled water, if necessary. | |
| | Battery terminals | Check the battery terminals for corrosion and looseness. | |
| Hydraulic oil reservoir | Oil level, contamination. | Check the oil level and replenish, if necessary. | Change the hydraulic oil. Oil change interval: 1,200 hours or one year. |
| | Oil leakage. | Check the oil reservoir for oil leakage | |
| Hydraulic filters | Oil leakage. | Check the hydraulic filter for oil leakage. | |
| | Replacement | | Replace the oil filter element. Replacement interval: 1,200 hours or one year. |
| Hydraulic pump | Bolts and nuts | Check the pump mounting bolts and nuts for looseness. | |
| | Abnormal noise | Operate the machine and check the pump for abnormal noise. | |
| | Oil leakage | Check the pump for oil leakage. | |
| Chassis frame | Cracks, deformations | Check the chassis frame for cracks and deformations. | |
| | Counter weight | Check the counter weight anchor bolts, nuts for looseness. | |
| Tires and wheels | Wear, cuts | Check the tire for wear and cuts. | |
| | Air pressure | Check the tires for air pressure | |
| | Clip bolts, nuts | Check the wheel clip bolts and nuts for looseness. | |

| <i>Unit</i> | <i>Item</i> | <i>Monthly inspections</i> | <i>Annual inspections</i> |
|--------------------------------|--------------------------------|--|---|
| Axles | Cracks, deformations | Check the axles for cracks and deformations. | |
| Oscillation axle lock cylinder | Oil leakage | Check the cylinder for oil leakage. | |
| | Functions | Check the oscillation axle lock cylinder if the cylinder locks and releases in the specific machine status | |
| Travel motor and gearbox | Gear oil | Check the gearbox for oil level and replenish the gear oil, if necessary. | Change the gear oil. Oil change interval: 1,200 hours or 12 months. |
| | Oil leakage | Check the motor and the gearbox for oil leakage. | |
| | Abnormal noise | Travel the machine and check for abnormal noise. | |
| Steering mechanism | Lubrication | Supply grease through each grease fitting. | |
| | Cracks, deformations | Check the steering linkages for cracks and deformations. | |
| | Wheel bearings | | Jack up the machine and check the wheel bearings for free play and any damages. |
| Steering cylinder | Oil leakage | Check the steering cylinder for oil leakage. | |
| | Functions | Operate the steering switch and check for the functions. | |
| Jack cylinder | Oil leakage | Check the jack cylinder for oil leakage. | |
| | Natural descent | Extend the jack cylinder, support the machine by the jack cylinder, and then check the jack cylinders for natural descent. Serviceable limit: 1 mm (0.04 in)/10 min. | |
| Crawler | Track links | Check the track links for wear and tension. | |
| | Track shoes | Check the track shoes for wear and deformations. | |
| | Track rollers, Carrier rollers | Check the track and carrier rollers for wear and oil leakage. | |
| | Sprockets, Idler wheels | Check the sprockets and the idler wheels for wear and cracks. | |
| Rotation bearing | Bolts and nuts | Check each anchor bolt and nut for looseness. | |
| | Wear, cracks | Check the rotation bearing for wear and cracks. | |
| | Lubrication | Check for lubrication. | |
| Rotation gear box | Bolts and nuts | Check each anchor bolt and nut for looseness. | |
| | Oil leakage | Check the gearbox for oil leakage. | |
| | Gear oil | Check the gear oil and replenish, if necessary. | Change gear oil. Oil change interval: 1,200 hours or one year. |
| | Back-lash | | Check the backlash between the pinion of the rotation gearbox and the ring gear of the rotation bearing. Standard back-lash: 0.6 mm (0.024 in) |
| | Abnormal noise | Rotate the turntable and check for abnormal noise. | |

| <i>Unit</i> | <i>Item</i> | <i>Monthly inspections</i> | <i>Annual inspections</i> |
|---|--|---|---|
| Turntable | Cracks, deformations | Check the turntable for cracks and deformations. | |
| | Bolts and nuts | Check each bolt and nut for looseness. | |
| Swivel joint | Bolts and nuts | Check each bolt and nut for looseness. | |
| | Oil leakage | Check for oil leakage. | |
| | Lubrication | Check for lubrication. | |
| Boom Fly jib | Cracks, deformations | Extend the boom and check each boom section and the fly jib for cracks and deformations. | |
| | Pivot pins | Check the boom and fly jib pivot pins for any damage. | |
| | Bolts and nuts | Check each bolt and nut for looseness. | |
| | Oil leakage | Check for oil leakage. | |
| | Lubrication | Check for lubrication and lubricate, if necessary. | |
| | Extension/retraction wire ropes | Check each wire rope for tension and any damage. | Disassemble the boom and check each wire rope thoroughly every 4 years. |
| | Electric cables and hydraulic hoses. | | Check each electric cable and hydraulic hose if proper tension is applied to. |
| | Wear pads | | Check each wear pad for wear. |
| | Abnormal noise, movement | Raise, lower, telescope the boom and the fly jib and check for abnormal noise and movements. | |
| Elevation, Telescope, Fly jib cylinders | Oil leakage | Check the cylinders for oil leakage. | |
| | Natural descent | Check the elevation, telescope and fly jib cylinders for natural descent. Serviceable limit: 2 mm (0.08 in)/10 min. | |
| Platform | Cracks, deformation | Check the platform and its mounting bracket for cracks and deformations. | |
| | Bolts and nuts | Check each bolt and nut for looseness. | |
| | Rotation motor, Rotary actuator | Check for oil leakage. | |
| | | Rotate the platform and check for abnormal noise and movements. | |
| | Lubrication | Check the rotation worm gear and bushings for lubrication. | |
| Platform levelling system | Levelling cylinders | Check each levelling cylinder for oil leakage. | |
| | Function | Operate the boom and make sure that the platform stays level. | |
| Control panels | Joystick controllers, Control switches | Check each joystick controller and control switch for any damage. | |
| | | Operate each joystick controller and control switch and check for the functions | |
| | Indicator lights | Check each indicator lights for any damage | |
| | | Check each indicator lights for its functions. | |

| <i>Unit</i> | <i>Item</i> | <i>Monthly inspections</i> | <i>Annual inspections</i> |
|----------------|---|--|---|
| Safety devices | Emergency stop system | Start the engine, operate the emergency stop switches and make sure that engine stops and all of the functions are disabled. | |
| | Emergency pump | Shut down the engine, operate the machine using the emergency pump and make sure that the machine moves properly. | |
| | Moment limiter Work range limit system | Operate the boom and make sure that the moment limiter works properly. | Measure each work radius of the platform and make sure that the work radius is within the specific range. |
| | Pre-start check system | Conduct the pre-start check by using the pre-start check switch and make sure that no failure is in the system | |
| | Foot switch | Operate the machine from the platform and make sure that the functions are disabled unless the foot switch is pressed down. | |
| | Tilt alarm buzzer | Turn on the main key switch and make sure that the tilt alarm buzzer sounds just after turning on the key switch. | |
| | Motion alarm buzzer | Operate the machine and make sure that the motion alarm buzzer sounds while the machine is in motion. | |
| | Alarm horn | Press the horn switch and make sure that the horn sounds. | |
| | Overload sensing system | Overload the platform and make sure that the functions are disabled and the overload alarm buzzer sounds. | |
| | Other safety devices | Check the functions of other safety devices and make sure that they work properly. | |
| Decals | Readability | Check each decal for readability and replace the decal, if necessary. | |

Procedures of Function tests

Conduct the function tests annually or in accordance with local regulations.

Set the machine on firm and level surface when conducting function tests.

| <i>Test</i> | <i>Item</i> | <i>Descriptions</i> |
|----------------------|--|--|
| Load test | Damage, function, Abnormal noise | <ol style="list-style-type: none"> 1. Load the platform with 110% of the rated load, operate the boom and the fly jib thoroughly from the lower control and make sure that the boom and the fly jib moves smoothly without any abnormal noise. Caution: Do not allow any person on the platform. 2. Check the machine thoroughly and make sure that no damage is on the machine. |
| Natural descent test | Elevation, Telescope and Fly jib cylinders | <ol style="list-style-type: none"> 1. Set the boom and the fly jib to the positions specified in the hydraulic section of this service manual to load the cylinders with the gravity of the boom and the platform. 2. Stop the engine and leave the machine in the above status for 10 minutes. 3. Measure the natural descent of each cylinder. Serviceable limit: 2 mm (0.08 in) / 10 minutes. Note: See the hydraulic section of this service manual for detail. |
| Speed test | Boom elevation speed | <ol style="list-style-type: none"> 1. Retract the boom fully. 2. Raise and lower the boom to its full stroke, measure the boom rising and the lowering speed (seconds/stroke) and make sure that the speed is within the specific range. |
| | Boom telescope speed | <ol style="list-style-type: none"> 1. Raise the boom fully. 2. Extend and retract the boom to its full stroke, measure the boom extending and the retracting speed (seconds/stroke) and make sure that the speed is within the specific range. |
| | Boom rotation speed | <ol style="list-style-type: none"> 1. Retract and raise the boom fully. 2. Rotate the turntable 360 degrees CW and CCW, measure the rotation speed (seconds/360 degrees) and make sure that the speed is within the specific range. |
| | Fly jib speed | Raise and lower the fly jib to its full stroke, measure the fly jib raising and the lowering speed (seconds/stroke) and make sure that the speed is within the specific range. |
| | Vertical movement speed | Move the platform vertically for the distance of 3 meters (9ft – 10in), measure the platform moving speed and make sure that the speed is within the specific range. |
| | Horizontal movement speed | Move the platform horizontally for the distance of 3 meters (9ft – 10in), measure the platform moving speed and make sure that the speed is within the specific range. |
| | Platform rotation speed | Rotate the platform CW and CCW, measure the platform rotation speed (seconds/stroke), then make sure that the speed is within the specific range. |
| Brake test | Stopping distance | <ol style="list-style-type: none"> 1. Retract the boom fully, and then lower it under the horizontal. 2. Set the travel speed select switch to its “High” position. 3. Drive the machine forward at high speed and then release the joystick controller quickly. 4. Measure the stopping distance, then make sure that the distance is shorter than 3 meters. 5. Test the backward stopping distance in the same way. |

Periodical inspection check sheet

| <i>Model</i> | <i>Spec No.</i> | <i>Serial No.</i> | <i>Hour meter</i> | <i>Date</i> | <i>Inspector</i> |
|--------------|-----------------|-------------------|-------------------|-------------|------------------|
| | | | | | |

The items marked (*) should be inspected annually or in accordance with local regulations.

| <i>Unit</i> | <i>Item</i> | | <i>Results</i> | <i>Remarks</i> |
|--------------------------------|----------------------------------|---------------------------------------|----------------|---|
| Engine | Engine oil | Oil level, contamination, leakage | | Oil change interval: 200 hours |
| | Oil filter | Replacement | | Replacement interval: 400 hours |
| | Coolant | Coolant level, contamination, leakage | | |
| | Fan belt | Wear, tension | | |
| | Radiator hose | Damage | | |
| | Air filter | Cleaning, replacement | | |
| | Fuel filter | Replacement | | Replacement interval: 600 hours |
| | Fuel | Fuel level, leakage | | |
| | Bolts, nuts | Looseness | | |
| | Abnormal noise, Performance | | | |
| Battery | Electrolyte | Electrolyte level | | |
| | Battery terminals | Corrosion, looseness | | |
| Hydraulic oil reservoir | Oil level, contamination | | | Oil change interval: 1,200 hours or one year. |
| | Oil leakage | | | |
| Hydraulic filters | Oil leakage | | | Replacement interval: 1,200 hours or one year. |
| | Replacement | | | |
| Hydraulic pump | Loose bolts and nuts | | | |
| | Abnormal noise | | | |
| | Oil leakage | | | |
| Chassis frame | Cracks, deformation | | | |
| | Counterweight anchor bolts, nuts | Looseness | | |
| Tires and wheels | Tires | Wear, cuts | | |
| | | Air pressure | | |
| | Clip bolts, nuts | Looseness | | |
| Axles | Cracks, deformations | | | |
| Oscillation axle lock cylinder | Oil leakage | | | |
| | Functions | | | |
| Travel motor and gearbox | Gear oil level, contamination | | | |
| | Oil leakage | | | |
| | Abnormal noise | | | |
| Steering mechanism | Lubrication | | | |
| | Cracks, deformations | | | |
| | Wheel bearings | Free play, damage | | |
| Steering cylinder | Oil leakage | | | |
| | Functions | | | |
| Jack cylinder | Oil leakage | | | |
| | Natural descent | | | Serviceable limit: 1mm (0.04 in) / 10 minutes |
| Crawler | Track links | Wear, tension | | |
| | Track shoes | Wear, deformations | | |
| | Track rollers, Carrier rollers | Wear, oil leakage | | |
| | Sprockets, Idler wheels | Wear, cracks | | |

| <i>Unit</i> | <i>Item</i> | | <i>Results</i> | <i>Remarks</i> |
|--|--|------------------------------|-----------------|--|
| Rotation bearing | Loose bolts and nuts | | | |
| | Wear, cracks | | | |
| | Lubrication | | | |
| Rotation gear box | Loose bolts and nuts | | | Gear oil change interval: 1,200 hours or one year. |
| | Oil leakage | | | |
| | Gear oil | | | |
| | (*) Backlash between pinion and ring gear (Standard backlash: 0.6 mm, 0.024 in) | | | |
| | Abnormal noise | | | |
| Turn table | Cracks, deformations | | | |
| | Loose bolts and nuts | | | |
| Swivel joint | Loose bolts and nuts | | | |
| | Oil leakage | | | |
| | Lubrication | | | |
| Boom Fly jib | Cracks, deformations | | | Disassemble the boom to check each extension / retraction wire rope thoroughly every 4 years. |
| | Damaged pivot pins | | | |
| | Loose bolts and nuts | | | |
| | Oil leakage | | | |
| | Lubrication | | | |
| | Extension / retraction wire ropes | Damage, tension | | |
| | | (*) Tension | | |
| | Electric cables, Hydraulic hoses | (*) Tension | | |
| | | (*) Wear | | |
| | Abnormal noise, movements | | | |
| Elevation, Telescope, Fly jib cylinders | Oil leakage | | | |
| | Natural descent Serviceable limit: 2 mm (0.08 in) / 10 minutes. | | | |
| Platform | Cracks, deformations | | | |
| | Loose bolts and nuts | | | |
| | Rotation motor, Rotary actuator | Oil leakage | | |
| | | Abnormal noise, movements | | |
| | Worm gear, Bushings | | Lubrication | |
| Platform levelling system | Levelling cylinders | | Oil leakage | |
| | Functions | | | |
| Control panels | Joystick controllers, Control switches, | Damage | | |
| | | Functions | | |
| | Indicator lamps | Damage | | |
| | | Functions | | |
| Safety devices | Emergency stop system | | Functions | |
| | Emergency pump | | Functions | |
| | Moment limiter | | Functions | |
| | Work range limit system | | (*) Work radius | |
| | Pre-start check system | | Functions | |
| | Foot switch | | Functions | |
| | Tilt alarm buzzer | | Functions | |
| | Motion alarm buzzer | | Functions | |
| | Alarm horn | | Functions | |
| | Overload sensing system | | Functions | |
| | Other safety devices | | Functions | |
| Decals | Readability | | | |

Function tests check sheet

| <i>Test</i> | <i>Item</i> | | <i>Results</i> | <i>Remarks</i> |
|-----------------|---------------------------|------|----------------|---|
| Load test | Function | | | |
| | Abnormal noise | | | |
| | Damage | | | |
| Natural descent | Elevation cylinder | | | Serviceable limit: 2 mm (0.08 in) / 10 minutes |
| | Telescope cylinder | | | |
| | Fly jib cylinder | | | |
| Speed test | Boom elevation speed | Up | | |
| | | Down | | |
| | Boom telescope speed | Out | | |
| | | In | | |
| | Boom rotation speed | CW | | |
| | | CCW | | |
| | Fly jib speed | Up | | |
| | | Down | | |
| | Vertical movement speed | Up | | |
| | | Down | | |
| | Horizontal movement speed | Out | | |
| | | In | | |
| Brake test | Stopping distance | FWD | | |
| | | REV | | |
| | | | | |

Major alterations and repairs