

# MANUAL

## ANCHOR BEAM

ELSF-AB500



CE 2834

EN 795:2012 type B,  
TS 16415:2013 type B




### NOTIFIED BODY FOR EU TYPE EXAMINATION AND PRODUCTION CONTROL:

Notified body for EU type examination and production control:

VVUÚ a.s (1019) Pikartská 1337/7, Ostrava-Radvanice, 716 07, Czech Republic

This product must not be pushed beyond its limits, nor be used for any purpose other than that for which it is designed.

### NOMENCLATURE OF PARTS



- |                     |                        |
|---------------------|------------------------|
| 1. Main beam        | 5. Safety pin          |
| 2. Fastening plate  | 6. Limit bolt          |
| 3. Adjustment plate | 7. Anchorage eye bolts |
| 4. Adjustment holes |                        |

### MARKING



- |   |                                     |
|---|-------------------------------------|
| 1. ELLERsafe: Manufacturer name                               | 6. CE means conform according to    |
| 2. AB500 is model number                                      | Regulation 2016/425                 |
| 3. MM/YY: MONTH/YEAR  | 7. MAX 2 persons                    |
| 4. 350-1240 is max. adjustment range                          | 8.  Read the instruction before use |
| 5. EN795:2012-B. means European standard and publication date |                                     |

### LIMITATIONS

The anchor beam is a portable anchor device. The anchor beam is designed and intended to be used with personal fall protection equipment. The anchor beam must be installed inside the door or window opening with a width from 350-1240mm. The anchor beam provides protection for up to 2 persons.

### LIFESPAN

The anchor beam lifetime is indefinite. The maximum lifetime depends on the intensity of usage and the environment of usage. Using the beam in rough environment, marine environment, contact with sharp edges, exposure to extreme temperatures or aggressive substances, etc. can lead to the withdrawal from use even after one use.

### PERIODICAL INSPECTION

At least once every 12 months, the anchor beam shall be subject to periodical inspection. The periodical inspection must be carried out by a suitably qualified, competent person, responsible for the periodical inspections of protective equipment at the given site. The periodical inspection can be carried out also by the manufacturer or his authorized representative. Every periodical inspection must be recorded in the Identity Card of the equipment.

### WITHDRAWAL FROM USE

The anchor beam shall be withdrawn from use and destroyed to avoid incidental use when:


- It has been used to arrest a fall.
- It fails to pass inspection. There are any doubt as to its reliability.

The anchor beam shall be withdrawn from use by the person who is responsible for the protective equipment at the given site.


### INSTALLATION

The anchor beam must be fixed into the stable door or window opening of the static construction. The anchor beam must be situated horizontally on the ground. It is strictly forbidden to install the beam in vertical direction. The maximum load that can be transmitted in service from the anchor beam to the static construction is 600 kg. The strength of the static construction must be at least double of the load transmitted in use from the anchor beam to the structure, but not less than 13 kN.


1. Place the anchor beam in the door or window opening with the anchorage eye bolts facing the area where work will be performed.(fig. 1) The anchor beam must rest on the bottom of the window or door opening. Do not install the anchor beam in a position where it is not supported by the floor or window sill.



2. Make sure the anchor beam is situated horizontally and fits close to the wall. Push the fastening plate to one side of the opening (fig. 2).



3. Shift the adjusting plate close to the other side of the opening and lock in place with the safety pin. Tighten it with the adjustment screw to stabilize the beam inside the opening (fig. 3). Ensure that the fastening and adjustment plates fit close to the surfaces of the opening. The shape and construction of the window or door opening shall not allow for self disconnection of the beam.



4. Connect personal fall protection system to the anchorage eye bolt of the anchor beam (fig. 4). To avoid the danger of collision of a falling worker with any object or the ground there must be a defined free clearance below the working level. The free clearance depends on fall protection equipment being used. The minimum distance of the free clearance below the working level is evaluated as the sum of lengths of particular components of the fall protection system plus an additional 1 m safety margin. The required free clearance below the working level must be verified against the user's manual of the fall protection system to be used.

Every time before using the fall protection system that includes the anchor beam it is necessary to verify if all the elements of the system are properly connected to one another and operate properly without any mutual interferences, as well that they conform to effective standards:

- EN 361 – for full body harnesses
- EN 358 – for work positioning belts;
- EN 813 – for sit harnesses;
- EN 362 – for connectors
- EN 354, EN 355, EN 353-1, EN 353-2, EN 360 – for fall arrest systems;
- EN 795 – for anchor devices;
- EN 341, EN 1496, EN 1497, EN 1498 – for rescue equipment.

The length of anchor device used in the fall arrest system has to be taken into consideration every time, as it has an effect directly on the fall arrest distance.

Special attention should be paid to some elements connected to the anchor device that can reduce its strength characteristics, such as connecting wide straps.

The anchor beam cannot be used for lifting or lowering of loads.

The fall arrest system must include energy dissipating component reducing braking force acting on the user while arresting the fall, to maximum value of 6 kN. (e.g. energy absorber with lanyard or retractable fall arrester).

