



## IRGL-STB-L

L-852G/S LED In-pavement Runway Guard Light & Stop Bar, Medium Intensity, Style 3

## User Manual

96A0470, Rev. G, 2024/09/16

  
**ADB  
SAFEGATE**



## A.0 Disclaimer / Standard Warranty

### CE certification

The equipment listed as CE certified means that the product complies with the essential requirements concerning safety and hygiene. The European directives that have been taken into consideration in the design are available on written request to ADB SAFEGATE.

### ETL certification

The equipment listed as ETL certified means that the product complies with the essential requirements concerning safety and C22.2 No.180:13 (R2018) regulations. The CSA directives that have been taken into consideration in the design are available on written request to ADB SAFEGATE.

### All Products Guarantee

ADB SAFEGATE will correct by repair or replacement per the applicable guarantee below, at its option, equipment or parts which fail because of mechanical, electrical or physical defects, provided that the goods have been properly handled and stored prior to installation, properly installed and properly operated after installation, and provided further that Buyer gives ADB SAFEGATE written notice of such defects after delivery of the goods to Buyer. Refer to the Safety section for more information on Material Handling Precautions and Storage precautions that must be followed.

ADB SAFEGATE reserves the right to examine goods upon which a claim is made. Said goods must be presented in the same condition as when the defect therein was discovered. ADB SAFEGATE further reserves the right to require the return of such goods to establish any claim.

ADB SAFEGATE's obligation under this guarantee is limited to making repair or replacement within a reasonable time after receipt of such written notice and does not include any other costs such as the cost of removal of defective part, installation of repaired product, labor or consequential damages of any kind, the exclusive remedy being to require such new parts to be furnished.

ADB SAFEGATE's liability under no circumstances will exceed the contract price of goods claimed to be defective. Any returns under this guarantee are to be on a transportation charges prepaid basis. For products not manufactured by, but sold by ADB SAFEGATE, warranty is limited to that extended by the original manufacturer. This is ADB SAFEGATE's sole guarantee and warranty with respect to the goods; there are no express warranties or warranties of fitness for any particular purpose or any implied warranties of fitness for any particular purpose or any implied warranties other than those made expressly herein. All such warranties being expressly disclaimed.

### Standard Products Guarantee

Products manufactured by ADB SAFEGATE are guaranteed against mechanical, electrical, and physical defects (excluding lamps) which may occur during proper and normal use for a period of two years from the date of ex-works delivery, and are guaranteed to be merchantable and fit for the ordinary purposes for which such products are made.



#### Note

See your applicable sales agreement for a complete warranty description.

Replaced or repaired equipment under warranty falls into the warranty of the original delivery. No new warranty period is started for these replaced or repaired products.

### FAA Certified products manufactured by ADB SAFEGATE

ADB SAFEGATE L858 Airfield Guidance Signs are warranted against mechanical and physical defects in design or manufacture for a period of 2 years from date of installation, per FAA AC 150/5345-44 (applicable edition).

ADB SAFEGATE LED products (with the exception of obstruction lighting) are warranted against electrical defects in design or manufacture of the LED or LED specific circuitry for a period of 4 years from date of installation, per FAA EB67 (applicable edition). These FAA certified constant current (series) powered LED products must be installed, interfaced and powered with and through products certified under the FAA Airfield Lighting Equipment Program (ALECP) to be included in this 4 (four) year warranty. This includes, but is not limited to, interface with products such as Base Cans, Isolation Transformers, Connectors, Wiring, and Constant Current Regulators.

**Note**

See your sales order contract for a complete warranty description.

Replaced or repaired equipment under warranty falls into the warranty of the original delivery. No new warranty period is started for these replaced or repaired products.

---

**Liability**

---

**WARNING**

Use of the equipment in ways other than described in the catalog leaflet and the manual may result in personal injury, death, or property and equipment damage. Use this equipment only as described in the manual.

---

ADB SAFEGATE cannot be held responsible for injuries or damages resulting from non-standard, unintended uses of its equipment. The equipment is designed and intended only for the purpose described in the manual. Uses not described in the manual are considered unintended uses and may result in serious personal injury, death or property damage.

Unintended uses, includes the following actions:

- Making changes to equipment that have not been recommended or described in this manual or using parts that are not genuine ADB SAFEGATE replacement parts or accessories.
- Failing to make sure that auxiliary equipment complies with approval agency requirements, local codes, and all applicable safety standards if not in contradiction with the general rules.
- Using materials or auxiliary equipment that are inappropriate or incompatible with your ADB SAFEGATE equipment.
- Allowing unskilled personnel to perform any task on or with the equipment.

**Copyright Statement**

This manual or parts thereof may not be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, nor otherwise, without the author's prior written consent.

This manual could contain technical inaccuracies or typographical errors. The author reserves the right to revise this manual from time to time in the contents thereof without obligation of the author to notify any person of such revision or change. Details and values given in this manual are average values and have been compiled with care. They are not binding, however, and the author disclaims any liability for damages or detriments suffered as a result of reliance on the information given herein or the use of products, processes or equipment to which this manual refers. No warranty is made that the use of the information or of the products, processes or equipment to which this manual refers will not infringe any third party's patents or rights. The information given does not release the buyer from making their own experiments and tests.

# TABLE OF CONTENTS

<b>1.0 Safety</b>	<b>1</b>
1.1 Safety Messages	1
1.1.1 Introduction to Safety	2
1.1.2 Intended Use	2
1.1.3 Material Handling Precautions: Storage	3
1.1.4 Material Handling Precautions: Fasteners	3
1.1.5 Maintenance Safety	4
1.1.6 Material Handling Precautions, ESD	4
1.1.7 Arc Flash and Electric Shock Hazard	5
<b>2.0 IRGL-STB-L</b>	<b>7</b>
2.1 About this manual	7
2.1.1 How to work with the manual	7
<b>3.0 Introduction</b>	<b>9</b>
3.1 LED In-pavement Runway Guard Light & Stop Bar	9
<b>4.0 Installation</b>	<b>13</b>
4.1 Safety Considerations	13
4.2 Photobiological safety	14
4.3 Earth Ground Connection	14
4.4 Typical L-868 Assembly	15
4.5 Verify Input Requirements and Equipment Needed	16
4.6 Unpacking the Unit	16
4.7 Inspect on delivery	16
4.8 Store	17
4.9 IRGL-STB installation using a RELIANCE Platform II Remote	17
4.9.1 Installing a Remote in a Base Can	18
4.9.2 Connection of the Series Transformer and the Light Connectors	19
4.10 Installation on L-868 Base	20
4.11 Torquing and Installation Guidance for In-pavement Fixtures	21
4.12 Shallow base can installation	23
4.12.1 Installation on a Shallow Base	23
<b>5.0 Maintenance</b>	<b>25</b>
5.1 Fixture Component Maintenance	25
5.1.1 Cleaning the Light Channel and Prism	25
5.1.2 Lifting Optical Unit Out of Base	25
5.2 Repair Procedures	26
5.2.1 Opening Optical Unit	26
5.2.2 Replacing Prism	27
5.2.3 Replacing LED Assembly	29
5.2.4 Replacing PCB Assemblies	30
5.2.5 Remote RRHLG01 Programming Procedure	31
5.2.6 Replacing L-823 Cordset	33
5.2.7 Testing for Leaks	33
5.3 Material Handling Precautions: Fasteners	35
5.4 Bolt Torque Preventive Maintenance Schedule	36
<b>6.0 Troubleshooting</b>	<b>39</b>
<b>7.0 Parts</b>	<b>41</b>
7.1 Spare Parts	44
<b>A.0 SUPPORT</b>	<b>45</b>
A.1 ADB SAFEGATE Website	46
A.2 Recycling	47
A.2.1 Local Authority Recycling	47

A.2.2 ADB SAFEGATE Recycling ..... 47

# 1.0 Safety

## Introduction to Safety

This section contains general safety instructions for installing and using ADB SAFEGATE equipment. Some safety instructions may not apply to the equipment in this manual. Task- and equipment-specific warnings are included in other sections of this manual where appropriate.

## 1.1 Safety Messages

### HAZARD Icons used in the manual

For all HAZARD symbols in use, see the Safety section. All symbols must comply with ISO and ANSI standards.

Carefully read and observe all safety instructions in this manual, which alert you to safety hazards and conditions that may result in personal injury, death or property and equipment damage and are accompanied by the symbol shown below.



#### WARNING

Failure to observe a warning may result in personal injury, death or equipment damage.



#### DANGER - Risk of electrical shock or ARC FLASH

Disconnect equipment from line voltage. Failure to observe this warning may result in personal injury, death, or equipment damage. ARC Flash may cause blindness, severe burns or death.



#### WARNING - Wear personal protective equipment

Failure to observe may result in serious injury.



#### WARNING - Do not touch

Failure to observe this warning may result in personal injury, death, or equipment damage.



#### CAUTION

Failure to observe a caution may result in equipment damage.



#### ELECTROSTATIC SENSITIVE DEVICES

This equipment may contain electrostatic devices.

## Qualified Personnel



#### Important Information

The term **qualified personnel** is defined here as individuals who thoroughly understand the equipment and its safe operation, maintenance and repair. Qualified personnel are physically capable of performing the required tasks, familiar with all relevant safety rules and regulations and have been trained to safely install, operate, maintain and repair the equipment. It is the responsibility of the company operating this equipment to ensure that its personnel meet these requirements.

Always use required personal protective equipment (PPE) and follow safe electrical work practice.

### 1.1.1 Introduction to Safety



#### CAUTION

##### Unsafe Equipment Use

This equipment may contain electrostatic devices, hazardous voltages and sharp edges on components

- Read installation instructions in their entirety before starting installation.
- Become familiar with the general safety instructions in this section of the manual before installing, operating, maintaining or repairing this equipment.
- Read and carefully follow the instructions throughout this manual for performing specific tasks and working with specific equipment.
- Make this manual available to personnel installing, operating, maintaining or repairing this equipment.
- Follow all applicable safety procedures required by your company, industry standards and government or other regulatory agencies.
- Install all electrical connections to local code.
- Use only electrical wire of sufficient gauge and insulation to handle the rated current demand. All wiring must meet local codes.
- Route electrical wiring along a protected path. Make sure they will not be damaged by moving equipment.
- Protect components from damage, wear, and harsh environment conditions.
- Allow ample room for maintenance, panel accessibility, and cover removal.
- Protect equipment with safety devices as specified by applicable safety regulations
- If safety devices must be removed for installation, install them immediately after the work is completed and check them for proper functioning prior to returning power to the circuit.

**Failure to follow this instruction can result in serious injury or equipment damage**

### Additional Reference Materials



#### Important Information

- IEC - International Standards and Conformity Assessment for all electrical, electronic and related technologies.
- IEC 60364 - Electrical Installations in Buildings.
- CSA - C22.2 No.180:13 (R2018) Series isolating transformers for airport lighting
- FAA Advisory: AC 150/5340-26 (current edition), Maintenance of Airport Visual Aid Facilities.
- Maintenance personnel must refer to the maintenance procedure described in the ICAO Airport Services Manual, Part 9.
- ANSI/NFPA 79, Electrical Standards for Metalworking Machine Tools.
- National and local electrical codes and standards.

### 1.1.2 Intended Use



#### CAUTION

##### Use this equipment as intended by the manufacturer

This equipment is designed to perform a specific function, do not use this equipment for other purposes

- Using this equipment in ways other than described in this manual may result in personal injury, death or property and equipment damage. Use this equipment only as described in this manual.

**Failure to follow this instruction can result in serious injury or equipment damage**

### 1.1.3 Material Handling Precautions: Storage



#### CAUTION

##### Improper Storage

Store this equipment properly

- If equipment is to be stored prior to installation, it must be protected from the weather and kept free of condensation and dust.

**Failure to follow this instruction can result in equipment damage**

### 1.1.4 Material Handling Precautions: Fasteners



#### DANGER

##### Foreign Object Damage - FOD

This equipment may contain fasteners that may come loose - torque properly.

- Only use fasteners of the same type as the one originally supplied with the equipment.
- Use of incorrect combination of gaskets, bolts and nuts can create severe damages to the product installation and create safety risk .
- You need to know what base the light fixture will be installed in, in order to chose the correct gasket, bolts and nuts.
- Bolt type, length, and torque value are determined by type of base, height of spacers used, and clamp force required in FAA Engineering Brief No 83 (latest revision).
- Due to the risk of bolts vibrating loose, do not use any type of washer with the fixing bolts (such as split lock washers) other than an anti-vibration washer. Anti-vibration washers as defined in FAA EB 83 (latest edition) must be used. For installations other than FAA, use the base can manufacturer's recommendations.
- Always tighten the fasteners to the recommended torque. Use a calibrated torque wrench and apply the recommended adhesive type.
- Obey the instructions of the adhesives necessary for the fasteners.

**Failure to follow these warnings may cause the fasteners to loosen, damage the equipment, potentially to loosen the equipment. This can lead to a highly dangerous situation of FOD, with potential lethal consequences.**



#### Note

To minimize the risk of errors, the ADB SAFEGATE Sales Representative will have information on which gasket goes with which base. This information is also provided in the product Data sheets, the User Manuals and the Spare Part Lists.



#### CAUTION

Use of incorrect combination of gaskets, bolts and nuts can create severe damages to the product installation and create multiple safety risks.

To obtain a safe and watertight installation the O-ring and retaining bolt stated in the document must be used.

You need to know what base the light fixture will be installed in, in order to choose the correct gasket, bolts and nuts.

**Failure to follow these cautions can result in equipment damage or aircraft FOD.**

### 1.1.5 Maintenance Safety



#### **DANGER**

##### **Electric Shock Hazard**

This equipment may contain electrostatic devices

- Do not operate a system that contains malfunctioning components. If a component malfunctions, turn the system OFF immediately.
- Disconnect and lock out electrical power.
- Allow only qualified personnel to make repairs. Repair or replace the malfunctioning component according to instructions provided in its manual.

**Failure to follow these instructions can result in death or equipment damage**

### 1.1.6 Material Handling Precautions, ESD



#### **CAUTION**

##### **Electrostatic Sensitive Devices**

This equipment may contain electrostatic devices

- Protect from electrostatic discharge.
- Electronic modules and components should be touched only when this is unavoidable e.g. soldering, replacement.
- Before touching any component of the cabinet you shall bring your body to the same potential as the cabinet by touching a conductive earthed part of the cabinet.
- Electronic modules or components must not be brought in contact with highly insulating materials such as plastic sheets, synthetic fiber clothing. They must be laid down on conductive surfaces.
- The tip of the soldering iron must be grounded.
- Electronic modules and components must be stored and transported in conductive packing.

**Failure to follow this instruction can result in equipment damage**

### 1.1.7 Arc Flash and Electric Shock Hazard



## DANGER

### Series Circuits have Hazardous Voltages

This equipment produces high voltages to maintain the specified current - Do NOT Disconnect while energized.

- Allow only qualified personnel to perform maintenance, troubleshooting, and repair tasks.
- Only persons who are properly trained and familiar with ADB SAFEGATE equipment are permitted to service this equipment.
- An open airfield current circuit is capable of generating >5000 Vac and may appear OFF to a meter.
- Never unplug a device from a constant current circuit while it is operating; Arc flash may result.
- Disconnect and lock out electrical power.
- Always use safety devices when working on this equipment.
- Follow the recommended maintenance procedures in the product manuals.
- Do not service or adjust any equipment unless another person trained in first aid and CPR is present.
- Connect all disconnected equipment ground cables and wires after servicing equipment. Ground all conductive equipment.
- Use only approved ADB SAFEGATE replacement parts. Using unapproved parts or making unapproved modifications to equipment may void agency approvals and create safety hazards.
- Check the interlock systems periodically to ensure their effectiveness.
- Do not attempt to service electrical equipment if standing water is present. Use caution when servicing electrical equipment in a high-humidity environment.
- Use tools with insulated handles when working with airfield electrical equipment.

**Failure to follow these instructions can result in death or equipment damage**



## 2.0 IRGL-STB-L

L-852G/S LED Style 3, In-pavement Stop-bar and Runway Guard Light (IRGL-STB) manual.

### 2.1 About this manual

The manual shows the information necessary to:

- Install and maintain the L-852G/S In-pavement Stop-bar and Runway Guard Light (IRGL-STB).

#### 2.1.1 How to work with the manual

1. Become familiar with the structure and content.
2. Carry out the actions completely and in the given sequence.



## 3.0 Introduction



### 3.1 LED In-pavement Runway Guard Light & Stop Bar

#### Compliance with Standards

<b>FAA:</b>	L-852G(L) and L-852S(L) AC 150/5345-46 (Current Edition) and the FAA Engineering Brief No. 67. Meets the requirements of Low-Visibility Taxiway Lighting Systems as specified by FAA AC 150/5340-30.
<b>T/C:</b>	AC 302-005 (Fig. 9) and TP312 – 5th Ed. Amendment 1 Para 5.3.26.11, Figure B-17 (L852G) Runway Guard Light configuration B. Meets or exceeds TP312 – 5th Ed. Amendment 1 – Figure B-12, and Appendix 5A, Figure A-1(b) (L-852S) Stop Bar

#### Uses

##### FAA L-852G/S(L) and T/C

- Stop Bar, controlled and uncontrolled -steady burning
- In-pavement Runway Guard Light - flashing
- Runway incursion prevention

#### Features

- FAA Style 3 ( $\leq 0.25$  inch) provides a low protrusion above ground, which reduces vibrations in both the light fixture and the landing gear, increasing lamp life.
- Operates on either 3- or 5-step ferroresonant or thyristor CCRs that are designed in compliance with IEC or FAA requirements.
- Can be retrofit on existing 6.6 A or 20 A series circuits using existing CCRs and Local Control Devices. Requires the addition of a Y-Harness adapter. Adapter connects isolation transformer to both the input of the Local Control Device and the fixture. In electronically monitored applications, fixture opens existing Local Control Device output connection, providing an alarm signal in case of fixture failure.
- An autonomous version is available for applications where fixture failures are not electronically monitored. Synchronization circuitry is contained within each fixture, eliminating the need for any synchronizing Local Control Devices. Fixture connects directly into isolation transformer. A simple, separate Remote Control Device is used to set the fixture to Initial ON or Initial OFF. The Remote Control Device can also be optionally used to program variable start up delays (for an entire RGL bar). This effectively reduces the load variation on a CCR that powers multiple RGL bars.
- Thermostatically controlled heater cycles on and off when temperature drops below freezing, reducing overall energy consumption.
- Light channel in front of prism windows protects prisms from damage and prevents rubber buildup thereby maintaining optimal light output.
- Use of LED light source eliminates filter replacement and color shifts when viewed at various angles or CCR step settings.
- LED photometric performance will be maintained longer due to a cleaner lens. The lower temperature of the lens prevents the “baking effect” that causes contaminants to stick to the surface of the lens.

- Fixture uses aluminum alloy cover and inner cover, stainless steel hardware, and aluminum alloy and stainless steel optical assembly
- Rugged lightning protection complies with ANSI/IEEE C62.41-1991 Location Category C2 given in FAA Eng. Brief 67. Category C2 is defined as a 1.2/50µS - 8/20 µS combination wave, with a peak voltage of 10,000 V and a peak current of 5,000 A.
- Includes a UL 467 rated ground lug, which accepts an AWG 6 earth ground wire

## Control and Monitoring

For control and monitoring applications per AC 120-57 (Current Edition) and AC 150/5340-30 (Current Edition), see the following ADB SAFEGATE data sheets:

- LINC 360 - Individual Lamp Control and Monitoring, data sheet 4043
- RELIANCE Elite ALCMS - Airport lighting control and monitoring system, data sheet 1041

## Operating Conditions

Temperature:	-40 °C to +55 °C / -40 °F to +131 °F
Altitude:	Sea level to 10,000 feet / 3000 m
Relative Humidity:	Up to 100%

## Dimensions

Outside Diameter:	11.94 in / 30.33 cm
Bolt Circle Diameter (L-868B):	11.25 in / 28.58 cm
Max. Bottom Cover O.D.:	
- 9.92 in / 25.20 cm <i>down to depth of 1.63 in / 4.14 cm</i>	
- 8.69 in / 22.07 cm <i>from depth of 1.63 in / 4.14 cm to 3.88 in / 9.86 cm</i>	
Compatible with L-868B Top Sections where the overall height of the Top Section is less than 4 in / 10.16 cm.	
Bottom Cover Depth:	3.88 in / 9.9 cm

## Power Supply

6.6 A through an L-830 (for 60 Hz) or L-831 (for 50 Hz) isolation transformer.

Application <sup>1</sup>	Fixture Load <sup>2</sup>	Isol. XF Size	Isolation XF Load <sup>2</sup>	CCR Load <sup>2</sup>
<b>L-852G(L) without heater</b>				
Unmonitored	28 VA	65 W	13 VA	41 VA
Monitored <sup>3</sup>	59 VA	65 W	15 VA	74 VA
<b>L-852G(L) with heater</b>				
Unmonitored	88 VA	100 W	16 VA	104 VA
Monitored <sup>3</sup>	109 VA	150 W	22 VA	131 VA
<b>L-852S(L) without heater</b>				
Unmonitored	20 VA	65 W	14 VA	34 VA
Monitored <sup>3</sup>	48 VA	65 W	16 VA	64 VA
<b>L-852S(L) with heater</b>				
Unmonitored	87 VA	100 W	15 VA	102 VA
Monitored <sup>3</sup>	107 VA	100 W	13 VA	120 VA

### Notes

<sup>1</sup> Data is for a ferroresonant CCR only. Contact the ADB Safegate Sales Department for thyristor/SCR CCR data.

Application <sup>1</sup>	Fixture Load <sup>2</sup>	Isol. XF Size	Isolation XF Load <sup>2</sup>	CCR Load <sup>2</sup>
--------------------------	---------------------------	---------------	--------------------------------	-----------------------

<sup>2</sup> All load data is average load per fixture for applications where the entire load alternately flashes.

<sup>3</sup> Fixture load includes Local Control Device load.

## Packaging

In cardboard box:	7 × 13 × 13 in / 17.8 × 33 × 33 cm
Weight with packing:	20.55 lb / 9.32 kg
Weight without packing:	17.55 lb / 7.96 kg



## 4.0 Installation



### WARNING

Read the instructions in their entirety before starting installation.  
Do not unpack or remove the fixtures from their boxes until reading all these instructions.

This section provides installation instructions for the L-852G/S, IRGL-STB Light Fixture.

### Input Requirement Summary

The L-852G/S light fixture is designed for connection to a 6.6 A or 20 A series lighting circuit via an L-830 (for 60Hz) or L-831 (for 50Hz) isolation transformer.

### Unpacking

Each unit is individually packaged in a durable, cushioned, corrugated cardboard carton. To avoid unnecessary damage to the light assembly, unpack the carton at the installation site.

To unpack the carton, open the flaps and carefully remove the top packing material. Thread an eye-bolt into each of the two opposite threaded holes. Run a rod through the eye-bolts and lift the light assembly from the shipping carton. Set the light assembly in a protected area.

If damage to any equipment is noted, file a claim form with the carrier immediately. The carrier may request to inspect the equipment.

## 4.1 Safety Considerations

Read the installation section of all system component manuals before starting these steps. A thorough understanding of system components and their requirements will promote safe and efficient installation. See FAA AC 150/5340-30, Design and Installation Details for Airport Visual Aids, and site plans and specifications for field installation of runway and taxiway in-pavement lights.



### DANGER

Failure to follow these safety procedures can result in personal injury or death.

- Allow only qualified personnel to install ADB SAFEGATE and auxiliary equipment. Use only approved equipment. Using unapproved equipment in an approved system may void FAA approvals. Observe and follow the safety instructions in this document and all other related documentation.
- Make sure all equipment is rated and approved for the environment where it is being used.
- Follow all instructions for installing components and accessories.
- Install all electrical connections in compliance with local and national codes and regulations.
- Use only electrical wire of sufficient gauge and insulation to handle the rated current demand. All wiring must meet local and national codes.
- Route electrical wiring along a protected path. Make sure it will not be damaged by moving equipment.
- Protect components from damage, wear and harsh environmental conditions.
- Allow ample clearance for maintenance, panel accessibility and cover removal.
- Protect equipment with safety devices as specified by applicable safety regulations.
- If safety devices must be removed for installation, reinstall them immediately after the work is completed and check them for proper functioning.
- The cord set must be protected prior to installation.

## 4.2 Photobiological safety



### CAUTION

Photobiological safety conforming with IEC 62471

RISK GROUP 0 or 1: Optical radiation emitted from LED lights may be harmful to the eyes. Do not stare with at the light source with bare eyes at a fixture operating at high intensity. Use protection goggles or similar protection method.

Goggles with a transmission factor not higher than 5% in the 400-530 nm band have been tested and provide adequate protection.


## 4.3 Earth Ground Connection



### Note

**RELIANCE Platform II Only:** To protect it against over-voltages generated by lightning, each Remote must be provided with a separate, low induction and low resistance earth connection via the earth ground screw. The earth ground cable must be connected to the earth ground screw by means of a suitable cable lug. The cross-sectional area of the cable should be at least AWG 6 (4.1 mm, 13.3 mm<sup>2</sup>) with a maximum cable length of 3.3-Feet (1m.)


Figure 1: Base Can Cross-section Using a Remote



Using a Remote


## 4.4 Typical L-868 Assembly

**Figure 2: Diagram of the Fixture Installed in a 1-Piece Base Can**



1. Torque according to: FAA EB-83 (latest revision).

**Figure 3: Anti-vibration washer example**





## CAUTION

Per FAA AC 150/5340-30, Chapter 10, and FAA Engineering Brief No 83 (latest revision), it is extremely important that other types of washers, such as split washers, must not be used. Failure to use properly installed anti-vibration lock washers will cause mounting bolts to become loose. The cams (or steps) of each half of the lock washer must face each other.

## 4.5 Verify Input Requirements and Equipment Needed

The In-pavement light fixture is designed for connection to a 6.6A or 20A series lighting circuit via an L-830 (60 Hz) or L-831 (50 Hz) isolation transformer.

Make sure you have the necessary tools and materials ready for installation (not supplied). Also consider other tools that might be needed based on site-specific conditions.

**Table 1: Suggested Tools and Materials for Installation and Repair**

Qty.	Description	Qty.	Description
1	Torque wrench	1	Set of screwdrivers, one with 3/8" (9.525mm) minimum blade width
1	Alignment jig		
1	Diamond-faced core drill	As needed	Silicone grease
1	Diamond-faced saw, 3/8" (9.525mm) thick	As needed	Joint sealing filler
1	Crimping tool	1	Pressure test fitting assembly
1	Small water suction pump	As needed	Dow Corning Molykote® 3452 or equal (P/N 67A0095) - used on top cover prism seal
2	Eyebolts, 3/8 inch (9.525mm) diameter		
1	Lifting rod, 16 inches (406mm) long	As needed	Novagard® Silicone Versilube® G322L™ (P/N 67A0009) - used on O-ring between top cover and inner pan assembly; also may be applied to four nipples of inner pan assembly to install optical assembly
1 or 2	L-830 / L-831 isolation transformer		
1	Set of fiber brushes		
1	Set of socket wrenches, 1/2" (12.7mm) drive		

## 4.6 Unpacking the Unit

To reduce the possibility of damaging the light assembly, unpack the light fixtures at the installation site. If damage to any equipment is noted, file a claim form with the carrier immediately.

When receiving the light fixture, open the box and verify that the characteristics of the light fixture correspond to the design requirements, such as type, color etc. When installing a light fixture where the control and monitoring function is to be activated at a later stage, make sure to register product information, such as PID/SN and position of the light fixture in, for example, a site documentation table. The information is required for remote activation and administration of control and monitoring functionality from a substation.

## 4.7 Inspect on delivery

1. Inspect all packings for visible damage.
2. Open every damaged box and inspect the contents for damage.
3. Immediately fill a claim form with the carrier if any fixture is damaged.
4. Store the fixture in its original packing in a protected area.



### Note

If damage to any equipment is noted, file a claim form with the carrier immediately.



### WARNING

Do not damage the cable insulation.



### CAUTION

Do not unpack the fixture before it is at the installation site to avoid damage due to transportation and handling.

## 4.8 Store

Store the fixture in its original packing in a protected area. Indoor storage:

- Storage temperature: 14°F to 122°F (-10°C to +50°C).
- Humidity: <95% non condensing.

For long storage periods (longer than one year), we recommend to energize the LED lights once a year at nominal intensity (6.6 Amps) for 20 minutes.

## 4.9 IRGL-STB installation using a RELIANCE Platform II Remote



### Attention


- Read installation instructions in the entirety before starting installation.
- Do not unpack or remove the Remotes from their boxes until reading all these instructions.



## Note

- See instruction manual 96A0480 (master) and 96A0481 (remote) for RELIANCE Platform II.
- See instruction manual 96A0199 and 96A0200 for BRITE I/BRITE II remote/master.

**Figure 4: Diagram of a RELIANCE Platform II Installation in a Series Circuit**




### 4.9.1 Installing a Remote in a Base Can



## Note

RELIANCE Platform II Only: For best results, place the Remote in the can with the ground screw face down.

If several Remotes are installed in a single base can or manhole, they must be spaced with a distance of at least 2-inches (50mm) from each other and from the series transformers. The distance between the transformers should also not be less than 2-inches (50mm).



#### 4.9.2 Connection of the Series Transformer and the Light Connectors


1. As per [Figure 4](#), the 2-pin plug on cable X1 is connected to the socket for the secondary circuit of the series transformer via the Y-connector. See [Figure 5](#). The light CONTROL is connected to the 2-pin socket of the Remote. X3 of the Y-connector is then connected to the Remote. See [Figure 4](#) and the Remote instruction manual 96A0199.
2. The remaining lead X2 from the Y-connector, attached to the transformer, is then connected to the POWER connector of the light assembly. See [Figure 4](#) and [Figure 5](#).



### Note

Autonomous lights do not use a Remote and therefore do not have the CONTROL lead. The light assemblies are factory set to start ON. Make certain to alternate the units to get a proper flashing sequence. See "[Remote RRHLG01 Programming Procedure](#)" for how to use the hand held remote control to set the proper sequence.

**Figure 5: IRGL-STB with Power and the Control Lead**



### Note

All connections should be sealed with self-bonding insulation tape and then covered with electrical tape in accordance with local airport practices. If your airport does not require this, it is highly recommend that you at least wrap the connection with electrical tape.

## 4.10 Installation on L-868 Base

The light assembly is shipped complete, and is ready for installation.

To install the fixture on an L-868 base, see FAA AC 150/5345-30 and the project site-specific plans and specifications for details on L-868 base installation.



### Note

Mounting bolts are not supplied with the fixture. Mounting bolts and anti-rotation lock washers are normally supplied with the base can spacer or flange ring. If a flange ring is used, the bolt length is 1-1/4 inch (32mm) plus the thickness of the flange ring.

Also read the following guidelines:

1. Clean the base receptacle. Make sure the base receptacle is completely clean and dry. The mating surfaces must be clean and free of foreign particles.
2. If present, fit an appropriate lifting tool into the two threaded holes, which are located 180° apart in the cover.



The lifting tool can be made from two 1/2 x 13 eyebolts (1-inch ID) and a 1/2-inch diameter, 16-inch (406mm) long rod or pipe inserted through the eyebolts.



### CAUTION

Never hold the light fixture by the wires. Doing so may damage the insulation, break the waterproof seal and cause insulation faults and water leakage.

3. Carry the light assembly to the base.
4. Place the light assembly next to the opening in the L-868 base so that the L-823 connector can be connected with the mating receptacle from the L-830 or L-831 isolation transformer in the base. Make sure that the connection is solid and secure. Refer to the Electrical Supply section of the User manual for required isolation transformers.
5. Make sure items such as spacers, shims and gaskets are installed on the light base as indicated on site plans, specifications and drawings.
6. Position the light assembly over the L-868 base and set it onto the base. Align the light according to FAA AC 150/5345-30 and project plans and specifications. Remove the eyebolts and lifting rod.



### CAUTION

Ensure that the cord set wires are NOT pinched between the base can and the fixture. Pinched wires can cause water to be drawn inside the fixture.

7. If present, lubricate the labyrinth gasket with water. soap may be added to the water (8" only).



### CAUTION

Do not use silicon or any other type of grease. Avoid the use of soap that contains silicon or glycerin.

8. Attach the six fixing bolts and anti-vibration washers. [See FAA EB-83 (latest revision)]



### CAUTION

Due to the risk of bolts vibrating loose, do not use any type of washer with the fixing bolts (such as split lock washers) other than an anti-vibration washer. Anti-vibration washers as defined in FAA EB-83 (latest revision).

9. Turn on the power to determine whether the fixture will illuminate. Operate for a minimum of five minutes.

## 4.11 Torquing and Installation Guidance for In-pavement Fixtures

In-pavement fixtures must be installed according to the plans and specifications; the applicable regulatory guidance; and the following guidance. The importance of using the proper fixture clamping components and bolt torque to minimize the risk for fixture failure or loosening of clamping components cannot be overemphasized. Refer to FAA Engineering Brief No 83 (latest revision) for torque and installation guidelines for this fixture.

Also see our Product Center at [www.adbsafegate.com](http://www.adbsafegate.com).



## CAUTION

Read installation instructions in their entirety before starting installation.

- Failure to follow the installation guidance could result in bolt loosening or bolts breaking off, resulting in catastrophic failure of the fixture and/or the mounting system components.
  - Failure to follow these warnings may result in serious injury or equipment damage.
-

## 4.12 Shallow base can installation

Shallow base cans may be non-load bearing or load bearing depending on location or fixture application. Following are specific requirements to insure that an either an elevated or an in-pavement fixture is properly installed.



### CAUTION

Read installation instructions in their entirety before starting installation.

Fasteners:

- Make sure the power is OFF when you install or remove any fixture.
- Only use fasteners of the same type as the one originally supplied with the mounting support. See Base O-ring and Bolt Selection.
- Always tighten the fasteners to the recommended torque. Use a calibrated torque wrench and apply the recommended adhesive type.
- If this is not the case, this may cause the fasteners to loosen, damage the fixture, potentially to loosen the fixture. This can lead to a highly dangerous situation of FOD, with potential lethal consequences.
- Obey the instructions of the adhesives necessary for the fasteners.
- Only install the fixture on mounting supports:
  - That ADB Safegate has approved;
  - That are installed according to the Instruction Manual of the mounting support.
- Failure to do so can result in a highly dangerous situation of FOD, with potential lethal consequences.

Failure to follow these warnings may result in serious injury or equipment damage.



### CAUTION

Proper Operation:

- The fixture is supplied from a 6.6 A series circuit;
- The series circuit is powered by a Constant Current Regulator that complies with IEC 61822;
- The transformer is an AGL series transformer that complies with IEC 61823.
- The power of the series transformer shall not exceed 200 W, for versions with the monitoring option.
- The mounting support is correctly earthed. Failure to do so will void the warranty for all damages that occur as a result of voltage surges.
- Never hold the fixture by the cable leads. This can damage the insulation, break the waterproof seal and cause insulation faults and water leakage.



### Note

See the Instruction Manual of the mounting support for instructions on how to earth the mounting support.


### 4.12.1 Installation on a Shallow Base

Installing the light fixture on a shallow base involves preparing the pavement recess and wireways, then installing the light fixture on a shallow base.

See FAA AC 150/5345-30 and the project site-specific plans and specifications for details on shallow base installation.


Also follow the applicable instructions in the previous section, when connecting, installing and powering the fixture.

**Figure 6: Example of a Shallow Base Installation**



1. Torque according to: FAA EB-83 (latest revision).

**Figure 7: Anti-vibration washer example**



### CAUTION

Per FAA AC 150/5340-30, Chapter 10, and FAA Engineering Brief No 83 (latest revision), it is extremely important that other types of washers, such as split washers, must not be used. Failure to use properly installed anti-vibration lock washers will cause mounting bolts to become loose. The cams (or steps) of each half of the lock washer must face each other.

## 5.0 Maintenance

**Table 2: L852G/S(L) LED Style 3 IRGL-STB Maintenance Schedule**

Interval	Maintenance Task	Action	Refer to:
Weekly	Check for dirty channel and prism.	Clean channel and prism.	Cleaning the Light Channel and Prism
<b>Monthly</b> (more often during rainy seasons)	Check for moisture in the light fixture.	Open up the light fixture. Clean, dry, and inspect the light assembly. Replace O-ring.	—
<b>Every 60 days</b> (also whenever the light assembly is serviced)	Check for improper torque on hold- down bolts.	Torque the six bolts holding the fixture to the base.	See “ <a href="#">Bolt Torque Preventive Maintenance Schedule</a> ”
After snow removal	Check for damaged light fixtures.	Replace damaged fixtures. Use a power broom for snow removal, if practical.	—

### 5.1 Fixture Component Maintenance



#### CAUTION

Turn off the circuit before replacing fixture(s). Failure to observe this warning may result in personal injury, death, or equipment damage.

The preferred method of maintaining the L-852G/S(L) inset light is to periodically and systematically replace the light assembly and return the replaced assembly to the maintenance shop for renovation. As an alternative, you can service the light assembly in the field. It is recommended, however, that field servicing be limited to cleaning lenses and removing moisture.

#### 5.1.1 Cleaning the Light Channel and Prism

To clean the light channel and prism, perform the following procedure:

1. Use a suitable fiber brush to remove all accumulated debris from the light channel (4).
2. Clean the outer surface of the prism (3) using liquid glass cleaner. If the prism is coated with a substance impervious to the cleaner, apply a suitable solvent sparingly with a wad of cotton or a patch of cloth. After the solvent has acted, remove the softened coating with a clean piece of cotton or cloth. Dry the prism with dry, oil-free compressed air at a pressure no greater than 10 psi (69 KN/m<sup>2</sup>) to evaporate or remove all remaining cleaner.

#### 5.1.2 Lifting Optical Unit Out of Base

To lift the optical unit from the light base, perform the following procedure:

1. Remove the six bolts and anti-vibration washers.
2. Fit the appropriate lifting tool into both threaded holes located (180 degrees apart) in the cover, lift the optical unit out of the base and place the optical unit next to the base.
3. Disconnect the light fixture wires from the power wires coming from the transformer(s) and Power Line Carrier device (if present).
4. Mount a serviced or new light fixture as described in Installation on L-868 Base in the Installation section.



#### Note

See FAA EB 83 (latest revision).

5. Take the inset fixture unit back to the maintenance base where it can be serviced entirely.



### Note

Never hold the light fixture by the wires. This may damage the insulation, break the waterproof seal, and cause insulation faults and cord set water leakage.

## 5.2 Repair Procedures

### 5.2.1 Opening Optical Unit

To open the optical unit, perform the following procedure:


1. Turn the light unit upside-down.
2. See [Figure 8](#). Remove the pressure release screw.



### Note


Removing the pressure release screw equalizes the pressure inside and outside the fixture, making it easier to break the seal and remove the inner cover.

**Figure 8: Pressure Release Screw**




3. See [Figure 9](#). Remove the ten screws. To unlock the screws, take a Phillips screw driver securely placed in the screw, and gently tap it several times with a hammer. This will break the thread lock seals. Now loosen the screws.

**Figure 9: Removing Base Pan M5 x 10 Screws**



4. See [Figure 10](#). Insert a small or medium flat blade screwdriver in the machined recess slot between cover and inner cover and turn it vertically to separate the inner cover from the cover.

**Figure 10: Separating Inner Cover from Top Cover**




### 5.2.2 Replacing Prism

Replace the prism if it is broken or its surface is badly pitted or scarred. Refer to [Figure 11](#) for parts referred to in the procedure.

To replace the prism, perform the following procedure:

1. Remove the prism-clamp and prism-keeper plate secured in the inner pan assembly.

**Figure 11: Parts List and Diagram for Replacing the Prisms )**



2. Remove the flat seal.
3. Push the prism with the sock seal towards the inside of the cover.
4. Clean and remove grease from the prism chamber with any effective solvent.




**Note**

Never use any abrasive substance. This will scratch or frost the prism.

5. Apply a thin layer of Dow Corning Molykote 3452 or equivalent in the prism chamber using a small brush.
6. Install a new sock seal over the prism.
7. Push the prism/gasket assembly in the prism pocket from the inside and clean the inner surface of the prism.
8. Install a new flat seal over the prism-keeper plate.
9. Reinstall hardware with the Phillips pan head screws. Apply a droplet of sealant Loctite 270 to the last threads. Torque to  $31 \pm 4$  inch-pounds ( $3.5 \pm 0.5$  N•m).

### 5.2.3 Replacing LED Assembly


Figure 12: Optical Unit: IRGS LED Assembly )



1. Open the Optical Unit, see " [Opening Optical Unit](#)".
2. Disconnect the LED Assembly wires at the PCB by pressing on the Molex Connector clip and pulling gently upward.
3. Remove the two Phillips Head screws, clean the mounting surface of the top cover.
4. Replace the LED Assembly, attach with two Phillips Head screws, apply a drop of Loctite 242 and torque to  $2.5 \pm 0.5\text{N}\cdot\text{m}$  ( $22 \pm 4\text{ IN}\cdot\text{LBS}$ ).
5. Connect the LED Assembly to the PCB.
6. Close the Optical Unit.
7. Test for leaks, see " [Testing for Leaks](#)".


## 5.2.4 Replacing PCB Assemblies

**Figure 13: Optical Unit Base: IRGL-STB PCB Assembly**



1. Open the Optical Unit, see “ [Opening Optical Unit](#)”.
2. Disconnect the LED Assembly wires at the PCB by pressing on the Molex Connector clip and pulling gently upward.
3. Remove the four Phillips Head screws.
4. Replace the PCB Assembly, attach with four Phillips Head screws.
5. Connect the LED Assembly to the PCB.
6. Close the Optical Unit.
7. Test for leaks, see “ [Testing for Leaks](#)”.

**Figure 14: Bottom Pan**



### 5.2.5 Remote RRHLG01 Programming Procedure

IR Remote Configuration procedure if the remote stops working or Anderic RRHLG01 batteries are replaced.



1. Press and hold the component key **TV (top-left)** for 3 seconds until the TV key light remains on. Release the TV key.  
The illuminated ON/OFF key turns on and remains on. During the programming mode, not pressing any button for 20 seconds will cause the remote to exit the programming mode.
2. Use the number keys (0-9) on the keypad to enter 2001. (old remote=1172)
  - a. If valid - the Mode key light will go out directly.
  - b. If invalid - the Mode key will blink 3 times quickly and go out.  
Please return to step 1.
3. Turn on the the IRGL-STB light you wish to control.
4. Check if the keys can control the IRGL light. (place the remote close and right in front of the light channel)
  - a. Ensure "TV" mode is enabled (press and release "TV" button).
  - b. Press and release "0" button (for initial flash "ON").
  - c. Press and release "cc" button. (old remote was "OK" button)
  - d. Verify the fixture flashes 4 times. (unit is configured for initial flash "ON".)

#### L-852G/S Programming




#### Note

The IR Remote is only used in unmonitored applications in which no Remote Control device is present. Prior to using the IR Remote, the fixture must be energized at any brightness step and flashing.

5. Press and release the remote **TV** key.
6. Point the IR Remote at the L-852G/S right light channel.  
The IR Remote should be held approximately 0.5" (13 mm) from the right light channel at an angle of approximately 45° from the pavement surface.

7. Press and release IR Remote keys according to the following table.

Setting	First Key	Second Key	NOTES
Initial Flash ON	0	"CC" (old remote was "OK" button)	The IRGL light turns on, then turns off.
Initial Flash OFF	2	"CC" (old remote was "OK" button)	The IRGL light turns off, then turns on.
ON alternative	1	"CC" (old remote was "OK" button)	<div>  <b>Note</b>            If a CCR only powers a single RGL bar, the L-852G fixtures within the bar shall be configured "ON (IRGL/2X100 Initial flash ON) next OFF (IRGL/3X100 Initial flash OFF) next ON (IRGL/2X100 Initial flash ON) ... etc."            If a CCR powers multiple RGL bars, it is recommended that approximately half of the continuous bars shall be configured "ON next OFF" and the rest use the "alternative ON next alternative OFF" settings.            The alternative settings incorporate a small time delay (when compared to the ON or OFF setting). This small time delay on half of the RGL bars evens out the load on a CCR, reducing CCR output current fluctuations.         </div>
OFF alternative	3	"CC" (old remote was "OK" button)	

8. The First Key is pressed followed by the "CC" key within 2 seconds. (old remote was "OK" button)



### Note

The system will respond to an INQUIRY to the programmed setting as follows:

- programmed for '0', unit will flash 4 times to confirm setting.
- programmed for '2', unit will flash 2 times to confirm setting.

9. The L-852G should start to flash as commanded. The setting is kept in its volatile memory.



### Note


The programming procedure can be repeated if necessary.

## 5.2.6 Replacing L-823 Cordset

To replace the L-823 cordset, perform the following procedure:

1. See [Figure 15](#). Remove both screws (F7) from the cordset strap (F9).
2. Unplug the cordset assembly.

**Figure 15: L-823 Cordset**



3. Replace the cordset by plugging in the new cordset.
4. Attach the two screws and the cable strap. Do not use a power screw driver. Compress the cord rubber by no more than 1/32" (0.79 mm).
5. Return the light to service.

## 5.2.7 Testing for Leaks

To test for leaks, perform the following procedure:


1. See [Figure 16](#).  
Remove pressure relief screw.
2. See [Figure 17](#).

Screw pressure test fitting into the pressure relief port (the opening created when the pressure relief screw is removed).  
Screw fitting hand-tight.

**Figure 16: Pressure Relief Screw**



**Figure 17: Pressure Test Fitting Assembly**



3. Attach the shop airline to the lock hose plug sleeve (2).
  4. Pressurize to 20 psi.
  5. Submerge the pressure test fitting in a water tank.  
Check for air bubbles. Air bubbles indicate a leak.
  6. Locate the leak source, depressurize, replace the seal that is leaking, reassemble, and retest by following steps 4 and 5.  
If leak is fixed, depressurize and reinstall the pressure release screw (1).
- Go to [Installation](#) to finish.

## 5.3 Material Handling Precautions: Fasteners



### DANGER

#### Foreign Object Damage - FOD

This equipment may contain fasteners that may come loose - torque properly.

- Only use fasteners of the same type as the one originally supplied with the equipment.
- Use of incorrect combination of gaskets, bolts and nuts can create severe damages to the product installation and create safety risk .
- You need to know what base the light fixture will be installed in, in order to chose the correct gasket, bolts and nuts.
- Bolt type, length, and torque value are determined by type of base, height of spacers used, and clamp force required in FAA Engineering Brief No 83 (latest revision).
- Due to the risk of bolts vibrating loose, do not use any type of washer with the fixing bolts (such as split lock washers) other than an anti-vibration washer. Anti-vibration washers as defined in FAA EB 83 (latest edition) must be used. For installations other than FAA, use the base can manufacturer's recommendations.
- Always tighten the fasteners to the recommended torque. Use a calibrated torque wrench and apply the recommended adhesive type.
- Obey the instructions of the adhesives necessary for the fasteners.

**Failure to follow these warnings may cause the fasteners to loosen, damage the equipment, potentially to loosen the equipment. This can lead to a highly dangerous situation of FOD, with potential lethal consequences.**



### Note

To minimize the risk of errors, the ADB SAFEGATE Sales Representative will have information on which gasket goes with which base. This information is also provided in the product Data sheets, the User Manuals and the Spare Part Lists.



### CAUTION

Use of incorrect combination of gaskets, bolts and nuts can create severe damages to the product installation and create multiple safety risks.

To obtain a safe and watertight installation the O-ring and retaining bolt stated in the document must be used.

You need to know what base the light fixture will be installed in, in order to choose the correct gasket, bolts and nuts.


**Failure to follow these cautions can result in equipment damage or aircraft FOD.**

## 5.4 Bolt Torque Preventive Maintenance Schedule

An established schedule for checking light fixture bolt torque and bolt condition is mandatory. This is particularly true for areas that are subject to high impact loads from aircraft such as runway status lights, runway touchdown zone lights, runway centerline lights, and taxiway lead-off lights. Although AC 150/5340-26 offers a recommended schedule for periodic checks, these checks should be tailored to the facility based on local conditions such as environmental issues and runway traffic load.

1. Torque according to: FAA Engineering Brief No 83 (latest revision).

**Figure 18: Anti-vibration washer example**



### CAUTION

Per FAA AC 150/5340-30, Chapter 10, and FAA Engineering Brief No 83 (latest revision), it is extremely important that other types of washers, such as split washers, must not be used. Failure to use properly installed anti-vibration lock washers will cause mounting bolts to become loose. The cams (or steps) of each half of the lock washer must face each other.

FAA Cert Alert No. 14-03 refers to AC 150/5340-26 for the frequency of checking bolt torque. AC 150/5340-26 (latest revision) paragraph 5.3.4.1.4, *Bi-Monthly Checks* states: "The torque of the bolts attaching the light fixture to its base should be checked with a calibrated torque wrench – never use an impact wrench."

Regular inspection as outlined in FAA Engineering Brief 83 (latest edition), Canada Civil Aviation Safety Alert Document CASA 2014-05, and any other applicable regulatory guidelines is critical in insuring torque on all bolts is restored to optimum values. Bolts that loosen more often should be inspected and re-torqued on a more frequent basis.

It is especially important to maintain a regular inspection schedule for LED fixtures. Since LED fixtures operate more reliably and are not subject to removal/replacement/re-torque as frequently as would be seen with incandescent fixtures, it is even more important to implement regular torque inspections.

It is critical that remedial action be taken if bolts are found to be loose or missing during inspection. If this occurs, it is important to carefully inspect all structural elements of the mounting system as defined in Installation. Also inspect the base can for general structural conditions such as:

- Is the base can solidly mounted in the pavement, and not moving or rocking during rollovers?
- If a base can extension is present, are all extension attachment bolts tight?

If poor base can structure or mounting system components are not in accordance with regulatory requirements or are in poor condition, it is the airport's responsibility to:

- Increase the frequency of bolt torque inspection to insure that no bolts become loose or missing.
- Quickly replace/repair the mounting system components, which may include replacing the entire base can.

Airport operators must also ensure these maintenance activities are properly documented.

### Digital Asset Tracking and Service Application Information

ALIS is ADB SAFEGATE's new digital asset tracking, inspection and service solution, helps airports easily register airside assets, electronically schedule and track maintenance, and record maintenance and inspection tasks in compliance with ICAO and FAA standards.

Easy to implement and use, cloud-based software enables a more reliable and fail-safe approach to asset tracking and maintenance by always using live field data and eliminating inefficiencies caused by human error. Every asset is registered using GPS data and its status recorded, so airport maintenance teams get a clearer view of maintenance schedules and history, allowing them to manage resources more effectively as well as improve the safety and longevity of airside assets. This increased visibility helps airports plan and schedule preventive maintenance, or undertake corrective maintenance more quickly, to reduce downtime and significantly improve operational availability.

<https://adbsafegate.com/product-center/airfield/airside-services/ALIS-airside-maintenance>

- Easily integrates electronic torque measurements and photometric measurement reports to provide a complete view of the asset's status.
- ALIS can be integrated with the AirTorque or Ingersoll Rand® QX series wrenches, which are used for accurate, ergonomic torque inspections of AGL fixtures. The applied torque can seamlessly be registered in the ALIS system as a part of the maintenance record.
- The iPhone application of ALIS – ALIS Personal – makes it easier than ever to register maintenance actions while working. It will proactively show you which assets you still need to work on and select the closest one to you automatically. ALIS Personal acts as a feedback and information device for the associated torque wrench.



## 6.0 Troubleshooting



### WARNING

Read the instructions in their entirety before starting installation.

Problem	Possible Cause	Corrective Action
LEDs not pulsing (monitored applications)	Defective remote control device	Consult the remote control device's instruction manual.
LEDs not pulsing in Sync. (Autonomous)	Light Units not set correctly	See " <a href="#">IR Remote Control</a> "
LEDs continuously OFF or ON	Failed fixture component	Replace internal fixture PCB or Light Engine.
LEDs not pulsing in Sync.	CCR needs to be reset	Monitored Applications: Once power from the CCR is turned off for 3-seconds and then on again, the RELIANCE Platform II system will re-establish timing with all Remotes and reset any Remotes with replaced components. Autonomous Applications: Turn CCR off for 3 seconds and then on again to re-establish internal fixture PCB timing.
Short LED life	Current too high (series circuit applications)	Check constant current regulator output current levels. Check the label on the isolation transformer and replace if necessary. For example, incorrectly installing a 6.6A/20A transformer will cause very short fixture component life.
	Water in assembly	Inspect the prism. Open light assembly. Clean, dry and inspect light assembly. Replace O-ring. Verify fixture is sealed. See " <a href="#">Cleaning the Light Channel and Prism</a> "
Distorted light beam output	Broken, damaged or wrong prism installed	Check parts list and install correct prism
Water inside optical chamber	Damaged or missing prism seals or top cover O-ring	Replace both prism seals. Replace top cover O-ring. Verify that the fixture is sealed.
	Fixture wires pinched between base can and fixture	A break in the fixture wire insulation will cause water to be drawn into the fixture during the fixture's heating and cooling cycle (when switched on and off). Replace fixture leads. Use care when remounting the fixture on the base can to ensure that the wires do not get pinched.



## 7.0 Parts

### Ordering Code

#### Power/Control

- 1 = LINC 360 Compatible<sup>1</sup>
- 2 = Autonomous, Initial Flash ON<sup>2</sup>
- 3 = Autonomous, Initial Flash OFF<sup>2</sup>
- 4 = BRITE II Compatible<sup>1</sup>

#### Frequency

- 1 = 60 Hz
- 2 = 50 Hz

#### Arctic Option (both G & S)

- 1 = No
- 2 = Yes

#### Notes

- <sup>1</sup> Used on electronically monitored L-852G applications. Must be used with a LINC 360 or BRITE II remote device on new or retrofit applications. This configuration of the L-852G has two cord sets: one for power input and one to connect to the remote device. The remote device cord set receives the "flash" signal from the remote and opens to provide the monitoring feedback of a failed lamp. Requires use of Y-Harness Adapter.
- <sup>2</sup> Used on non-electronically monitored L-852G applications. L-852G input of fixture is connected directly to L-830/L-831 isolation transformer.


Y-Harness Adapter 70A0761

Remote Programming Device<sup>1</sup> 61A0458

#### Note

- <sup>1</sup> Required on autonomous fixtures to modify initial flash ON or OFF or to adjust CCR loading. One device required per installation.

**Figure 19: Pressure Release Screw and Ground Lug**



**Figure 20: IRGS-XXX00**




Figure 21: Parts List and Diagram for Replacing the Prisms )





Figure 22: Bottom Pan with PCBs



## 7.1 Spare Parts

Use the table below to create a sufficiently large stock of spare parts to maintain the IRGS unit. Consider acquiring approximately 10% spare final assemblies (with a minimum quantity of 1) for the total amount of equipment in the field. This allows for repairs to be made in the shop. Components that are more likely to need replacement, such as prisms, should be stocked at higher quantities, while PCB assemblies should be stocked in smaller quantities. If you have questions, contact your ADB representative.

**Table 3: Spares**

Part Number	Description	Notes	Spares
60A2602	Pressure Release Screw F-Range	<a href="#">Figure 19</a>	1
63B0267-011	O-ring L852A/B/C/D	<a href="#">Figure 19</a>	1
72A0401	Aluminum Ground Lug AL/CU & UL 467	<a href="#">Figure 19</a>	4
61A0458	Remote for Autonomous, Unmonitored Applications	<a href="#">Figure 19</a>	2
73A0107-37	L-823 Cordset FAA Class A, Type II Style 1 Plug	<a href="#">Figure 20</a>	4
61A0517	Compression Fitting 1/2"	<a href="#">Figure 20</a>	1
73A0183-10	L-823 Style 1 : AD Light Three Pin	<a href="#">Figure 20</a>	2
60A4537	Cable Strap, AD Light SO	<a href="#">Figure 20</a>	2
48A0415-RED	IRGL Light Engine Low Profile	<a href="#">Figure 20</a>	1
48A0415-TYLW	IRGL Light Engine Low Profile	<a href="#">Figure 20</a>	1
61A0459	Heater Disc, 2 Leads	<a href="#">Figure 20</a>	2
54A0022-8060	Thermostat	<a href="#">Figure 20</a>	2
4071.50.360	Prism Clamp	<a href="#">Figure 21</a>	3
4071.50.030	Gasket Prism Sock Seal	<a href="#">Figure 21</a>	3
63A0993-2	Prism F-ring Narrow Beam Optical Glass	<a href="#">Figure 21</a>	3
63A0986	Prism Flat Seal F-Range	<a href="#">Figure 21</a>	3
4071.50.052	Prism Keeper Plate	<a href="#">Figure 21</a>	3
44A7530-X	L-852G Power Supply with Bracket, L-852G	<a href="#">Figure 22</a>	1
44A7531-X	L-852S Power Supply with Bracket, L-852S	<a href="#">Figure 22</a>	1
44A7273-1	Power Interface Board	<a href="#">Figure 22</a>	1

## Appendix A: SUPPORT

Our experienced engineers are available for support and service at all times, 24 hour/7 days a week. They are part of a dynamic organization making sure the entire ADB SAFEGATE is committed to minimal disturbance for airport operations.

### ADB SAFEGATE Support

#### Technical Support – Global

Customers in Europe, the Middle East, Africa or Asia Pacific are more than welcome to our portal for technical support. Trained in all areas of system issues, troubleshooting, quality control and technical assistance, our highly experienced Technical support specialists are available 24 hours a day, seven days a week to provide assistance over the phone. In the Americas, we also offer live technical support.

#### Live Technical Support – Americas

If at any time you have a question or concern about your product, contact ADB SAFEGATE's US-based technical support specialists, available 24 hours a day, seven days a week, to assist you via phone.

ADB SAFEGATE Americas Technical Service & Support (US & Canada) : **+1-800-545-4157**

ADB SAFEGATE Americas Technical Service & Support (Canada): **+1-905-631-1597**

ADB SAFEGATE Americas Technical Service & Support (International): **+1-614-861-1304**

We can also be reached via email during regular business hours:

Airfield and Gate: **techservice.us@adbsafegate.com**

Gate: **gateservice.us@adbsafegate.com**

We look forward to working with you!


#### Before You Call

When you have an airfield lighting or system control system problem, prior to calling, please ensure the following:

- Review the product's manual and troubleshooting guide.
- Be located with the product ready to troubleshoot.
- Have all necessary information available: airport code/company name, customer id number, contact phone number/email address, product/part number.
- Have a *True RMS* meter available and any other necessary tools.

When calling about an issue with Safedock A-VDGS, we can serve you better if you collect the following information before you call:

- Relevant information regarding the issue you are calling about, such as gate number, flight number, aircraft type and time of the event.
- What, if any, actions have been taken to resolve the issue prior to the call.
- If available, provide a CCTV recording of the incident to aid in aligning the information from the Safedock log file.



#### Note

For more information, see [www.adbsafegate.com](http://www.adbsafegate.com), contact ADB SAFEGATE Support via email at [support@adbsafegate.com](mailto:support@adbsafegate.com) or

Europe: +32 2 722 17 11

Americas: +1 614 861 1304. Press 3 for technical service or press 4 for sales support.

China: +86 (10) 8476 0106

Middle East and Africa: +971 4 452 7575

## A.1 ADB SAFEGATE Website

The ADB SAFEGATE website, [www.adbsafegate.com](http://www.adbsafegate.com), offers information regarding our airport solutions, products, company, news, links, downloads, references, contacts and more.

## A.2 Recycling

### A.2.1 Local Authority Recycling

The disposal of ADB SAFEGATE products is to be made at an applicable collection point for the recycling of electrical and electronic equipment. The correct disposal of equipment prevents any potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. The recycling of materials helps to conserve natural resources. For more detailed information about recycling of products, contact your local authority city office.

### A.2.2 ADB SAFEGATE Recycling

ADB SAFEGATE is fully committed to environmentally-conscious manufacturing with strict monitoring of our own processes as well as supplier components and sub-contractor operations. ADB SAFEGATE offers a recycling program for our products to all customers worldwide, whether or not the products were sold within the EU.

ADB SAFEGATE products and/or specific electrical and electronic component parts which are fully removed/separated from any customer equipment and returned will be accepted for our recycling program.

All items returned must be clearly labeled as follows:

- For *ROHS/WEEE* Recycling
- Sender contact information (Name, Business Address, Phone number).
- Main Unit Serial Number.

ADB SAFEGATE will continue to monitor and update according for any future requirements for *EU directives* as and when *EU member states* implement new *regulations* and or *amendments*. It is our aim to maintain our *compliance plan* and assist our customers.



## Company Addresses

ADB SAFEGATE, Belgium	ADB SAFEGATE BV Leuvensesteenweg 585 B-1930 Zaventem Belgium
Contact: Tel.: +32 2 722 17 11 Fax: +32 2 722 17 64	Email: <a href="mailto:marketing@adbsafegate.com">marketing@adbsafegate.com</a> Internet: <a href="http://www.adbsafegate.com">www.adbsafegate.com</a>
ADB SAFEGATE, Americas	ADB SAFEGATE Americas, LLC 700 Science Blvd Gahanna, OH 43230 USA
Contact: Tel.: +1 (614) 861 1304 Fax: +1 (614) 864 2069	Email: <a href="mailto:sales.us@adbsafegate.com">sales.us@adbsafegate.com</a> Internet: <a href="http://www.adbsafegate.com">www.adbsafegate.com</a>
ADB SAFEGATE, Sweden	ADB SAFEGATE Sweden AB Djurhagegatan 19 SE-213 76 Malmö Sweden
Contact: Tel.: +46 (0)40 699 17 00 Fax: +46 (0)40 699 17 30	Email: <a href="mailto:marketing@adbsafegate.com">marketing@adbsafegate.com</a> Internet: <a href="http://www.adbsafegate.com">www.adbsafegate.com</a>
ADB SAFEGATE, China	ADB SAFEGATE Airfield Technologies Ltd. China Unit 603, D Block, CAMIC International Convention Center, No 3, Hua Jia Di East road, ChaoYang district, Beijing 100102 P.R. China
Contact: Tel.: +86 (10) 8476 0106 Fax: +86 (10) 8476 0090	Email: <a href="mailto:china@safegate.com">china@safegate.com</a> Internet: <a href="http://www.adbsafegate.com">www.adbsafegate.com</a>
ADB SAFEGATE, Germany	ADB SAFEGATE Germany GmbH Konrad-Zuse-Ring 6, D-68163 Mannheim Germany
Contact: Tel.: +49 (621) 87 55 76-0 Fax: +49 (621) 87 55 76-55	Email: <a href="mailto:marketing@adbsafegate.com">marketing@adbsafegate.com</a> Internet: <a href="http://www.adbsafegate.com">www.adbsafegate.com</a>



**Powering Your Airport Performance  
from Approach to Departure**

[adbsafegate.com](https://adbsafegate.com)

Copyright © ADB SAFEGATE, all rights reserved

