


TLP Truck Loading Platform




General Information

Work safe!




Check the distance and the height!




Use platform on both sides!

Point load: max. 150 kg



Distributed load: 200 kg/m²




Inspect the platform before every use!




Keep the platform free from snow, dirt and any objects!




Item Overview




Truck loading platform, module
Code: 2079780 / 764 kg



Platform handrail
– long side
Code: 2079786 / 21 kg



Platform handrail
– short side
Code: 2079787 / 9 kg



Stair
Code: 2079770 / 65 kg



Stair handrail - left
Code: 2079772L / 8 kg




Stair handrail - right
Code: 2079772R / 8 kg



Truck Loading Platform (Single System)


Code: 2079760
812 kg



[mm]

No.	Art. No.	Quantity	Description	Picture
1	2079780	1	Truck loading platform module	
2	2079786	2	Platform handrail long side	
3	2079787	1	Platform handrail short side	
4	2308301	6	Concrete foot	

Truck Loading Platform (Double System)




[mm]

No.	Art. No.	Quantity	Description	Picture
1	2079780	2	Truck loading platform module	
2	2079786	4	Platform handrail long side	
3	2079787	1	Platform handrail short side	
4	2308301	12	Concrete foot	

Stairway

Code: 2079761

81 kg




[mm]

No.	Art. No.	Quantity	Description	Picture
1	2079770	1	Stair	
2	2079772L	1	Stair handrail - left	
3	2079772R	1	Stair handrail - right	



Assembling

1 Unloading with a crane or with a forklift


a



b




2 Check the height of the platforms and the distance between two platforms




Assembling

3 Put a piece of base plate (according to EN 74) under the platform's feet





Min. 150 cm²
Min. width 120 mm
Made of min. 6 mm material



4 Set the height of the platform



Pay attention to the inclination!








Max. inclination of the ground 2° (3,5%)






Assembling

5 Connect all parts of the platform (platforms, handrails and stair)

a Single system




b Double system




max. 50 mm between two platforms

Working with the Platform

1 Driving the platform out (preparing for use)




Work only if all platforms are driven out!




Working with the Platform


2 Truck loading or unloading






Do not use the platform for storing!



Not allowed for any person to be on the truck while loading or unloading!




3 Driving the platform in (before the truck leave)





Ready for the next truck!



Packaging



Max. 4 pcs on one truck.



[mm]

Tammet Oy
Metallikutomonkatu 1
10600 Tammisaari

www.tammet.fi
info@tammet.fi
+358 201 450 201

