



# Easi-Torch

6 Rechargeable LED Torches and  
Docking Station

## Warranty & Support

This product is provided with a one year warranty for problems found during normal usage. Mistreating the Easi-Torch or opening the unit will invalidate this warranty.

All out of warranty repairs will be subject to a replacement fee.

## Technical Support

Please visit [www.tts-group.co.uk](http://www.tts-group.co.uk) for the latest product information.

Email [feedback@tts-group.co.uk](mailto:feedback@tts-group.co.uk) for technical support.

TTS Group Ltd.  
Park Lane Business Park  
Kirkby-in-Ashfield  
Nottinghamshire,  
NG17 9GU, UK.  
Freephone: 0800 318686 Freefax: 0800 137525



## USER GUIDE

[www.tts-shopping.com](http://www.tts-shopping.com)

## Easi-Torch

**WARNING:** Do not dispose of this product in household waste. Hand it over to a collection point for recycling electronic appliances.

**WARNING!** Not suitable for children under 36 months due to small parts – choking hazard.  
Made in China, on behalf of the TTS Group Ltd.



TTS Group Ltd.,  
Park Lane Business Park,  
Kirkby-in-Ashfield,  
Nottinghamshire, NG17  
9GU, UK

TTS Product Code:  
**EL00101**



## Important Information

Please read these instructions carefully before using the Easi-Torches and retain for future reference.

- Easi-Torch contains a non-replaceable, rechargeable battery.
- Do not attempt to remove the battery.
- Do not allow your Easi-Torch to come into contact with water or other liquids.
- In the event of static your Easi-Torch may malfunction. In this case, please switch it off and then back on again to reset it.

## Charging Your Easi-Torch

Before using your Easi-Torch for the first time, the torch will require charging. Place all the torches onto the docking station, plug the power adaptor into the docking station, and a green LED will light on the docking station to show that the docking station is powered, and a red LED will light on each of the torches indicating that they are charging. After approximately four hours the amber LED on the torch will light indicating that the Easi-Torch is fully charged and ready for use.

## Using Your Easi-Torch

A fully charged Easi-Torch will last for approximately two hours continuous use. The battery life indicator (above the on/off switch indicates the remaining battery life (100%, 75%, 50%, 25%). When less than 10% of the battery life remains, the red LED will begin to flash. When this occurs the torch should be turned off and returned to the docking station to recharge. Note the torch must be turned OFF or it will not recharge.

## Easi-Torch Charger

The Easi-Torch is supplied with a charging adaptor. The adaptor is supplied with a UK plug only.

The safety isolating transformer to be used with the Docking Station should be regularly examined for potential hazards such as damage to the cable, cord, plug, enclosure or other parts. In the event of any damage, the Docking Station must not be used until the damage has been properly repaired.

- The Docking Station is not intended for children under 3 years old.
- The transformer is not a toy.
- The Docking Station must only be used with the recommended transformer.
- Toys liable to be cleaned with liquids are to be disconnected from the transformer before cleaning.

## Specifications

Specification	
Working	Voltage 2.4V dc
Charge	Voltage 5V dc
Charge current	100mA
Temperature range	-20 to 80°C
Battery life	2 hours continuous use (approx)
Recharge time	4 hours (approx)

## Troubleshooting

Easi-Torch is designed to work reliably and predictably in all normal conditions. However, it is possible that problems may occur. Please check the following before contacting technical support:

Problem	Solution
Red LED flashes	Battery is very low. Recharge the Easi-Torch
Easi-Torch does not charge	The Easi-Torch must be switched off prior to placing on charge