


JET 10T HYDRAULIC TOE JACK PRODUCT # 149125



REF	PART NUMBER	DESCRIPTION	REQ	REF	PART NUMBER	DESCRIPTION	REQ
1	PMS-JTJ10SV-01	JHTJ BODY	1	21	PMS-JTJ10SV-21	JHTJ SNAP RING	1
2	PMS-JTJ10SV-02	JHTJ PUMP PLUNGER	1	22	PMS-JTJ10SV-22	JHTJ STUFFING RING	1
3	PMS-JTJ10SV-76	JHTJ PUMP BACKUP RING	1	23	PMS-JTJ10SV-76	JHTJ CYLINDER PACKING	1
4	PMS-JTJ10SV-76	JHTJ PUMP PACKING	1	24	PMS-JTJ10SV-24	JHTJ STOPPER RING	1
5	PMS-JTJ10SV-05	JHTJ PUMP PLUNGER PIN	1	28	PMS-JTJ10SV-76	JHTJ OIL PLUG	1
6	PMS-JTJ10SV-06	JHTJ PUMP STAY PIN	1	29	PMS-JTJ10SV-29	JHTJ HORIZONTAL PIN	1
7	PMS-JTJ10SV-07	JHTJ HANDLE SOCKET ASSY	1	30	PMS-JTJ10SV-30	JHTJ VERTICAL PIN	1
8	PMS-JTJ10SV-08	JHTJ HANDLE	1	31	PMS-JTJ10SV-31	JHTJ RAM SPRING	1
9	PMS-JTJ10SV-09	JHTJ SNAP RING	1	32	PMS-JTJ10SV-32	JHTJ RAM SPRING STOPPER RING	1
10	PMS-JTJ5SV-10	JHTJ VALVE BALL	2	34	PMS-JTJ5SV-34	JHTJ SAFETY VALVE BALL	1
11	PMS-JTJ5SV-11	JHTJ VALVE SPRING	2	35	PMS-JTJ5SV-35	JHTJ SAFETY VALVE BALL SHEET	1
12	PMS-JTJ5SV-12	JHTJ VALVE PLUG	2	36	PMS-JTJ5SV-36	JHTJ SAFETY VALVE SPRING	1
14	PMS-JTJ10SV-76	JHTJ RELEASE PACKING	1	37	PMS-JTJ5SV-37	JHTJ SAFETY VALVE ADJ SPRING	1
15	PMS-JTJ5SV-15	JHTJ RELEASE ASSY	1	38	PMS-JTJ5SV-38	JHTJ SAFETY VALVE PLUG	1
16	PMS-JTJ10SV-16	JHTJ RAM	1	71	PMS-JTJ10SV-71	JHTJ HANGER	1
17	PMS-JTJ10SV-17	JHTJ RAM PACKING SHEET	1	72	PMS-JTJ10SV-72	JHTJ PUMP BASE	1
18	PMS-JTJ10SV-76	JHTJ RAM BACKUP RING	1	73	PMS-JTJ5SV-73	JHTJ PUMP STOPPER A	1
19	PMS-JTJ10SV-76	JHTJ RAM PACKING	1	74	PMS-JTJ5SV-74	JHTJ PUMP STOPPER B	1
20	PMS-JTJ10SV-20	JHTJ RAM GUIDE RING	1	75	PMS-JTJ5SV-75	JHTJ RETURN SPRING	1
21	PMS-JTJ10SV-21	JHTJ SNAP RING	1	76	PMS-JTJ10SV-76	JHTJ HYD REPAIR KIT	1