


HPS140 HAND PUMP SINGLE ACTING , TWO SPEED

PROD NO. 033102
MOD NO. HPS140



**HPS140 HAND PUMP SINGLE
ACTING , TWO SPEED**PROD NO. 033102
MOD NO. HPS140

REF	Part Number	Description	REQ	REF	Part Number	Description	REQ
1	PEP-HPS140-01	Valve Block	1	33	PEP-HPS140-33	Handle	1
2*	PEP-HPS140-02	Copper Washer	1	34	PEP-HPS140-34	Screw	2
3	PEP-HPS140-03	Filter	1	35*	PEP-HPS140-35	O-ring	2
4	PEP-HPS140-04	Bolt	1	36	PEP-HPS140-36	Screw	1
5	PEP-HPS140-05	Stem	1	37	PEP-HPS140-37	Spring	1
6*	PEP-HPS140-06	O-ring	1	38	PEP-HPS140-38	Ball Seat	1
7	PEP-HPS140-07	Oil Reserve	1	39	PEP-HPS140-39	Steel Ball	1
8*	PEP-HPS140-08	Gasket	1	40	PEP-HPS140-40	Screw	1
9	PEP-HPS140-09	Nut	1	41	PEP-HPS140-41	Spring	1
10*	PEP-HPS140-10	O-ring	1	42	PEP-HPS140-42	Cone Valve	1
11	PEP-HPS140-11	Oil Plug	1	43	PEP-HPS140-43	Bolt	5
12	PEP-HPS140-12	Bolt	1	44	PEP-HPS140-44	Washer	1
13	PEP-HPS140-13	Filter	1	45*	PEP-HPS140-45	O-ring	1
14	PEP-HPS140-14	Snap Ring	1	46*	PEP-HPS140-46	Gasket	1
15*	PEP-HPS140-15	O-ring	1	47	PEP-HPS140-47	Pump Cylinder	1
16	PEP-HPS140-16	Air Plug	1	48	PEP-HPS140-48	Bolt	1
17	PEP-HS1S40-17	Handle	1	49	PEP-HPS140-49	Nylon Ball	1
18	PEP-HPS140-18	Bolt	2	50	PEP-HPS140-50	Socket	1
19	PEP-HPS140-19	Steel Ball	4	51	PEP-HPS140-51	Pin	2
20	PEP-HPS140-20	Spring	3	52	PEP-HPS140-52	Snap Ring	6
21*	PEP-HPS140-21	Copper Washer	3	53*	PEP-HPS140-53	O-ring	1
22	PEP-HPS140-22	Screw	3	54	PEP-HPS140-54	Link Rod	1
23*	PEP-HPS140-23	Copper Washer	3	55	PEP-HPS140-55	Cover	1
24	PEP-HPS140-24	Bolt	3	56	PEP-HPS140-56	Filter	1
25*	PEP-HPS140-25	O-ring	1	57	PEP-HPS140-57	Snap Ring	1
26	PEP-HPS140-26	Release Rod	1	58	PEP-HPS140-58	End Cap	1
27*	PEP-HPS140-27	O-ring	1	59	PEP-HPS140-59	Pin.	1
28	PEP-HPS140-28	Release Seat	1	60*	PEP-HPS140-60	Copper Washer	1
29	PEP-HPS140-29	Bolt	2	61	PEP-HPS140-61	Screw	1
30	PEP-HPS140-30	Knob	1	62	PEP-HPS140-62	Cover	1
31	PEP-HPS140-31	Bolt	1	63	PEP-HPS140-63	Bolt	4
32	PEP-HPS140-32	Handle Sleeve	1				

* Items included in Repair Kit, Repair Kit order number: PEP-HPS140-RK