


PARTS SCHEMATIC



PARTS LIST

Key Number	Description	Qty.
1	Star-head Screw Assembly	6
2	Left Safety Guard Cover	1
3	Hex Nut	1
4	Flange	4
5	Wheel (6 x 3/4 x 1/2")	1
6	Star-head Screw	6
7	Left Safety Guard Plate Assembly	1
8	Left Spark Shield	1
9	Flat Washer	2
10	Lock Washer	8
11	Star-head Screw	4
12	Star-head Screw	4
13	Left Work Rest	1
14	Locking Knob	2
15	Left Eye Shield Mounting Rod	1
16	Flat Washer	2
17	Lock Washer	4
18	Star-head Screw	2
19	Left Eye Shield Assembly	1
20	Eye Shield Locking Knob	2
21	End Cap	2
22	Lamp Lock nut	1
23	Spring Wave Washer	1
24	Bearing	2
25	Special Nut	2
26	Toothed Lock Washer	3
27	Cord Bushing	1
28	Flat Washer	6
29	Lock Washer	6

Key Number	Description	Qty.
30	Star-head Screw	1
31	Base	1
32	Switch Plate	1
33	Single Switch	1
34	Coolant tray clip	1
35	Star-head Screw	2
36	Coolant tray	1
37	Plate	1
38	Star-head Screw	4
39	Rubber Foot	4
40	Star-head Screw	2
41	Hex Nut	1
42	Capacitor support	1
43	Capacitor 8 μ F300 V	1
44	Star-head Screw	2
45	Lamp Assembly	1
46	Stator	1
47	Rotor	1
48	Hex Nut	4
49	Right Spark Shield	1
50	Right Safety guard plate Assembly	1
51	Wheel (6 x 3/4 x 1/2")	1
52	Hex Nut (White)	1
53	Right Safety Guard Cover	1
54	Right Work Rest	1
55	Right Eye Shield Mounting Rod	1
56	Eye Shield with Magnifier	1
57	Cord Clip	4
58	Cord & Plug	1