


JET 5T HYDRAULIC TOE JACK PRODUCT # 149123



REF	PART NUMBER	DESCRIPTION	REQ	REF	PART NUMBER	DESCRIPTION	REQ
1	PMS-JTJ5SV-01	JHTJ BODY	1	19	PMS-JTJ5SV-76	JHTJ RAM PACKING	1
2	PMS-JTJ5SV-02	JHTJ PUMP PLUNGER	1	20	PMS-JTJ5SV-20	JHTJ RAM GUIDE RING	1
3	PMS-JTJ5SV-76	JHTJ PUMP BACKUP RING	1	21	PMS-JTJ5SV-21	JHTJ SNAP RING	1
4	PMS-JTJ5SV-76	JHTJ PUMP PACKING:USE	1	22	PMS-JTJ5SV-22	JHTJ STUFFING RING	1
5	PMS-JTJ5SV-05	JHTJ PUMP PLUNGER PIN	1	23	PMS-JTJ5SV-76	JHTJ CYLINDER PACKING	1
6	PMS-JTJ5SV-06	JHTJ PUMP STAY PIN	1	24	PMS-JTJ5SV-24	JHTJ STOPPER RING	1
7	PMS-JTJ5SV-07	JHTJ HANDLE SOCKET ASSY	1	28	PMS-JTJ5SV-76	JHTJ OIL PLUG	1
8	PMS-JTJ5SV-08	JHTJ HANDLE	1	34	PMS-JTJ5SV-34	JHTJ SAFETY VALVE BALL	1
9	PMS-JTJ5SV-09	JHTJ SNAP RING	1	35	PMS-JTJ5SV-35	JHTJ SAFETY VALVE BALL SHEET	1
10	PMS-JTJ5SV-10	JHTJ VALVE BALL	2	36	PMS-JTJ5SV-36	JHTJ SAFETY VALVE SPRING	1
11	PMS-JTJ5SV-11	JHTJ VALVE SPRING	2	37	PMS-JTJ5SV-37	JHTJ SAFETY VALVE ADJ SPRING	1
12	PMS-JTJ5SV-12	JHTJ VALVE PLUG	2	38	PMS-JTJ5SV-38	JHTJ SAFETY VALVE PLUG	1
14	PMS-JTJ5SV-76	JHTJ RELEASE PACKING:USE	1	71	PMS-JTJ5SV-71	JHTJ HANGER	1
15	PMS-JTJ5SV-15	JHTJ RELEASE ASSY	1	72	PMS-JTJ5SV-72	JHTJ PUMP BASE	1
16	PMS-JTJ5SV-16	JHTJ RAM	1	73	PMS-JTJ5SV-73	JHTJ PUMP STOPPER A	1
17	PMS-JTJ5SV-17	JHTJ RAM PACKING SHEET	1	74	PMS-JTJ5SV-74	JHTJ PUMP STOPPER B	1
18	PMS-JTJ5SV-76	JHTJ RAM BACKUP RING	1	75	PMS-JTJ5SV-75	JHTJ RETURN SPRING	1
19	PMS-JTJ5SV-76	JHTJ RAM PACKING:USE	1	76	PMS-JTJ5SV-76	JHTJ HYD REPAIR KIT	1