

STRONGARM

30 TON
HAND JACK
Models 330A

REPAIR PARTS LIST

01	Base	(1)
01-2	Filter	(1)
01-4	Washer	(1)
01-5	Spring Plunger	(1)
01-6	Spring	(1)
01-7	Screw Safety Valve	(1)
01-8	Seal	(1)
01-9	Guard Screw	(1)
02	Steel Ball 1/4"	(3)
03	Seal	(1)
04	Release Valve	(1)
05	O-Ring	(1)
06	Cylinder	(1)
07	Washers	(1)
08	Check Valve Kit	(1)
09	Seal	(1)
10	Cap Washer	(1)
11	Pump Cylinder	(1)
12	O-Ring	(1)
14	Cup Seal	(1)
15	Back-up Ring	(1)
16	Pump Plunger	(1)
17	Handle Sleeve	(1)
18	Pin	(1)
19	Cotter Pin	(1)
19-1	Cotter Pin	(1)
20	Pin	(1)
21	Packing	(1)
22	Reservoir	(1)
25	Ram	(1)
26	Bushing	(1)
27	Cup Seal	(1)
28	Cap Washer	(1)
29	Snap-Ring "C"	(1)
30	Packing	(1)
31	Top Nut	(1)
32	O-Ring	(1)
34A	Handle	(1)

