DATA SHEET



790MM ACTIVESMART[™] FRIDGE

Model no:

RF170WDLUX4, RF170WDLUX5

(refer page 2 for metric measurements)

Product Dimensions	in
Overall height* of fridge	67 1/2"
Overall width of fridge	31 3/32"
© Depth of fridge door and gasket (excludes handle)	2 3/4"
 Depth of fridge door and chassis (excludes handle) 	27 3/8"
Depth of fridge chassis (does not include fridge door)	24 5/8"
© Height from bottom datum to top of fridge door	66 9/16"
© Height of feet (adjustable)	15/16″
Height from bottom datum to top of top handle	52 3/8"
I Height from bottom datum to bottom of top handle	27 1/8"
 Height from bottom datum to bottom of top door 	25 5/32"
 Height from bottom datum to top of bottom door 	24 21/32"
L Height from bottom datum to centerline of bottom handle	22 3/16"
Thickness of handles	5/8″
 Height from bottom datum to bottom of bottom door 	13/16″
 Depth of handle (measured from front of door) 	1 5/8"
Depth of door (open at 90°) (measured from front of door)	29 5/16"
© Depth of drawer (open) (measured from front of drawer) excluding handle	14 3/4"
Rotation of door (open)	138°

* Includes mounted feet

in
68 5/16"
25/32"
5 5/16"
1 3/16"

DATE: 06.10.2015

IMPORTANT NOTE: Throughout this guide, dimensions may vary by $\pm 2mm$ (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com

Fisher&Paykel _____

DATA SHEET



790MM ACTIVESMART[™] FRIDGE

Model no: RF170WDLUX4, RF170WDLUX5

(refer page 1 for imperial measurements)

Product Dimensions	mm
Overall height* of fridge	1715
Overall width of fridge	790
© Depth of fridge door and gasket (excludes handle)	70
 Depth of fridge door and chassis (excludes handle) 	695
E Depth of fridge chassis (does not include fridge door)	625
F Height from bottom datum to top of fridge door	1691
© Height of feet (adjustable)	24
(i) Height from bottom datum to top of top handle	1331
 Height from bottom datum to bottom of top handle 	689
 ④ Height from bottom datum to bottom of top door 	639
Beight from bottom datum to top of bottom door	627
() Height from bottom datum to centreline of bottom handle	564
Thickness of handles	16
Height from bottom datum to bottom of bottom door	21
 Depth of handle (measured from front of door) 	41
P Depth of door (open at 90°) (measured from front of door)	745
© Depth of drawer (open) (measured from front of drawer) excluding handle	375
Rotation of door (open)	138°

* Includes mounted feet

mm
1735
20
135
30

DATE: 06.10.2015

IMPORTANT NOTE: Throughout this guide, dimensions may vary by $\pm 2mm$ (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com

Fisher&Paykel _____