


# STACKING COMPATIBILITY

FRONT LOAD WASHER/DRYER  
INSTALLATION COMBINATIONS

# FISHER & PAYKEL

NZ AU BI EU SG

## BEFORE YOU BEGIN



**To ensure stacking stability a stacking kit MUST BE USED between the products and fitted correctly to the washing machine and dryer, as per the stacking kit instructions.**

- Ensure you use the compatible stacking kit for your washer and dryer combination.
- Stacking kit is available from your Fisher & Paykel dealer, online or from a Fisher & Paykel service technician.
- The power plug must be accessible.

**The following stacking configurations are not stable and MUST NOT be used:**

- A washer stacked on top of a dryer
- A washer on top of a washer
- Stacking a dryer on top of a washer not listed as compatible

## STACKED WASHER & HEAT PUMP/CONDENSING DRYER

STACKING KIT	WASHERS	DRYERS
428122	WH1260, WH1160, WH1060, WH9060, WH8560, WH8060, WH7560	DE8060P, DH8060P
428159	WH1260, WH1160, WH1060, WH9060, WH8560, WH8060P	DH9060
99373 (graphite)	WH1060 graphite	DH9060 graphite

## STACKED WASHER & VENTED DRYER

STACKING KIT	WASHERS	DRYERS
428069	WH1260, WH1160, WH1060, WH9060, WH8560, WH8060, WH7560	DE7060, DE6060, DE5060, DE4560M