FISHER & PAYKEL

DATA SHEET

30" Pro Induction Cooktop

Model no: CI304PTX4



IMPORTANT NOTE: Throughout this guide, dimensions may vary by $\pm 2mm$ (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit fisherpaykel.com

FISHER & PAYKEL

DATA SHEET

30" Pro Induction Cooktop

Model no: CI304PTX4



IMPORTANT NOTE: Throughout this guide, dimensions may vary by $\pm 2mm$ (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit fisherpaykel.com