DATA SHEET



24'' SINGLE DISHDRAWER[™] TALL

Model no:

DD24SCTW9

(refer page 2 for metric measurements)

Dimensions	
Overall height of DishDrawer™	17 7/8"
⑧ Overall width of DishDrawer™	23 9/16"
© Overall depth of DishDrawer™	22 9/16"
 Depth of chassis 	21 3/4"
© Depth of front panel	13/16"
F Height of front panel	17 3/16"
I Height from top of door to top of chassis	5/16"
 Height of ventilation gap below front panel 	1/4"
I Maximum extension of drawer from front datum	21 9/16"

Minimum Clearances	in
Height of cavity	min 18"
Width of cavity	23 5/8"
Depth of cavity	min 22 1/16"
Minimum clearance from a corner cupboard	1/2"

Note: Service outlet at rear extends both sides, hoses and cords can be routed to either or both.

DATE: 07.09.2016

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit www.fisherpaykel.com

Fisher&Paykel _____

DATA SHEET



24" SINGLE DISHDRAWER[™] TALL

Model no:

DD24SCTW9

(refer page 1 for imperial measurements)

Dimensions	mm
Overall height of DishDrawer™	454
B Overall width of DishDrawer™	599
© Overall depth of DishDrawer™	573
 Depth of chassis 	553
© Depth of front panel	20
© Height of front panel	437
© Height from top of door to top of chassis	8
Height of ventilation gap below front panel	7
Maximum extension of drawer from front datum	547

Minimum Clearances	mm
Height of cavity	min 456
Width of cavity	600
Depth of cavity	min 560
Minimum clearance from a corner cupboard	13

Note: Service outlet at rear extends both sides, hoses and cords can be routed to either or both.

DATE: 07.09.2016

IMPORTANT NOTE: Throughout this guide, dimensions may vary by $\pm 2mm$ (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit www.fisherpaykel.com

Fisher&Paykel _____