
HD108N Automatic Water Leveller Installation Instructions








Automatic Water Leveller Installation Instructions



Use P.T.F.E. tape to make threaded joints, liquid jointing must not be used

*The water supply to the HD108N must be compliant with local regulations. For the UK, the supply should be via a suitable header tank with an overflow, NOT a direct mains supply. Refer to the supplied filling valve instructions re: pressure restrictors

ENHD108N Automatic Water Leveller





Certikin International Ltd, Unit 4 Tungsten Park, Colletts Way, Witney, Oxon, OX29 0AX

