



TECHNICAL DATA SHEET

RENOLIT ALKORCLEAN Cleaning / Degreasing Agent - Type 81026

Application:

RENOLIT ALKORCLEAN is a Cleaning or Degreasing agent used to clean the flotation line on swimming pool liners and reinforced membranes.

Technical Data:

- Base: 2-Propanol
- Color: Colorless
- Viscosity: Approx. 2,08 mPa·s
- Specific Density: 0.89 +/- 0.01 g/cm³
- Flash point: 12°C < 21°C (Highly flammable liquid and vapour)
- Toxicity: Causes serious eye irritation. May cause drowsiness or dizziness.

Description:

RENOLIT ALKORGLUE 81045 for pools is a highly versatile contact adhesive suitable as a general purpose adhesive for the installation of reinforced membrane and other accessories such as geotextile. Unlike many equivalent industrial-use contact glues, it is Toluene-free.

The product is ready for use and does not require additional solvents. Utensils should be cleaned with acetone or THF solvents for metallic elements.

Use:

Ensure that the surfaces to be bonded are completely clean. Apply the adhesive to both surfaces with a spatula, brush or roller. Do not bring the two faces together until the adhesive is completely dry, this will take between 30 and 60 minutes depending on the ambient temperature and humidity. Apply uniform pressure on the whole surface to be glued. The glue dries slowly, so slight corrections during the installation of the reinforced membrane can be made. After 30-60 minutes, it will no longer be possible to make further corrections. The contact adhesive must not be applied to the area to be welded as this would prevent homogeneous welding. Any unwanted stains can be removed with solvents once the adhesive has completely dried.

Format:

One litter bottles. Six bottles carton.

Shelf life:

5 years

Warning:

As it is flammable product, it must be kept well away from fire, flames and sparks during its storage and usage; also, it should only be used in well-ventilated areas. Do not smoke during its application. Keep container tightly closed. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

Storage:

Store in a well-ventilated place.

For more information:

Read MSDS

January 14th, 2020