

## JET Manual Ball Bearing Trolley Installation and Safety Instructions

### Specifications

Product No.	Model No.	Capacity	Flange Width (min. - max.)
120251	1/2 SBT	1/2 ton	3-1/4" - 8"
120252	1 SBT	1 ton	4" - 8"
120253	1-1/2 SBT	1-1/2 ton	4" - 8"
120254	2 SBT	2 ton	4" - 8"
120255	3 SBT	3 ton	4" - 8"
120256	5 SBT	5 ton	4-1/4" - 8-1/8"
120257	10 SBT	10 ton	4-5/8" - 8-1/8"

JET Manual Ball Bearing Trolleys are designed to be used on either "I" or wide flange beams.

### WARNING

1. Beam must be properly installed and rated for anticipated loads.
2. Do not install trolley on beams of unknown capacity.
3. Do not install trolley on damaged or deformed beams.
4. JET trolleys are designed to be used with hoists of the same rated capacity. Never use a hoist with a capacity greater than the capacity of the trolley.
5. Never subject trolley to a side pull or load. Load must be centered directly under the hoist/trolley assembly.
6. Make sure load is stable and secure before moving.
7. Never lift load more than is necessary to safely move it.
8. Always follow installation instructions.
9. Do not use if under the influence of drugs, alcohol, or medication.

### Installation Instructions

1. Trolley must be installed on a beam with a minimum clearance (wheels to flange) of 1/16" to a maximum of 1/8". Reference "A" on both sides of the beam.
2. To extend trolley width, remove washer spacers from center bolt and place between hanger bracket "C" and fixed spacer "D". Note: washer spacers must be moved in sets of two, one on either side of the hanger bracket, as the hanger bracket must always remain centered between the trolley side plates.
3. Once trolley is spaced properly, install remaining washer spacers on the center bolt (same number on both sides) on the out side of the side plates. Install nuts and split pins "B". Do not over tighten nuts. Tighten nuts and then back nuts off to align the nut with hole in shaft for split pin. Insert split pin through both nuts and bend one end of split pin.
4. Recheck wheel clearance "A" and readjust if necessary.

