ABOVE-GROUND AUTOMATIC POOL COVER

CONFLENT MODEL 120 Nm



Œ

INSTALLATION AND MAINTENANCE MANUAL



Serial N°:

Revision number :S 003-2008-01-01

TABLE OF CONTENTS


- Personnel and material required for unloading and assembly.	Page 02/21
- Components of the automatic pool cover.	Page 03/21
- Warning.	Page 04/21
- Bearing sides and motor assembly.	Page 04/21
- Bearing sides with roller shaft assembly.	Page 05/21
- Assembly in the pool.	Page 06/21
- General installation in the pool.	Page 07/21
- Fixing the plates in the wall level.	Page 08/21
- Slat assembly.	Page 09/21
- Slat direction.	Page 10/21
- Slat with melted caps Assembly.	Page 11/21
- Stair assembly.	Page 12/21
- Partition assembly.	Page 13/21
- Installation of beam's cases.	Page 14/21
- Mounting of beam and counterweights.	Page 15/21
- Electrical installation.	Page 16/21
- Electrical connections.	Page 17/21
- Safety Brackets & Straps Positioning.	Page 18; 19; 20; 21/21

UNLOADING











TOOLS REQUIRED FOR ASSEMBLY



Drill and drill bits for concrete Ø 6 and Ø10 Flat head screwdrivers Phillips screwdrivers Spirit level 10 - 13 – 17 wrench Nippers Wire strippers 5 and 6 mm Allen wrench Hammer Standard and long (10 m) measuring tape Grease Metal saw



COMPONENTS OF THE AUTOMATIC POOL COVER



WARNING

We recommend before performing any operation to read carefully the installation instructions and to check the following points:

- Check the wall's hardness and particular those places where the bearing stands have to be placed.

- Make sure there is an efficient overflow drain; the overflow's shaft will be installed at 100 mm from the wall. (The overflow drain tube is Ø 40mm mini)

- It is recommendable an automatic water level.

- Your automatic cover have been manufactured according to the manufacturing sheet, however we suggest checking, before doing any performance, that the slats can be properly placed in the pool.


- Make sure that the power feeding is carried out from the right side of the pool.

- The electrical installation must be done by a properly trained and qualified electrician.

- The electrical box must be protected by a 30mA circuit breaker. (Not supplied by us).

BEARING SIDES AND MOTOR ASSEMBLY

MOTOR SIDE



<u>Note:</u> The assembly of bearing sides is not obligatory, the horizontal parts can be well positioned and fixed on the wall level to immediately fix the vertical parts on them.


BEARING SIDES WITH ROLLER SHAFT ASSEMBLY

FIXING OF SHAFT ON MOTOR BRACKET

- Place the motor side of the roller shaft next to the motor bracket and put the power cable into the protection groove.

- Attach the motor plate to the fixed part on the vertical side.

- Grease the fixed shaft \emptyset 200mm, place it between the two parts immobilize it with the stainless steel pin.





FIXING OF SHAFT ON BEARING SIDE

- Place the bearing side of the roller shaft next to the bearing side.

- Make sure there is a Ø8mm bolt at the end of bearing shaft and attach the black bearing with the bearing side, center this one and fix them with the two nuts.


- Check that bearing shaft slides well through the tube of the roller shaft!






ASSEMBLY IN THE POOL

- Loose the fixing screw of the shaft bearing's fixing ring and introduce the set: shaft – bearing – bearing shaft towards the interior of roller shaft with a minimum dimension to make the assembly easier.




Retaining ring


- Proceed with the assembly of the system between two workers



ENGLISH

GENERAL INSTALLATION IN THE POOL





Note: The axis of the roller shaft and bearing should be perfectly parallel for a good assembly and at 90° to the pool length wall.

ATTENTION: In presence of rays behind the roller, you will have:


- To if required off-set the roller towards the basin by you ensuring that slats once rolled up on the roller shaft do not touch the liner in the rays

- - You to ensure that the assembly of the beam and the pit cover is always realizable in spite of the new positioning of the roller

FIXING OF PLATES


After having placed the roller in the pool, it is important to put the bearings of the roller together against the walls of the pool.

To do so, slide the bearing shaft and fix it by tightening the hexagonal M8 screw of the ring (see drawings) against the roller's tube.



Retaining ring

After having decided the location and angle brackets of the pool, according to the installation system indicated on the previous page, it will be best to fix the plates through a Ø10mm drill, dowels and stainless steel screws included in the pack.



Drill Ø 10mm depth 100mm


Placing of brass dowels Ø10 mm and stainless steel countersunk-head screw M8×60

SLAT ASSEMBLY

* Immediately after taking the slats out of the packaging, they should be put into the water to prevent any possible deformation.

*The number of slats has been determined according to the length of the pool, though there are 4 extra slats.


* The first set of slats is easily recognisable as it has the straps to be fastening to the roller.




*Slide the strap under the fastening plates.

*Centre the cover in the pool leaving enough space on both sides.


*Tighten the attachment plates with a screwdriver




* Bring closer the set of 7 slats to assemble them.




ASSEMBLING OF SLATS WITH MELTED CAPS:




Phase 1: Place both slats (see above) wing to groove. Be careful with the slats direction.



<u>Phase 2:</u> Slide the slats along. Stop it at the when the edges of of the slats are on line.







Phase 3:

Place the removable wing on to the


and assemble the wing on to the cap

Do the same for the following ones.






- 1°) Put the stair slats on the water
- 2°) Assemble the slats until the stairs are completely assembled.
- 3°) Centre the big width slats in the pool (allowed dimension X: from both sides of the pool)
- 4°) Centre the stair using this slat.



To assemble the stair slats to the pool slats, proceed as follows:

► Mark the position of both cap edges of the stair slat on the wing of the long width slat.

► Make two notches of a cap dimension on both sides of the stair on the wing of the long width slat without hurting the waterproof of the slat.




INSTALLATION OF BEAM'S CASES


The installation of the beam's cases is rigorous. Two cases can come up:

A) With coping recoiling from 50mm/ vertical wall of the pool:

The coping stones have been cut (in the case of existing coping stone) or installed moving back from 50 mm (new pool)



B) Without coping stone, with stainless steel frames angles to attach to the wall:



Note: In the case of a model with partition, see also page 13/25


MOUNTING OF BEAM AND COUNTERWEIGHTS

1: Place the two beam support brackets on the embedding parts for the beam support, previously fixed, or directly on the wall, using screws.

2: Slide the counterweights along the beam slot and place Aluminium beam on support bracket.

3: Adjust the length of the counterweight when cover is completely unrolled over the pool surface. The counterweight should not touch the floor.


4: Place pit cover as indicated in the diagram (note: the beam section has been calculated to withstand pit cover only. Do not cover with concrete stabs).



ELECTRICAL INSTALLATION


The electrical installation must be done in accordance with C15100 and P91C by a properly trained and qualified electrician

Protect the 220 Volts power for the box with a 30 mA circuit breaker (Not included)




electrolyser's documentation for the connexion)

ENGLISH




BRACKET AND STRAP POSITION




Warning: The position of the brackets is subject to the position of the skimmers in the pool. If these lasts bother the positioning of the safety Brackets, the positioning of the Brackets will be done taking into account the safety Brackets on the slats panels (If necessary move the straps)


POSITION OF BRACKETS AND THE STRAPS




SAFETY BRACKETS POSITIONING: ABS BRACKETS:




1) When positioning the brackets make sure the shaft of the brackets is placed at 500 mm from the edge of the pool.



2) Pin the supports. Put the strap between the fixation plate and the bracket and keep the strap tense.





3) Tighten the screws until complete closing of the brackets.



Bracket Inox to be fixed to the wall + screws:


1) When positioning the safety brackets the shaft of the brackets must be return type placed at 500 mm from the edge of the pool.






2) Screw the supports. Put the return safety strap.

3) Clip both sides together.




Inox Bracket for model under construction + screws:

1) When positioning the safety brackets, The shaft of the brackets must be put at 500 mm from the edge of the pool.




 Put the pin M8 in the Ø10 wholes.
 Screw until complete closing of the brackets. Put the return safety strap in the brackets.





3) Clip both sides together.

Inox Brackets for renovation model + screws:



1) Cut the coping stone with a angle grinder






2) Make two Ø10 wholes. Place the M8 pin in the wholes. Screw until complete closing of the safety brackets.


Put the straps through as per drawings 2 and 3.

3) Replace the coping stone cut with an adequate product.


ABS brackets INOX support:



1) When placing the safety brackets, The shaft of the brackets must be placed at 500 mm from the edge of the pool.



2) Screw the supports.Put the strap through the fixation plate and the strap.Clip both sides of the strap and keep it tense.



3) Tighten the screws until complete closing of the brackets.



ATTESTATION DE CONFORMITE

aux exigences de sécurité de la norme NF P 90-308 (mai 2004) Eléments de protection pour piscines enterrées non closes privatives à usage individuel ou collectif – Couvertures de sécurité et dispositifs d'accrochage

Certificate of Conformity with the safety requirements of NF P 90-308 (May 2004) Standard Protective elements for in-ground, barrier-free, private or collective use swimming pools – Safety covers and securing devices

Type de couverture de sécurité Type of safety cover:	:	Couverture de type volet automatique
Modèle Model	:	ROUSSILLON
Fabricant Manufacturer:	:	EUROPEENNE DE COUVERTURE AUTOMATIQUE 661 rue J.B. Biot – Espace Polygone 66000 PERPIGNAN
Demandeur de l'attestation Applicant:	:	EUROPEENNE DE COUVERTURE AUTOMATIQUE 661 rue J.B. Biot – Espace Polygone 66000 PERPIGNAN

Au vu du rapport d'examen sur dossier référencé E020017/CQPE/5, la couverture essayée est déclarée conforme aux exigences du document de référence.

On the basis of the results contained in the report reference E020017 /CQPE/5, the safety cover tested is declared in conformity with the requirements of the above referenced document.



Cette attestation est délivrée dans les conditions suivantes :

- 1. Elle ne s'applique qu'à l'article essayé et pour les essais réalisés ou pour les informations qui sont consignés dans le rapport référencé d'dessus. "Le LNE décline toute responsabilité en cas de non-conformité d'un des éléments de l'article essayé pour lequel le demandeur a fourni au LNE un certificat ou une garantie de la conformité aux normes en vigueur, le demandeur étant seul responsable de la véracité des documents qu'il produit au LNE."
- Elle n'implique pas qu'une procédure de surveillance ou de contrôle de fabrication ait été mise en place par le LNE.
- La conformité à la norme référencée ci-dessus n'exonère pas de la conformité à la réglementation en vigueur.
- Des copies peuvent être délivrées sur simple demande auprès du demandeur.

Trappes, le 2 novembre 2004

Le Chef de la Division Produits pour l'Enfance Head of Childhood Products Division

Nicole COURCAULT

This certificate is issued under the following conditions:

- It applies only to the tested item and to the tests or information specified in the repor referenced above. "The LNE declines any responsibility in the event of non conformity for one of the elements of the article tested for which the applicant provided to the LNE a certificate or a guarantee of the compliance with the standards in force, the applicant being the only person responsible of the veracity of the documents that he produces to the LNE."
- It does not imply that LNE has performed any surveillance or control of its manufacture.
- The conformity to the above referenced standard does not exempt from the conformity to the regulation in force.
- 4. Copies are available upon request by the applicant.

 ETABLISSEMENT PUBLIC A CARACTERE INDUSTRIEL ET COMMERCIAL

 SIEGE SOCIAL - LABORATOIRES DE PARIS
 LABORATOIRES DE TRAPPES
 E-mail : info@ine.fr

 1, rue Gaston Boissier - 75724 Paris Cedex 15
 29, avenue Roger Hennequin - 78197 Trappes Cedex
 Siret 313 320 244 00012

 Tél. : 33 (0)1 40 43 37 00 - Fax : 33 (0)1 40 43 37 37
 Tél. : 33 (0)1 30 69 10 00 - Fax : 33 (0)1 30 69 12 34
 NAF 743 B

 BARCLAYS PARIS CENTRALE 30588 Guichet 60001 Compte 49726740101 RIB70 - CRCA PARIS IAA.DISTRIB. 18206 Guichet 00426 Compte 58381956001 RIB45



www.astralpool.com

WE RESERVE THE RIGHT TO CHANGE ALL OR PART OF THE FEATURES OF ARTICLES OR CONTENTS OF THIS DOCUMENT, WITHOUT PRIOR NOTICE