



# Room Care R2-Des plus

## Hard surface cleaner and disinfectant - concentrate

### Description

Concentrated cleaner disinfectant for the hygienic cleaning and disinfection of all water resistant hard surfaces. Also available in fully recyclable mono-material pouch.

### Key properties

- Formulated for the hygienic cleaning of hard, water-resistant surfaces
- Slightly alkaline
- Non-abrasive
- Light, delicate and fresh fragrance
- Unique, patented ONT air neutralising technology alters malodour molecules

### Benefits

- Leaves surfaces hygienically clean
- Quickly and gently removes oily and water-soluble residues
- Leaves a pleasant scent behind
- Neutralises malodour molecules, enhancing the effect of the perfume
- Colour and alphanumeric coded to prevent application mistakes
- Kills bacteria, yeast and enveloped viruses

### Use Instructions

The product can be used only with the Divermite/DQFM dosing and dilution system, which guarantees 100% cost control and safety. Apply onto the surface and distribute with a damp cloth/sponge pad and clean the surface. Let product act for the required time according to the microbiological data. Rinse with fresh water or wipe with a clean, damp cloth. Buff with a dry cloth for extra shine. For more detailed application, please refer to Room Care R2-Des plus Mini Guide.

### Dosage\*

When using with Divermite Room Care dosing unit, dose 15ml (5%) Room Care R2-Des plus into keyed bottle filled with 300ml of cold water or 2x15ml (5%) into keyed bottle filled with 600ml of cold water. Securely screw on the spray trigger, ensure the nozzle is closed and shake gently to mix.

When using with DQFM dilution dispenser unit, fill the Room Care R2-Des plus keyed spray bottle to the fill level mark or the bucket directly from the DQFM dispenser. Securely screw-on the spray trigger.

*\*This dosage is according to optimal conditions, recommendations may vary, please consult with your Diversey representative for directions.*

### Application

Spray a small quantity onto a damp cloth/sponge pad and clean the surface. Let product act for the required time according to the microbiological data. Rinse with fresh water or wipe with a clean, damp cloth. Buff with a dry cloth for extra shine. For more detailed application, please refer to Room Care R2-Des plus Mini Guide.





# Room Care R2-Des plus

## Technical data

Appearance: Clear Dark Green Liquid

Odour: Slightly perfumed

pH value (neat): ~ 11

pH value (in use): ~ 11 (5%)

Relative density (20°C): ≈ 1.03

Viscosity (mPa.s; 25°C): ≈ 40

*The above data is typical of normal production and should not be taken as a specification.*

## Safe handling and storage information

Full guidance on the handling and disposal of this product is provided in a separate Safety Data Sheet; [sds.diversey.com](https://sds.diversey.com). Store in original closed containers away from extremes of temperature. Only for professional users / specialists. Use disinfectants safely. Always read the label and product information before use and follow local regulations and advisory.

## Product compatibility

Do not use on water-sensitive surfaces, e.g. wood. Test material compatibility in a small, inconspicuous place before use. Do not use with other dilution systems or methods. Do not use undiluted.

## Microbiological data

|   | EN Test Method | Soiling Conditions | Test organisms  | Contact Time | Pass Concentration<br>% v/v |
|---|----------------|--------------------|---|--------------|-----------------------------|
| Bactericidal                                | EN 1276        | dirty conditions   | Staphylococcus aureus<br>Enterococcus hirae<br>Escherichia coli<br>Pseudomonas aeruginosa | 30 sec       | 1%                          |
|   | EN 13697       | dirty conditions   | Staphylococcus aureus<br>Enterococcus hirae<br>Escherichia coli<br>Pseudomonas aeruginosa | 2 min        | 5%                          |
| Yeasticidal                                 | EN 1650        | dirty conditions   | Candida albicans  | 1 min        | 5%                          |
|   | EN 13697       | dirty conditions   | Candida albicans  | 2 min        | 5%                          |
| Limited virucidal against enveloped viruses | EN 14476       | dirty conditions   | Modified Vaccinia virus Ankara  | 1 min        | 1%                          |
|   | EN 16777       | dirty conditions   | Modified Vaccinia virus Ankara  | 10 min       | 5%                          |

## Environmental information

Fully recyclable mono-material pouch with removable label and cap, so easy to recycle where the required infrastructure exists. The surfactants used in this product are biodegradable in compliance with the requirement of EU Detergent Regulation, EC 648/2004.

## Available pack sizes

Room Care R2-Des plus is available in 2x2L pouch.

[www.diversey.com](https://www.diversey.com)

© 2025 Diversey, Inc. All Rights Reserved. Rev.27/06/2025 en (K02128)