# 76646 Test Strip for Salt



For use with salt chlorine generators

## **INSTRUCTIONS FOR USE**

## 01/ REMOVE

With dry hands, open cap and remove a foil-wrapped test strip.

Remove Test Strip from foil Wrapper

## 02/ DIP

For best results, use test strip away from skimmers or returns. Dip strip at wrist depth and remove with pads facing up.

DO NOT shake off excess water. Hold strip level for 25 SECONDS.

#### 03/ READ

Compare to colour chart.

Match the three test pads on the test strip to the closest set of colour standards.

Complete colour match within 10 seconds, then discard test strip.

## **MEASURING RANGE**

Sodium Chloride / Salt (NaCl) ppm: 0,1000,2000,3000,4000,5000 (recommended: 3000-4000)

See label for colour chart.

## **CONTENT**

10 test strips.

# **NOTES**

Test water should be within IDEAL range listed on back of bottle. Keep cap closed after removing a strip to prevent moisture from entering the bottle. TEST TWICE WEEKLY. STORE AT ROOM TEMPERATURE

