



NOTES:


- This drawing shows general installation details related to ADB Safegate products and is not for construction. The designer must verify compliance of design with local standards and varying characteristics for each unique airfield project.
 Pavement types and dimensions shown are only indicative. Installation details may vary depending on project specific pavement
- types and dimensions.
- Please refer to product installation manual for installation process details. 3.





ELEVATE TYPICAL

	SCALE: AS SHOWN DRAWN BY: SK	UNIT: mm CHECKED BY: TH
ETES ED OMNIDIRECTIONAL INSTALLATION DETAILS	DATE: 17/02/2023	SHEET: 1-3
	ADBSG_A_AGL_RELIANCE-E_ETES L_Omni_00	




1 PIECE L868B BASE INSTALLATION

RELIANCE TAXIWAY EDGE OMNIDIRECTIONAL LIGHT Scale 1/5

NOTES:

- This drawing shows general installation details related to ADB Safegate products 1. and is not for construction. The designer must verify compliance of design with local standards and varying characteristics for each unique airfield project.
- 2. Pavement types and dimensions shown are only indicative. Installation details may vary depending on project specific pavement types and dimensions.
- Please refer to product installation manual for installation process details. 3.





NOTES:

- 1. This drawing shows general installation details related to ADB Safegate products and is not for construction. The designer must verify compliance of design with local standards and varying characteristics for each unique airfield project.
- 2. Pavement types and dimensions shown are only indicative. Installation details may vary depending on project specific pavement types and dimensions.
- 3. Please refer to product installation manual for installation process details.

